

XINDADA H12 2025

XINDADA H12 2025 4G Smartwatch User Manual

Model: H12 2025

INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your XINDADA H12 2025 4G Smartwatch. Please read this manual thoroughly before using the device to ensure proper function and to maximize your user experience.

PACKAGE CONTENTS

Verify that all items are present in your product package:

- 1 x XINDADA H12 2025 Smartwatch
- 1 x Watch Strap
- 1 x Charging Cable
- 1 x Product Manual

PRODUCT OVERVIEW

The XINDADA H12 2025 is a 4G Android 9.0 OS smartwatch featuring a 1.51-inch AMOLED display, a 500W HD camera, GPS, Wi-Fi, and comprehensive health monitoring capabilities. It supports app downloads from the Google Play Store.

Key Features:

- **Full 4G Netcom:** Supports 4G connectivity (EU/UK countries only).
- **High-Performance CPU:** SL8541E quad-core processor for smooth operation.
- **Android 9.0 OS:** Enhanced performance and security.
- **Large AMOLED Display:** 1.51-inch screen with 466x466 resolution, wide color gamut, and 178° viewing angle.

- **500W HD Camera:** Rotatable front/rear camera.
- **800mAh Battery:** Extended battery life.
- **Health Monitoring:** Heart rate, blood oxygen, sleep detection, sedentary reminders, step counting.
- **Sports Modes:** Running, walking, hiking, mountaineering, rope skipping.
- **App Support:** Download apps like WhatsApp, YouTube, Facebook, Instagram, TikTok from Google Play Store.
- **Intelligent Crown:** Rotating crown for menu navigation.

The ultra clear large screen is eye opening

1.51-inch AMOLED ultra large round screen display,
high screen to body ratio,
Resolution 466 * 466, wider display interface



Ultra wide color gamut:
98%Adobe RGB

IPS

Ultra-Wide Viewing Angle

Ultra wide vision:
viewing angle 178°(H)/178°(V)

Color Accuracy
 $\Delta E < 5$

Accurate color:
reducing power($\Delta E < 5$)



Image: The smartwatch features a 1.51-inch AMOLED display with 466x466 resolution, offering a wide color gamut (98% Adobe RGB) and a 178-degree ultra-wide viewing angle for clear visuals.

Intelligent Crown Rotating Silk Slip

You can freely choose the dial and play with the menu,
experiencing a brand new human-computer interaction
Take you into a rich world on your wrist



Image: Close-up of the smartwatch's intelligent rotating crown, which allows for intuitive navigation through menus and watch faces.

500W HD camera



Image: The smartwatch is equipped with a 500W HD camera that can rotate 180 degrees, functioning as both a front and rear camera.

SETUP

1. Charging the Device

Before first use, fully charge your smartwatch. Connect the provided charging cable to the charging port on the watch and to a standard USB power adapter (not included). The watch display will indicate charging status.

2. SIM Card Installation (for 4G connectivity)

The smartwatch supports 4G Netcom. Ensure your SIM card is compatible with the supported network bands (2G: B3+B5+B8; 3G: B1+B5+B8; 4G_FDD: B1+B3+B5+B7+B8+B20; 4G_TDD: B34+B38+B39+B40+B41). This feature is primarily for EU/UK countries. Refer to the watch's manual for specific SIM card tray access and insertion instructions.

3. Initial Power On

Press and hold the Power button (usually located on the side of the watch) until the XINDADA logo appears. Follow the on-screen prompts to select your language and initial settings.

4. Connecting to the HiSportPro App

To synchronize data and receive notifications from your mobile phone, download and connect to the HiSportPro application.

1. **Step 1:** Enable Bluetooth on both your smartwatch and your mobile phone.
2. **Step 2:** On your smartwatch, access the app market and download the "Bluetooth Assistant" application.
3. **Step 3:** On your mobile phone, download the "HiSportPro" app from your phone's app store (Google Play Store for Android, Apple App Store for iOS).
4. **Step 4:** Open the Bluetooth Assistant on your smartwatch and enable Bluetooth service.
5. **Step 5:** In the HiSportPro app on your phone, use the scan function to scan the QR code displayed on your smartwatch to establish the connection.
6. **Step 6:** Once connected, you can configure notification push settings within the HiSportPro app to receive mobile phone information on your watch.




Image: The smartwatch on a wrist, displaying a message, illustrating its capability for 4G calls and real-time message viewing.

OPERATING INSTRUCTIONS

Basic Navigation

- **Touch Screen:** Tap to select, swipe to navigate through menus and screens.
- **Rotating Crown:** Rotate the crown to scroll through lists or adjust settings. Press the crown to return to the home screen or confirm selections.
- **Power Button:** Press to wake/sleep the screen. Long press to power on/off or restart.
- **Raise to Wake:** The screen can be activated by raising your wrist.

Communication Features

- **Phone Calls:** With a SIM card installed, you can make and receive calls directly from the watch. Access the "Phone" application.
- **Messaging:** View and reply to messages (SMS, WhatsApp, etc.) directly on the watch.
- **Contacts:** Access your synchronized contacts.

Camera Usage

The smartwatch features a 500W HD camera. Open the "Camera" application. The camera can rotate 180 degrees to function as both a front-facing and rear-facing camera. Tap the screen to take photos or start video recording.

Health and Fitness Monitoring

- **Heart Rate Monitoring:** Access the "Heart Rate" app to measure your heart rate.
- **Blood Oxygen Monitoring:** Use the "Blood Oxygen" app to check your SpO2 levels.
- **Sleep Detection:** The watch automatically monitors your sleep patterns when worn during sleep. View data in the "Sleep Detection" app or HiSportPro.
- **Sedentary Reminder:** Enable this feature in settings to receive alerts when you have been inactive for too long.
- **Step Counting:** The watch automatically tracks your daily steps.

Sports Modes

The smartwatch supports various sports modes to track your exercise data.

Multiple sports modes

Unleash your passion to the fullest

Mountaineering, walking, mountain climbing and other sports modes help you stay active at all times
Mastering exercise data to safeguard your health



Image: Icons representing various sports modes available on the smartwatch, including running, walking, cycling, mountaineering, and rope skipping.

To start a workout:

1. Navigate to the "Sports" application.
2. Select your desired activity (e.g., Running, Walking, Mountaineering, Rope Skipping).
3. Tap to start the activity. The watch will begin tracking relevant metrics like duration, distance, and calories burned.
4. Tap to pause or end the activity. Your exercise data will be saved and can be viewed on the watch or in the HiSportPro app.

Other Applications and Features

- **Google Play Store:** Download and install additional applications such as WhatsApp, YouTube, Facebook, Instagram, and TikTok directly from the Play Store on your watch.
- **Weather:** View current weather conditions.
- **Music Player:** Play music stored on the watch or control music on your phone.
- **Browser:** Access the internet using the built-in browser.
- **Calendar, Calculator, Alarm:** Standard utility applications.

- **OTA Online Update:** The watch supports Over-The-Air software updates. Check for updates periodically in the settings menu to ensure optimal performance and access to new features.

MAINTENANCE

- **Cleaning:** Regularly clean your smartwatch and strap with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** While the watch may have some water resistance, avoid prolonged exposure to water, swimming, or showering with the watch unless explicitly stated otherwise in the product specifications.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the watch when the battery level is low. Store the watch in a cool, dry place when not in use for extended periods.
- **Software Updates:** Keep your watch's software updated to ensure optimal performance and security.

TROUBLESHOOTING

Problem	Possible Solution
Watch does not power on.	Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes. If it still doesn't turn on, try a long press (10-15 seconds) of the power button.
Cannot connect to HiSportPro app.	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on both devices. • Make sure the HiSportPro app is installed on your phone and Bluetooth Assistant on your watch. • Restart both the watch and the phone. • Try rescanning the QR code from the HiSportPro app.
4G network not working.	<ul style="list-style-type: none"> • Verify that your SIM card is correctly inserted and activated. • Check if your region (EU/UK) and carrier support the watch's network bands. • Ensure mobile data is enabled in the watch's settings.
Screen is unresponsive.	Restart the watch by long-pressing the power button. If the issue persists, ensure the screen is clean and dry.
Inaccurate health data.	Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensors on the back of the watch. Avoid excessive movement during measurements.

SPECIFICATIONS

Feature	Detail
Brand	XINDADA
Model	H12 2025
Operating System	Android 9.0

Feature	Detail
CPU	SL8541E Quad-core
Display	1.51-inch AMOLED, 466x466 resolution
Camera	500W HD, 180° rotation
Battery Capacity	800 mAh
Connectivity	4G (EU/UK bands), Wi-Fi, Bluetooth
Network Bands	2G: B3+B5+B8; 3G: B1+B5+B8; 4G_FDD: B1+B3+B5+B7+B8+B20; 4G_TDD: B34+B38+B39+B40+B41
App Compatibility	HiSportPro (for phone sync), Google Play Store apps
Product Weight	100 g
Package Dimensions	5 x 5 x 5 cm

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: XINDADA