

[Manuals.plus](#) /

> [Genérico](#) /

> Genérico 1L USB Cat Water Fountain Instruction Manual

Genérico ONTRMRM78R7INED955

Genérico 1L USB Cat Water Fountain Instruction Manual

Model: ONTRMRM78R7INED955

Brand: Genérico

INTRODUCTION

Thank you for choosing the Genérico 1L USB Cat Water Fountain. This automatic circulation filtration system is designed to provide fresh, clean water for your indoor cats and dogs, encouraging healthy hydration habits. Please read this manual carefully before setup and operation to ensure proper use and maintenance of your pet's new water fountain.

SAFETY INSTRUCTIONS

- Ensure the fountain is placed on a stable, level surface to prevent spills.
- Do not immerse the USB power adapter or cable in water.
- Always unplug the fountain before cleaning or performing maintenance.
- Keep the power cord away from pets to prevent chewing.
- This appliance is for indoor use only.
- The fountain features an automatic power-off function when water levels are low to prevent dry burning. However, regular monitoring of water levels is recommended.
- Use only original or approved replacement parts and filters.

PACKAGE CONTENTS

Please check that all items are present and in good condition:

- 1x Genérico 1L USB Cat Water Fountain Unit
- 1x USB Power Cable
- 1x Filter Element (pre-installed or separate)
- 1x Instruction Manual (this document)

PRODUCT OVERVIEW

The Genérico 1L USB Cat Water Fountain consists of several key components designed for easy assembly and effective water circulation.



Image: The Genérico 1L USB Cat Water Fountain showing its transparent reservoir, blue top cover with water spout, and internal pump/filter system.

Key components include the water reservoir, pump, filter, and water spout. The transparent design allows for easy monitoring of the water level.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Clean Components:** Wash the water reservoir, top cover, and water spout with mild soap and water. Rinse thoroughly to remove any soap residue. Do not wash the pump or USB cable.
3. **Install Filter:** If not already installed, place the filter element into its designated slot within the pump assembly. Ensure it is seated correctly.
4. **Assemble Pump:** Connect the pump to the water spout and place it securely in the bottom of the reservoir.
5. **Fill with Water:** Fill the reservoir with clean tap water up to the maximum fill line. The visible water level design helps prevent overfilling or underfilling.
6. **Place Top Cover:** Carefully place the top cover onto the reservoir, ensuring the water spout aligns correctly.
7. **Connect Power:** Plug the USB cable into the fountain's port and then into a compatible USB power adapter (not included) or a USB port.
8. **Position Fountain:** Place the fountain on a stable, non-slip surface in an area accessible to your pet. The non-slip rubber pads on the base provide stability.



Image: A cat drinking from the fully assembled Genérico 1L USB Cat Water Fountain, demonstrating proper setup.

OPERATING INSTRUCTIONS

Once assembled and powered, the Genérico 1L USB Cat Water Fountain operates automatically.

- **Automatic Circulation:** The electric water outlet ensures continuous circulation, providing fresh, oxygenated water for your pet.
- **Water Level Monitoring:** Regularly check the water level through the transparent reservoir. Refill when the water level is low to ensure continuous operation and prevent pump damage.
- **Water Shortage Protection:** The smart sensor automatically cuts off power when the water level is too low, preventing the pump from running dry and extending its lifespan.



Image: The water fountain demonstrating its automatic power-off feature when water levels are critically low, indicated by a red glow or similar visual cue (implied by the image context).

MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity of your fountain and the health of your pet.

- **Daily:** Check water level and refill as needed.
- **Weekly:**
 - a. Unplug the fountain.
 - b. Disassemble all removable parts (reservoir, top cover, spout, pump).
 - c. Clean all parts (except the pump and USB cable) with mild soap and water. Use a brush to remove any residue or slime.
 - d. Rinse thoroughly.
 - e. Clean the pump: Carefully open the pump cover and remove the impeller. Clean the impeller and its housing with a small brush. Reassemble the pump.
 - f. Reassemble the fountain and refill with fresh water.
- **Filter Replacement:** Replace the filter element every 2-4 weeks, or more frequently if you have multiple pets or notice reduced water flow/quality.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No water flow or weak flow	<ul style="list-style-type: none"> ◦ Low water level ◦ Pump or filter clogged ◦ Pump impeller dirty ◦ Power disconnected 	<ul style="list-style-type: none"> ◦ Refill water to appropriate level. ◦ Clean or replace filter. ◦ Clean pump impeller. ◦ Check USB connection and power source.
Fountain making unusual noise	<ul style="list-style-type: none"> ◦ Low water level ◦ Pump not properly seated ◦ Impeller obstructed 	<ul style="list-style-type: none"> ◦ Refill water. ◦ Ensure pump is securely placed. ◦ Clean pump and impeller.
Water appears dirty or has odor	<ul style="list-style-type: none"> ◦ Infrequent cleaning ◦ Filter needs replacement 	<ul style="list-style-type: none"> ◦ Perform thorough cleaning. ◦ Replace filter element.
Fountain stops working unexpectedly	<ul style="list-style-type: none"> ◦ Water level too low (auto shut-off) ◦ Power outage or disconnection ◦ Pump malfunction 	<ul style="list-style-type: none"> ◦ Refill water and restart. ◦ Check power connection. ◦ Contact customer support if pump is faulty.

SPECIFICATIONS

Feature	Detail
Model Number	ONTRMRM78R7INED955
Brand	Genérico
Capacity	1 Liter (1L)
Power Source	USB (5V)
Product Dimensions	Approx. 15 cm (5.91 in) diameter x 10 cm (3.94 in) height
Product Weight	540 g
Color	Blue (for this variant)
Features	Automatic Circulation, Filtration, Water Shortage Protection, Automatic Power-off, Visible Water Level, Non-slip Base, Removable Parts



Image: Diagram showing the approximate dimensions of the water fountain: 15cm (5.91in) diameter and 10cm (3.94in) height.

WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the

documentation included with your purchase or contact the retailer. For technical support, replacement parts, or any inquiries, please contact the manufacturer or your point of purchase.

Manufacturer: Genérico

(Contact information may vary by region. Please check your purchase receipt or product packaging for specific support details.)