

Joso Mix Master

Joso Mix Master Keyboard and Mouse Adapter for PS5 User Manual

Model: Mix Master

1. INTRODUCTION

The Joso Mix Master Keyboard and Mouse Adapter is designed to enhance your gaming experience on PlayStation 5 consoles by allowing the use of a standard keyboard and mouse. This adapter converts keyboard and mouse inputs into controller signals, providing precise control for various game genres. It features a 1000Hz polling rate for ultra-low latency and supports on-the-fly sensitivity adjustments.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Joso Mix Master Keyboard and Mouse Converter
- 1 x P5 General Adapter
- 1 x Type-C to USB-A Cable
- 1 x USB-A (Female) to Type-C (Male) Adapter (for PS5 front Type-C port)
- 1 x User Manual



Image: The Joso Mix Master adapter and its included accessories, displayed on a product box.

3. COMPATIBILITY

The Joso Mix Master adapter is compatible with the following PlayStation 5 console models:

- PlayStation 5 (P5)
- PlayStation 5 Slim (P5 Slim)
- PlayStation 5 Pro (P5 Pro)

PLAY WITH KEYBOARD & MOUSE ON PS5 VIA JOSO ADAPTER

This keyboard adapter is universal compatible with PS5 series, including the P5 (2020 models), P5 Slim (2023 models), and P5 Pro (2024 model).



Image: A visual representation of the Joso adapter connected to a PS5 console, illustrating compatibility with different PS5 models (Digital, Disc, Slim, Pro).

4. SETUP INSTRUCTIONS

Follow these steps to connect and set up your Joso Mix Master adapter:

1. **Enable USB Cable Function:** On your PlayStation 5 console, navigate to the settings and enable the "Use USB Cable" function. This is crucial for the adapter to function correctly.
2. **Connect Peripherals:** Plug your keyboard and mouse into the designated USB ports on the Joso Mix Master adapter.
3. **Connect Adapter to PS5:**

- For standard PS5 models, plug the adapter directly into an available USB-A port on the console.
- For PS5 Slim/Pro models, use the included USB-A (Female) to Type-C (Male) adapter to connect the Joso Mix Master to the front Type-C port of your console.

4. **Verify Connection:** Once connected, the blue indicator light on the Joso Mix Master adapter will stay on, indicating a successful connection and recognition by the console.

PLUG & PLAY IN SECONDS

1. **Enable** — Set "Use USB Cable" in PS5 settings.
2. **Connect** — * Plug P5General/mouse/keyboard into keyboard adapter; * Plug adapter into PS5 front port (use included adapter for Slim/Pro).
3. **Ready** — Solid blue LED = connected.

See diagram for default key layout.



KEY VALUE DIAGRAM



The blue indicator light stays on, it indicates successful recognition. **Indicator Light**



Image: A step-by-step diagram illustrating how to connect the Joso adapter, keyboard, and mouse to a PS5 console, including the use of the Type-C adapter for Slim/Pro models. The indicator light is also shown.

5. OPERATING INSTRUCTIONS

5.1. General Gameplay

The Joso Mix Master allows you to use your keyboard and mouse for precise control in various games, including FPS, RPG, and adventure titles. This setup provides enhanced aiming accuracy, faster building, and superior movement compared to a standard controller.

DOMINATE WITH PRECISION

Take full control with your familiar keyboard and mouse for pinpoint accuracy, lightning-fast builds, and fluid movement.



Image: A gamer actively playing on a PS5 using a keyboard and mouse connected via the Joso adapter, demonstrating precise control in a first-person shooter game.

MASTER EVERY GENRE. DOMINATE EVERY GAME.

– Perfect for FPS, RPG & Adventure (Apex, COD, Fortnite & more)



Image: A graphic illustrating various game genres (FPS, RPG, Adventure) and popular titles like Apex, COD, and Fortnite, indicating the adapter's versatility.

5.2. On-the-Fly Sensitivity Adjustment

You can adjust mouse sensitivity during gameplay without pausing the action:

- **General Sensitivity:** Hold down the **Ctrl** key on your keyboard and scroll the mouse wheel up or down to adjust the overall mouse sensitivity. Release the Ctrl key to lock in your preferred setting.
- **Aim Down Sights (ADS) Sensitivity:** To adjust ADS sensitivity, actively aim down sights in-game and then hold down the **Ctrl** key while scrolling the mouse wheel up or down. This allows for precise adjustments specific to aiming scenarios.

FASTER AIMING WITH MOUSE

Ctrl + Mouse Wheel Up/Down to adjust mouse sensitivity
to help you aim quickly and win!



Play with Controller



Play with Keyboard Mouse

Image: A close-up of the Joso adapter and a mouse, with an overlay demonstrating how scrolling the mouse wheel while holding Ctrl adjusts sensitivity, comparing controller vs. keyboard/mouse aiming.

5.3. One-Touch Fire Function Switching

The adapter supports switching between different fire modes for an improved shooting experience:

- Pressing the "F4" key on your keyboard can toggle various fire modes on or off.
- In **Rapid Fire mode**, you must press and hold the left mouse button to fire continuously.

ONE-TOUCH SWITCHING OF FIRE FUNCTION

Pressing key "F4" can turn on/off fire modes, better shooting gaming experience.

* In Rapid Fire mode, you must press and hold the left mouse button to fire continuously.





Image: A hand operating a mouse, with an in-game overlay showing the effect of the one-touch fire function, highlighting the F4 key for mode switching.

6. KEY MAPPING

The Joso Mix Master adapter provides a default key mapping that translates keyboard and mouse inputs to PS5 controller actions. Refer to the diagram below for a visual representation of the default key assignments.

PLUG & PLAY IN SECONDS

1. Enable — Set "Use USB Cable" in PS5 settings.
 2. Connect — * Plug P5General/mouse/keyboard into keyboard adapter; * Plug adapter into PS5 front port (use included adapter for Slim/Pro).
 3. Ready — Solid blue LED = connected.
- See diagram for default key layout.



The blue indicator light stays on, it indicates successful recognition.

Indicator Light

Image: A detailed diagram showing the default key mappings from a standard keyboard and mouse to PS5 controller buttons (e.g., ESC to PS button, Q to L1, E to R1, Space to X, etc.).

7. MAINTENANCE

To ensure the longevity and optimal performance of your Joso Mix Master adapter, follow these simple maintenance guidelines:

- Keep the adapter clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the adapter to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or modify the adapter, as this will void the warranty and may cause damage.

- Store the adapter in a safe place when not in use to prevent physical damage.

8. TROUBLESHOOTING

If you encounter any issues with your Joso Mix Master adapter, please refer to the following common solutions:

- **Adapter Not Recognized / No Input:**

- Ensure the "Use USB Cable" function is enabled in your PS5 settings.
- Check all cable connections to ensure they are secure.
- Try connecting the adapter to a different USB port on your PS5.
- Verify that the blue indicator light on the adapter is solid, indicating a successful connection.
- Ensure your keyboard and mouse are functioning correctly when connected directly to a computer.

- **Lag or Input Delay:**

- The Joso Mix Master features a 1000Hz polling rate for minimal latency. If you experience lag, ensure your PS5 system software is up to date.
- Try restarting your PS5 console and reconnecting the adapter.

- **Firmware Updates:**

- Periodically check the official Joso website for any available firmware updates for the Mix Master adapter. Firmware updates can improve performance and compatibility. Instructions for updating firmware will be provided on the website.

9. SPECIFICATIONS

Feature	Detail
Model Number	Mix Master
Brand	Joso
Compatible Devices	PlayStation 5 (PS5, PS5 Slim, PS5 Pro)
Specific Product Uses	Video Game Console
Connector Type	USB Type A
Color	Black
Number of Ports	4
Power Plug Type	Type C – 2 pin (European plug)
Polling Rate	1000 Hz

10. WARRANTY AND SUPPORT

Specific warranty information for the Joso Mix Master Keyboard and Mouse Adapter is not provided within

this manual. For details regarding warranty coverage, technical support, or to inquire about firmware updates, please refer to the official Joso website or contact Joso customer service directly.