

BLOKEES NARUTO SHIPPUDEN LE01 KURAMA

BLOKEES Naruto Shippuden LE01 Nine Tails Kurama Model Kit
Instruction Manual

Model: NARUTO SHIPPUDEN LE01 KURAMA | Brand: BLOKEES

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BLOKEES Naruto Shippuden LE01 Nine Tails Kurama Model Kit. Please read all instructions carefully before beginning assembly to ensure proper construction and functionality.

Safety Information: This product contains small parts and is recommended for ages 14 years and up. Keep out of reach of small children to prevent choking hazards.

WHAT'S IN THE BOX

Verify that all components listed below are present before starting assembly.

- Kurama (Nine Tails) Figure components (263 pieces)
- Naruto Uzumaki Figure components
- Three (3) Sets of Interchangeable Hands for Kurama
- One (1) Tailed Beast Ball accessory
- One (1) Display Stand
- One (1) Magnetic Stick (for light-up feature)
- Instruction Booklet (this manual)



Image: All components included in the BLOKEES Naruto Shippuden LE01 Nine Tails Kurama Model Kit.

ASSEMBLY INSTRUCTIONS

This model kit is designed for snap-fit assembly, requiring no tools, paint, glue, or cutting. Follow the detailed diagrams in the included instruction booklet for precise component identification and placement. The kit consists of 263 pieces for

Kurama and additional pieces for Naruto.

1. **Preparation:** Carefully remove all components from their packaging. Organize pieces by section (e.g., Kurama body, tails, Naruto figure) to facilitate assembly.
2. **Kurama Body Assembly:** Begin by assembling the core body sections of Kurama. Pay close attention to the orientation of each piece as indicated in the diagrams. Ensure all connections are secure and flush.
3. **Tail Assembly:** Assemble the nine independently movable tails. Each tail consists of multiple segments. Connect these segments firmly to allow for articulation. Attach the completed tails to Kurama's main body.
4. **Limb Assembly:** Assemble Kurama's multi-segment articulated hands and legs. Connect these to the body, ensuring full range of motion at the 31 articulation points.
5. **Head and Facial Features:** Assemble Kurama's head, including the ears and jaw. Ensure the eye components are correctly installed for the magnetic light-up feature.
6. **Naruto Uzumaki Figure Assembly:** Assemble the Naruto Uzumaki figure according to its specific instructions.
7. **Accessory Preparation:** Prepare the three sets of interchangeable hands for Kurama and the Tailed Beast Ball accessory. These can be attached after the main figures are assembled.
8. **Display Stand Assembly:** Assemble the display stand. The stand is designed to support Kurama in various dynamic poses.



Image: Assembled Kurama figure, ready for posing.





豆包AI生成

Image: Assembled Naruto Uzumaki figure.

OPERATING INSTRUCTIONS

Posing Kurama

Kurama features 31 fully articulated joints, including multi-segment articulated hands, legs, and nine independently movable tails. This allows for a wide range of dynamic poses. Gently manipulate the joints to achieve desired positions. Avoid excessive force to prevent damage.

Magnetic Light-Up Eyes

To activate Kurama's glowing eyes, use the included magnetic stick. Touch the tip of the magnetic stick to the designated activation point on Kurama's head (refer to the detailed instruction booklet for exact location). The eyes will illuminate, adding a dramatic effect. Remove the magnetic stick to deactivate the light.



Image: Kurama figure in a dynamic crouching pose.

Interchangeable Hands and Accessories

To change Kurama's hands, gently pull off the current hand and snap on one of the three interchangeable sets. The Tailed Beast Ball accessory can be placed in Kurama's hand or positioned on the display stand as desired.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the figures. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the model kit away from direct sunlight, extreme temperatures, and high humidity to prevent material degradation and discoloration.
- **Handling:** Handle the figures with care, especially when posing articulated joints. Avoid dropping the figures or applying excessive pressure.

TROUBLESHOOTING

- **Parts do not fit:** Ensure you are using the correct parts as indicated in the instruction diagrams. Apply gentle, even pressure. If a part is particularly tight, ensure there are no obstructions or excess plastic. Do not force parts excessively.
- **Joints are loose or parts fall off easily:** This can sometimes occur with articulated models. Ensure all joint connections are fully seated. If a joint remains loose, it may be due to manufacturing tolerances. Consider applying a very small amount of clear nail polish or a specialized joint-tightening fluid to the ball joint (allow to dry completely before reassembling) to increase friction.
- **Magnetic light-up eyes not working:**
 - Ensure the magnetic stick is correctly applied to the activation point.
 - Check if the included nonstandard battery is properly installed and has charge. Replace if necessary.
- **Missing or damaged parts:** If you encounter missing or damaged components upon opening the kit, please contact BLOKEES customer support for assistance.

SPECIFICATIONS

Attribute	Detail
Model Name	NARUTO SHIPPUDEN LE01 KURAMA
Brand	BLOKEES
Model Number	LE01 (Manufacturer Part Number: 73524)
UPC	810181532579
Material	ABS Environmentally Friendly Plastic
Piece Count	263 components (Kurama)
Kurama Height	7.09 inches (crouching)

Naruto Height	2.95 inches
Articulation Points	31 fully articulated joints (Kurama)
Special Features	Magnetic Light-Up Eyes, Interchangeable Hands, Display Stand, Tailed Beast Ball
Recommended Age	14 years and up
Batteries	1 Nonstandard Battery (included, for light-up feature)
Item Weight	200 g
Item Dimensions (L x W x H)	7.09" x 7.09" x 7.09"

WARRANTY INFORMATION

BLOKEES products are manufactured with high-quality standards. For specific warranty details regarding manufacturing defects or missing components, please refer to the packaging or contact BLOKEES customer support directly. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your BLOKEES Naruto Shippuden LE01 Nine Tails Kurama Model Kit, please visit the official BLOKEES website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official online presence. You can also visit the [BLOKEES Store on Amazon](#) for more information.

© 2026 BLOKEES. All rights reserved. Naruto Shippuden ™ © Masashi Kishimoto.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GJX2W1M4>

More documents and user manuals: <https://manuals.plus/>