

Ahokua Mid-Century Modern Narrow Accent Cabinet

Ahokua Mid-Century Modern Narrow Accent Cabinet User Manual

Model: Mid-Century Modern Narrow Accent Cabinet

1. INTRODUCTION

Thank you for choosing the Ahokua Mid-Century Modern Narrow Accent Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This cabinet is designed with a refined mid-century modern aesthetic, featuring a geometric recessed panel door and a brass handle. Its slim profile makes it suitable for various compact spaces, including entryways, living rooms, hallways, or home offices. The enclosed storage compartment includes an adjustable interior shelf for flexible organization.

2. SAFETY INFORMATION

WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always use tip-over restraint devices provided with the product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time (if applicable).
- Place heaviest items in the lowest drawers (if applicable).

Failure to follow these warnings can result in death or serious injury.

Weight Capacity:

- Desktop load-bearing capacity: 80 lbs (36 kg)
- Adjustable shelf load-bearing capacity: 30 lbs (13.6 kg)

Do not exceed these weight limits to ensure stability and prevent damage.

3. PACKAGE CONTENTS

Before assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Side, Back, Top, Bottom)
- Door Panel
- Adjustable Shelf
- Solid Wood Legs (4)
- Handle (Brass)
- Hinges (2)
- Magnetic Door Closure
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Anti-Tip Kit
- Assembly Tool (Hex Key/Wrench)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

1. **Attach Legs:** Secure the four solid wood legs to the bottom panel of the cabinet using the provided screws. Tighten them firmly with the included tool.
2. **Assemble Cabinet Frame:** Connect the side panels to the back panel using dowels and cam locks. Ensure all connections are secure and flush.
3. **Insert Shelf Pins:** Locate the pre-drilled holes inside the cabinet for the adjustable shelf. Insert the shelf pins into the desired height.
4. **Place Adjustable Shelf:** Carefully place the adjustable shelf onto the installed shelf pins.
5. **Attach Door:** Mount the door panel to the cabinet frame using the hinges and screws. Adjust hinges as needed to ensure the door closes smoothly and aligns properly.
6. **Install Handle and Magnetic Closure:** Attach the brass handle to the door. Install the magnetic door closure mechanism to ensure the door stays securely shut.
7. **Install Anti-Tip Kit:** For safety, attach the anti-tip kit to the back of the cabinet and secure it to a wall stud according to the kit's specific instructions. This step is crucial to prevent accidental tip-overs.



Image 1: Product dimensions and load capacities. Overall dimensions are 17.32"W x 13.19"D x 31.89"H. Desktop capacity is 80 lbs, and shelf capacity is 30 lbs.



Sculpted Geometric Door Design



Two-Tone Wood Contrast



Tapered Solid Wood Legs



Magnetic Door Closure

Image 2: The cabinet with its door open, illustrating the adjustable interior shelf for flexible storage configurations.

5. OPERATING INSTRUCTIONS

Using your Ahokua Accent Cabinet is straightforward:

- **Opening/Closing the Door:** Gently pull the brass handle to open the door. The magnetic closure will keep the door securely shut when closed.
- **Adjusting the Shelf:** To adjust the height of the interior shelf, first remove any items from the shelf. Lift the shelf off its pins, then remove the pins from their current holes. Reinsert the pins into the desired pre-drilled holes at a new height, and carefully place the shelf back onto the pins. Ensure the shelf is level and securely seated before placing items on it.
- **Placement:** Position the cabinet on a flat, stable surface. Ensure the anti-tip kit is properly installed and secured to a wall stud for maximum safety.

6. MAINTENANCE

To ensure the longevity and appearance of your cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, dry cloth. For stubborn marks, use a slightly damp cloth with mild soap, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood from warping or cracking.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten as necessary.

7. TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common solutions:

- **Wobbly Cabinet:** Ensure the cabinet is placed on a level surface. Check that all leg screws and frame connections are securely tightened. Adjust leg levelers if present.
- **Door Not Closing Properly:** Check the alignment of the hinges. Loosen hinge screws slightly, adjust the door position, and then retighten. Ensure the magnetic closure is properly aligned and functioning.
- **Shelf Not Level:** Verify that the shelf pins are inserted into corresponding holes at the same height on both sides. Ensure the shelf is fully seated on the pins.
- **Scratches/Minor Damage:** For minor scratches, wood repair markers or touch-up pens matching the cabinet's finish can be used.

If problems persist, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Ahokua
Model Name	Mid-Century Modern Narrow Accent Cabinet
Color	Warm Brown
Material	Wood-based structure, Solid Wood Legs
Product Dimensions (D x W x H)	13.19" x 17.32" x 31.89" (33.5 cm x 44 cm x 81 cm)
Number of Doors	1
Number of Shelves	1 (Adjustable)
Desktop Load Capacity	80 lbs (36 kg)
Shelf Load Capacity	30 lbs (13.6 kg)
Additional Features	Geometric Panel Door, Raised Legs, Magnetic Door Closure

MULTI-FUNCTIONAL STORAGE CABINET



Image 3: Detailed view highlighting the sculpted geometric door design, two-tone wood contrast, tapered solid wood legs, and the magnetic door closure mechanism.

9. WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact Ahokua customer support for warranty terms and conditions.

10. CUSTOMER SUPPORT

For any questions regarding assembly, product use, missing parts, or other inquiries, please contact Ahokua customer support through the retailer where the product was purchased or visit the official Ahokua brand store online. We are committed to providing assistance to ensure your satisfaction with your Ahokua cabinet.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question