

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Dioche](#) /
- › [Dioche 2-in-1 USB Rechargeable Epilator and Trimmer User Manual](#)

## Dioche Diochegz0d3kxouc

# Dioche 2-in-1 USB Rechargeable Epilator and Trimmer User Manual

Model: Diochegz0d3kxouc (HT-560)

## 1. IMPORTANT SAFETY INFORMATION

---

Please read all instructions carefully before using the Dioche 2-in-1 Epilator and Trimmer. Keep this manual for future reference.

- **Water Safety:** This device is waterproof and suitable for wet and dry use. However, do not immerse the charging cable or adapter in water. Ensure the charging port is completely dry before connecting the USB cable.
- **Charging:** Use only the provided USB cable for charging. Do not use if the cable or device is damaged.
- **Skin Irritation:** If you experience severe irritation, redness, or discomfort, discontinue use immediately. Consult a dermatologist if symptoms persist.
- **Children:** Keep out of reach of children. This device is not a toy.
- **Maintenance:** Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- **Storage:** Store the device in a cool, dry place when not in use.

## 2. PRODUCT OVERVIEW

---

The Dioche 2-in-1 Epilator and Trimmer is a versatile hair removal device designed for women, offering both epilation and precision trimming functions. Its ergonomic design and waterproof construction make it convenient for use in various settings.

### Key Features:

- **2-in-1 Functionality:** Combines epilation for thorough hair removal and a precision trimming head for sensitive or smaller areas.

- **Efficient Shaving Technology:** Advanced mechanisms ensure smooth skin with reduced irritation.
- **Waterproof Design:** Allows for comfortable wet and dry use, and easy cleaning.
- **USB Rechargeable:** Convenient charging via USB.
- **Digital Display:** Shows power level and other indicators.
- **Portable:** Compact and lightweight for travel.

### Package Contents:

- 1 x Dioche Women's Epilator
- 1 x Replacement Trimmer Head
- 1 x USB Charging Cable
- 1 x Cleaning Brush
- 1 x User Manual (this document)



Image 2.1: Dioche Epilator and its accessories, including the main unit, a separate trimmer head, a USB cable, and a small cleaning brush.




Image 2.2: Visual representation of the epilator's features, highlighting its two-speed settings, dual-function blade, built-in light, powerful motor, USB charging capability, and skin-friendly blade design.

## 3. SETUP AND CHARGING

---

### 3.1 Unboxing

Carefully remove all components from the packaging. Check for any damage and ensure all listed package contents are present.

### 3.2 Charging the Device

1. Ensure the device is turned off before charging.
2. Locate the USB charging port on the device. Ensure it is dry.
3. Connect the small end of the provided USB cable to the device's charging port.
4. Connect the larger end of the USB cable to a compatible USB power source (e.g., computer, USB wall adapter, power bank).
5. The digital display will indicate the charging status. A full charge takes approximately 1.5 hours.
6. Once fully charged, disconnect the USB cable.

# USB Charging Convenient and fast



Image 3.1: The epilator being charged via USB, illustrating its compatibility with various USB power sources.

## 3.3 Attaching/Changing Heads

The device comes with an epilator head and a replacement trimmer head. To change heads:

1. Ensure the device is turned off.
2. Gently pull the current head upwards to detach it from the main body.
3. Align the desired head (epilator or trimmer) with the main body and press down until it clicks securely into place.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Basic Operation

1. **Power On/Off:** Press the power button located on the front of the device to turn it on or off. The digital display will illuminate.
2. **Speed Settings:** The device features 2 speed settings. Press the power button repeatedly to cycle through the speeds (if applicable, based on digital display).
3. **Illumination Light:** The built-in illumination light helps to reveal fine hairs for more thorough removal.



Image 4.1: Front view of the epilator, highlighting the power button and digital display.

## 4.2 Using the Epilator Head

The epilator head is designed for efficient removal of hair from the root, providing longer-lasting smoothness.

- Ensure your skin is clean and dry, or slightly damp if using in the shower.
- Hold the device at a 90-degree angle to your skin.
- Gently glide the epilator against the direction of hair growth.
- Do not press too hard. Move slowly and steadily for best results.
- For sensitive areas, stretch the skin taut to minimize discomfort.



Image 4.2: Detailed view of the epilator head, showing the stainless steel tweezers for effective hair removal.



Image 4.3: The epilator head, emphasizing its stainless steel, non-irritating design and powerful motor suitable for full body use.

### 4.3 Using the Trimmer Head

The precision trimmer head is ideal for shaping, tidying, or for areas where epilation is not preferred.

- Attach the trimmer head as described in Section 3.3.
- Hold the device flat against the skin or at a slight angle, depending on the desired trim length.
- Move the trimmer slowly and evenly over the area.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and hygiene of your device.

1. **After Each Use:** Turn off the device and detach the head.
2. **Cleaning the Head:** Use the provided cleaning brush to remove any trapped hairs from the epilator or trimmer head. For a more thorough clean, rinse the head under running water. Ensure the head is completely dry before reattaching or storing.
3. **Cleaning the Body:** Wipe the main body of the device with a damp cloth. Do not use abrasive

cleaners or solvents.

4. **Drying:** Allow all parts to air dry completely before reassembling or storing.
5. **Storage:** Store the device and its accessories in a clean, dry place, away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Dioche Epilator and Trimmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully (refer to Section 3.2).
Device not charging.	USB cable or power source issue; charging port is wet.	Ensure the USB cable is properly connected and the power source is functional. Check if the charging port is dry. Try a different USB port or adapter.
Poor hair removal performance.	Head is dirty or damaged; incorrect usage angle.	Clean the epilator/trimmer head thoroughly. Ensure the head is securely attached. Review operating instructions for correct angle and technique.
Excessive skin irritation.	Skin not prepared; pressing too hard; sensitive skin.	Ensure skin is clean and dry. Do not press too hard. Consider using the trimmer head for very sensitive areas. If irritation persists, discontinue use.

If the problem persists after trying these solutions, please contact Dioche customer support.

## 7. SPECIFICATIONS

---

<b>Model Number</b>	Diochegz0d3kxouc (HT-560)
<b>Brand</b>	Dioche
<b>Battery Type</b>	Built-in Lithium-ion battery
<b>Battery Capacity</b>	600 mAh
<b>Power</b>	5W
<b>Input</b>	5V=1A
<b>Charging Time</b>	Approx. 1.5 hours
<b>Dimensions (Package)</b>	17 x 13 x 4 cm
<b>Weight (Package)</b>	252 g
<b>Material</b>	ABS
<b>Waterproof</b>	Yes (Wet & Dry Use)

Country of Origin

China



Image 7.1: Back of the epilator displaying technical specifications such as model number, power, input voltage, and

charging time.

## 8. WARRANTY AND SUPPORT

---

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Dioche stands behind the quality of its products.

For further assistance, technical support, or to inquire about replacement parts, please visit the official Dioche brand store or contact their customer service department.

**Dioche Brand Store:** [Visit Dioche Store on Amazon](#)