

Weibath 26446947-WBC

Weibath 71-inch Whirlpool Bathtub

INSTRUCTION MANUAL - MODEL 26446947-WBC

Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your Weibath 71-inch Whirlpool Bathtub. Please read all instructions carefully before installation and use to ensure proper function and longevity of your product. Keep this manual for future reference.

Safety Information

- **Electrical Safety:** Ensure all electrical connections are performed by a qualified electrician in accordance with local and national electrical codes. The bathtub must be connected to a dedicated, grounded circuit protected by a Ground Fault Circuit Interrupter (GFCI).
- **Water Temperature:** Do not exceed 104°F (40°C) water temperature. Prolonged immersion in hotter water can cause hyperthermia.
- **Chemicals:** Use only approved cleaning agents for acrylic surfaces. Avoid abrasive cleaners or solvents that can damage the tub finish or internal components.
- **Children:** Supervise children at all times when they are near or in the bathtub.
- **Medical Conditions:** Consult a physician before use if you have any medical conditions, are pregnant, or are taking medication.

Setup

1. Pre-Installation Checks

- Verify that the installation area can support the weight of the bathtub filled with water and occupants.
- Ensure adequate space for plumbing and electrical connections.
- Confirm that all necessary plumbing and electrical rough-ins are in place according to local codes.

2. Dimensions and Placement

Refer to the dimension diagram for precise measurements to ensure proper fit and clearance in your bathroom.



Image: Dimension diagram of the Weibath 71-inch whirlpool tub, showing length 70.87 inches (1800mm), width 43.31 inches (1100mm), and height 24.8 inches (630mm). Internal dimensions for bathing area are also indicated.

3. Installation Steps

1. **Leveling:** Adjust the leveling feet on the bottom of the tub to ensure it is perfectly level.
2. **Plumbing Connections:** Connect the hot and cold water supply lines to the tub's faucet inlets. Ensure all connections are watertight. Connect the drain assembly to your household drainage system.
3. **Electrical Connections:** Have a qualified electrician connect the tub's electrical system to a dedicated GFCI-protected circuit.
4. **Leak Test:** Fill the tub with water and run the jets for several minutes. Carefully inspect all plumbing connections for leaks.

Operating Instructions

1. Filling the Bathtub

Open the hot and cold water valves using the mixer controls. Fill the tub to a level above the highest jets before activating

any massage functions.



Image: Close-up of the bathtub's mixer, faucet, and integrated shower head, showing water spraying from the shower.

2. Using Whirlpool and Air Massage Jets

Once the tub is filled, use the digital control panel to activate the whirlpool jets and air massage system. Adjust intensity as desired. The 16 strategically placed jets provide a full-body hydro-massage.



Image: Close-up of the bathtub's interior, showing multiple water jets and LED bubble jets on the acrylic surface.

3. LED Chromatherapy

Activate the LED chromatherapy feature via the digital controls to enjoy calming color therapy during your soak. Cycle through colors or select a static color.



Image: The Weibath whirlpool tub filled with water, illuminated by blue LED chromatherapy lighting, showcasing the jets and dual headrests.

4. Integrated Shower

The integrated shower system can be used by pulling out the handheld shower head from its holder and pressing the diverter button on the mixer to direct water flow to the shower.

5. Draining the Bathtub

After use, open the drain by rotating the drainer knob or pressing the pop-up drain mechanism. The efficient center drain (1.77" diameter) ensures quick drainage.



Image: Close-up of the bathtub's drainer with water intake, showing water flowing into the tub.

Maintenance

1. Cleaning the Bathtub

- **Acrylic Surface:** Clean the acrylic surface with a soft cloth and a non-abrasive, mild bathroom cleaner. Rinse thoroughly with water after cleaning.
- **Jets and Plumbing:** Periodically run the jets with a specialized jetted tub cleaner or a solution of white vinegar and water to prevent buildup and maintain hygiene. Follow the cleaner's instructions.
- **Drain:** Regularly clean the drain cover and remove any hair or debris to ensure efficient drainage.

2. Material Properties

The bathtub is constructed from high-quality acrylic, known for its durability and strong thermal insulation properties, designed to maintain water temperature for extended periods.



Acrylic material

High hardness
Strong thermal insulation
Designed for full body immersion



Keeping Warm



Image: Diagram showing the layers of the acrylic bathtub material, including acrylic layer and fiberglass layers, alongside a graph illustrating temperature retention over time.

Troubleshooting

- **Jets Not Working:** Check if the tub is filled above the jet level. Ensure the power supply is connected and the GFCI has not tripped.
- **No Power to Control Panel:** Verify the electrical connection and check the GFCI. If the issue persists, consult a qualified electrician.
- **Leaks:** Immediately turn off the water supply. Inspect all plumbing connections for loose fittings or damaged seals. Tighten or replace as necessary. If the leak is from the tub body, contact customer support.
- **Weak Jet Pressure:** Ensure the water intake is clear of debris. Check the water level in the tub.

Specifications

Feature	Specification
Model Number	26446947-WBC
Dimensions (L x W x H)	70.9" x 43.31" x 24.8" (1800mm x 1100mm x 630mm)
Material	Acrylic
Color	White
Installation Type	Freestanding
Number of Jets	16 (Whirlpool and Air Massage)
Features	LED Chromatherapy, Digital Controls, Integrated Shower, Dual Headrests
Drain Diameter	1.77"
Item Weight	346 Pounds

Warranty

Weibath products are covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase or contact customer support for detailed warranty terms and conditions.

Support

For technical assistance, replacement parts, or warranty claims, please contact Weibath customer support through the retailer where the product was purchased or visit the official Weibath website.

Online Support: [Weibath Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question