Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AWESAFE 7 inch

AWESAFE 7-inch Car GPS Navigation System User Manual

Model: 7 inch

1. Introduction

Thank you for choosing the AWESAFE 7-inch Car GPS Navigation System. This device is designed to provide reliable navigation and enhance your driving experience with features such as voice guidance, custom route planning, and safety alerts. Please read this manual thoroughly before operating the device to ensure proper use and optimal performance.



Image 1.1: The AWESAFE 7-inch Car GPS Navigation System installed on a vehicle dashboard, displaying a navigation map.

2. Package Contents

Verify that all items listed below are included in your package:

- GPS Navigation Unit
- Car Charger
- USB Cable

- Suction Cup Mount
- User Manual



Image 2.1: All components included in the AWESAFE GPS Navigation System package.

3. Setup and Installation

3.1 Device Overview and Ports

Familiarize yourself with the device's physical layout and connection ports.



Image 3.1: Front, side, and rear views of the GPS unit, highlighting the 7-inch screen, dimensions, headset socket, TF card slot, and USB interface.

3.2 Mounting the Device

The GPS unit can be mounted using the provided suction cup mount. Ensure the mounting surface is clean and dry for secure attachment.

1. Attach the suction cup mount to the back of the GPS unit.
2. Clean the desired area on your windshield or dashboard.
3. Press the suction cup firmly against the surface and engage the lever to secure it.
4. Adjust the viewing angle as needed. The mount allows for front, rear, and side rotation.



Image 3.2: Steps for attaching the mount to the dashboard, illustrating the rotational capabilities.




Image 3.3: The GPS unit mounted, demonstrating the adjustable rotation for optimal viewing.

3.3 Powering the Device

Connect the car charger to the GPS unit's USB port and plug the other end into your vehicle's cigarette lighter socket. The device will power on automatically or can be turned on using the power button.

4. Operating Instructions

4.1 Basic Navigation

The GPS navigation system comes with preloaded maps of North America (USA, Canada, Mexico). To begin navigation:

1. From the main menu, select "Navigation" or "Map".
2. Enter your destination using options like Postcode, Address, Coordinates, or Points of Interest (POI).
3. Choose your preferred route option: Fast, Green, Short, or Easy.
4. Confirm the route, and the system will provide turn-by-turn voice guidance.



Image 4.1: The GPS display showing an active navigation route with key travel information.



Image 4.2: The navigation system supports both 2D and 3D map views for enhanced clarity.

4.2 Customized Route Planning

For specific vehicle types, the GPS allows route customization based on vehicle dimensions (weight, length, height, width) to avoid restricted roads. This feature is particularly useful for trucks and larger vehicles.




Image 4.3: The GPS system offers route planning tailored for different vehicle types and modes of travel.

4.3 Intelligent Voice Navigation

The system provides clear voice prompts for turn-by-turn directions, road names, current speed, and lane assistance. It also informs you of remaining distance and estimated arrival time.

4.4 FM Broadcast Function

You can transfer the GPS audio output to your car's stereo system via FM broadcast. This allows navigation instructions to play through your car speakers.

1. Access the FM settings on your GPS unit.
2. Select an unused FM frequency on the GPS.
3. Tune your car radio to the same FM frequency.
4. GPS audio will now play through your car speakers.



Image 4.4: The FM connection interface on the GPS unit, allowing frequency selection.




Image 4.5: Visual guide for setting up FM transmission from the GPS to your car's audio system.

4.5 Map Updates

The device includes free lifetime map updates for North America. To update your maps:

1. Connect the GPS unit to a computer using the provided USB cable.
2. Follow the instructions provided with the device or on the manufacturer's website for map update software.
3. Download and install the latest map data.




Image 4.6: The map update process, illustrating the connection between the GPS unit and a computer.

5. Features and Functions

- **7-inch Touch Screen Display:** Provides clear visuals and easy interaction.
- **Sunshade Design:** Helps reduce glare from sunlight for improved screen visibility.
- **Advanced GPS Functions:** Supports Postcode, Address, Coordinates, Favorite, and POI Search.
- **Safety Alert Features:** Includes speed camera reminders and red light warnings to promote safe driving.
- **GPS Time or Map Time Setting:** Allows synchronization with GPS satellites or manual time setting.



Image 5.1: The GPS unit with its sun visor design, effectively reducing sunlight glare on the screen.



Image 5.2: The speed limit warning feature, providing visual alerts to help maintain safe driving speeds.

6. Specifications

Feature	Detail
Brand	AWESAFE
Screen Size	7 Inches
Display Type	Touch Screen
Map Type	North America (USA, Canada, Mexico)
Mounting Type	Windshield Mount
Control Method	Touch, Voice
Supported Satellite Navigation System	GPS
Included Components	GPS Navigation, Car Charger, USB Cable, Suction Cup Mount, User Manual

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and device exterior. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Regularly check for map and software updates to ensure optimal performance and the most current navigation data.

8. Troubleshooting

8.1 Device Not Powering On

- Ensure the car charger is securely connected to both the GPS unit and the vehicle's cigarette lighter socket.
- Check if the vehicle's cigarette lighter socket is receiving power.
- Try pressing and holding the power button for 10-15 seconds to perform a hard reset.

8.2 GPS Signal Loss

- Ensure the device has a clear view of the sky, away from obstructions like tall buildings or dense foliage.
- Move the device to a different location on the dashboard or windshield.
- Restart the device.

8.3 Inaccurate Navigation

- Verify that the maps are up to date. Refer to Section 4.5 for map update instructions.
- Ensure the correct destination address or coordinates have been entered.
- Check the GPS signal strength.

9. Warranty and Support

Warranty information for your AWESAFE GPS Navigation System is typically provided with your purchase documentation. For specific warranty details, technical support, or service inquiries, please refer to the warranty card included in your

package or visit the official AWESAFE website.

Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GKGH1611

More documents and user manuals: **https://manuals.plus/**