



[Manuals.plus](#) /

> [coldSky](#) /

> coldSky Hand Warmers Rechargeable 2 Pack Instruction Manual

## **coldSky YL-108**

# **coldSky Hand Warmers Rechargeable 2 Pack Instruction Manual**

Model: YL-108 | Brand: coldSky

## **INTRODUCTION**

---

Thank you for choosing coldSky Rechargeable Hand Warmers. This manual provides essential information for the safe and efficient use of your new device. Please read it thoroughly before operation and retain it for future reference.



Image: Two coldSky hand warmers, one being handed to another person, demonstrating the magnetic design and sharing feature in a snowy outdoor setting.

## PRODUCT FEATURES

- **2-in-1 Magnetic Design:** The hand warmers feature a strong magnetic connection, allowing them to be used as a single double-sided unit or separated into two individual hand warmers. This design facilitates sharing warmth with others.



## 2 in 1 Magnetic Design

Strong magnetic connects 2 hand warmers in 1

Image: Close-up of two coldSky hand warmers magnetically connected, highlighting the 2-in-1 design.

- **Digital Display & 3 Heating Levels:** Each hand warmer is equipped with an LED digital display that shows the current battery level and heating status. Choose from three distinct heating modes: 104°F (Level 1), 122°F (Level 2), and 140°F (Level 3).

## Digital Display & 3 Heating Levels

Display battery & heating status



🔥 Level 1: 104°F 🔥 Level 2: 122°F 🔥 Level 3: 140°F

Image: A pair of coldSky hand warmers held in hands, showing their digital displays with battery and temperature indicators, and illustrating the three heat levels.

- **Compact & Portable:** Each hand warmer measures approximately 3.3 x 1.7 x 0.69 inches and weighs only 0.14 lbs, making them easy to carry in pockets or gloves for various outdoor and indoor activities.



Image: A coldSky hand warmer being held in a hand and placed into a pocket, with dimensions overlaid, emphasizing its compact and portable size.

- **Long-Lasting & Fast Heating:** Each unit contains a 2000mAh battery, totaling 4000mAh for the pair. They heat up in just 3 seconds and can provide warmth for up to 8 hours on the lowest setting.

## PACKAGE CONTENTS

- 2 x coldSky Rechargeable Hand Warmers
- 1 x 2-in-1 Charging Cable
- 1 x User Manual

## SETUP

### Charging the Hand Warmers

Before first use, fully charge both hand warmers. Use the provided 2-in-1 charging cable to charge both units simultaneously. The digital display will show the battery percentage during charging.

Your browser does not support the video tag.

Video: Demonstrates the 2-in-1 magnetic hand warmer and its charging process using the included cable.

1. Connect the 2-in-1 charging cable to a USB power adapter (not included) or a computer USB port.
2. Attach each end of the 2-in-1 cable to the charging ports on the hand warmers.
3. The digital display on each unit will illuminate, showing the current battery charge percentage.
4. Once fully charged (display shows 100%), disconnect the hand warmers from the charging cable.

## OPERATING INSTRUCTIONS

---

### Power On/Off

- To turn on: Press and hold the power button for 3 seconds. The digital display will light up, and the unit will begin heating.
- To turn off: Press and hold the power button for 3 seconds. The digital display will turn off, indicating the unit is powered down.

### Adjusting Heat Levels

Once powered on, tap the power button to cycle through the three heating levels:

- **Level 1 (Cozy):** 104°F (indicated by one light on the display).
- **Level 2 (Warm):** 122°F (indicated by two lights on the display).
- **Level 3 (Hot):** 140°F (indicated by three lights on the display).

The digital display will show the current temperature and the active heating level.

---



Image: Two individuals using coldSky hand warmers outdoors in a snowy environment, demonstrating practical use.

## MAINTENANCE

---

- **Cleaning:** Wipe the surface of the hand warmers with a soft, dry cloth. Do not use abrasive cleaners or immerse the units in water.
- **Storage:** Store the hand warmers in a cool, dry place when not in use. Ensure they are fully charged before long-term storage to preserve battery life.
- **Battery Care:** To maximize battery lifespan, avoid completely draining the battery frequently. Recharge when the battery indicator is low.

## TROUBLESHOOTING

---

- **Unit not turning on:** Ensure the battery is charged. Connect to the charger and check the digital display.
- **Not heating sufficiently:** Check the selected heat level on the digital display. Cycle through the levels to ensure the desired setting is active. Allow a few seconds for the unit to reach temperature.
- **Charging issues:** Verify that the charging cable is securely connected to both the hand warmer and the power source. Try a different USB port or power adapter.

- **Magnetic connection weak:** Ensure both surfaces are clean and free from debris. The magnets are designed for secure connection but can be affected by foreign objects.

## SPECIFICATIONS

Feature	Detail
Brand	coldSky
Model Name	YL-108
Color	Black
Material	Acrylonitrile Butadiene Styrene
Recommended Uses	Camping, Fishing, Hunting
Battery Type	Lithium-Polymer or Lithium-Ion
Battery Capacity	4000 Milliamp Hours (2 x 2000mAh)
Lower Temperature Rating	40 Degrees Celsius (104°F)
Upper Temperature Rating	140 Degrees Fahrenheit
Reusability	Rechargeable
Power Source	Battery Powered
Item Package Dimensions	6.26 x 4.13 x 0.94 inches
Package Weight	0.02 Kilograms

## WARRANTY AND SUPPORT

coldSky offers a **1-year warranty** on this product. For any questions, concerns, or support needs, please contact coldSky customer service. We are committed to ensuring your satisfactory purchase.

For further assistance, please visit the [coldSky Store on Amazon](#).