

AGXOV P40

AGXOV P40 HiFi MP3 Player Instruction Manual

Model: P40  
Brand: AGXOV

1. INTRODUCTION AND OVERVIEW

The AGXOV P40 is a high-fidelity portable music player designed for an immersive audio experience. It supports a wide range of audio formats, offers robust Bluetooth connectivity, and features a user-friendly touchscreen interface with a durable zinc alloy chassis.

- **Extensive Format Support:** Compatible with MP3, AAC, FLAC, APE, WAV, PCM, WMA, OGG, ALAC, AIFF, DSF, and DFF, including native DSD256 (11.2MHz) playback.
- **Bluetooth 5.3 Connectivity:** Provides a stable, energy-efficient wireless connection for Bluetooth headphones, speakers, and car stereos (A2DP profile). Note: Functions as a Bluetooth transmitter only.
- **High-Fidelity Lossless Audio:** Utilizes advanced DSD decoding technology and an integrated ES9018K2M DAC for up to 24-bit/192kHz playback with a 127dB signal-to-noise ratio and minimal distortion.
- **Versatile Output Options:** Features both a 3.5mm headphone jack and a line-out port for connection to various external audio equipment.
- **User-Friendly Design:** Equipped with a 2.8-inch HD touchscreen (240x320 resolution) and a retro-style mechanical knob for precise volume adjustment.
- **Long Battery Life & Expandable Storage:** A 2000mAh battery offers up to 50 hours of continuous high-resolution audio playback. Includes a 64GB microSD card and supports expansion up to 256GB.



*Image: The AGXOV P40 HiFi MP3 Player, showcasing its compact design and screen.*

## 2. SETUP

### 2.1. What's in the Box

- MP3 player x1
- 64GB microSD card x1
- Protective Leather Case (Black) x1
- USB-C Charging Data Cable x1
- User Manual x1
- Gift Packaging Box x1

## What's in the Box?

- 1x P40 HiFi Music Player
- 1x 64GB SD Card
- 1x Protective Leather Case (Black)
- 1x USB-C Charging Data Cable
- 1x User Manual
- 1x Gift Packaging Box



Image: All items included in the AGXOV P40 product packaging.

### 2.2. Charging the Device

1. Connect the provided USB-C charging cable to the player's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The battery indicator on the screen will show charging status. A full charge provides up to 50 hours of playback.

### 2.3. Installing the MicroSD Card

1. Locate the microSD card slot on the side of the player.
2. Gently insert the provided 64GB microSD card into the slot until it clicks into place. The player supports up to 256GB.

## Massive Storage, Endless Music

64GB Card Included. Expandable up to 256GB. Store over 4,000 lossless songs right out of the box.




Image: The AGXOV P40 highlighting its massive storage capacity and microSD card slot.

### 2.4. Initial Power On

1. Press and hold the Power button (usually on the side) for a few seconds until the screen lights up.
2. Follow any on-screen prompts for initial setup, such as language selection.

## 3. OPERATING INSTRUCTIONS

### 3.1. Basic Navigation

- **Touchscreen:** Use your finger to tap icons, swipe through menus, and select options on the 2.8-inch HD touchscreen.
- **Mechanical Knob:** Rotate the retro-style mechanical knob for precise volume adjustment.
- **Physical Buttons:** Utilize the dedicated buttons for playback control (play/pause, skip tracks) and menu navigation.



Image: The 2.8-inch full-color touchscreen of the AGXOV P40, showing its intuitive interface.



Image: Close-up of the precision volume wheel on the AGXOV P40.

### 3.2. Music Playback

1. From the main menu, select the 'Music' icon.
2. Browse your music library by artist, album, genre, or all songs.
3. Tap on a song to begin playback.
4. Use the on-screen controls or physical buttons to play/pause, skip tracks, or adjust volume.

### 3.3. Bluetooth Pairing

1. Ensure your Bluetooth headphones or speaker are in pairing mode.
2. On the P40, navigate to 'Settings' and then 'Bluetooth'.

3. Turn Bluetooth ON and select 'Search Device' or 'Scan'.
4. Select your device from the list of available devices to pair.



Image: The AGXOV P40 demonstrating both wired and Bluetooth 5.3 wireless connectivity options.

### 3.4. File Transfer

1. Connect the P40 to your computer using the provided USB-C cable.
2. The device will appear as a removable storage device on your computer.
3. Drag and drop your desired audio files into the appropriate folders on the player's internal storage or microSD card.
4. Safely eject the device from your computer before disconnecting the cable.

## 4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly and store it in a cool, dry place when not in use for extended periods.
- **Storage:** Keep the device away from extreme temperatures, direct sunlight, and moisture.

## 5. TROUBLESHOOTING

- **Device won't turn on:** Ensure the battery is charged. Connect to a power source and try again.
- **No sound:** Check volume levels on both the player and connected headphones/speakers. Ensure headphones are properly connected or Bluetooth is paired correctly.
- **Bluetooth not connecting:** Ensure both devices are in pairing mode and within range. Try restarting both devices.
- **Files not transferring:** Ensure the USB cable is securely connected and the device is recognized by your computer. Try a different USB port or cable.
- **Device unresponsive:** Press and hold the power button for 10-15 seconds to force a restart.

## 6. SPECIFICATIONS

| Feature                 | Detail                                                                        |
|-------------------------|-------------------------------------------------------------------------------|
| Brand                   | AGXOV                                                                         |
| Model Name              | P40                                                                           |
| Special Feature         | Touch Screen                                                                  |
| Connectivity Technology | USB, Bluetooth 5.3                                                            |
| Memory Storage Capacity | 64 GB (Expandable up to 256GB via Micro SD)                                   |
| Screen Size             | 2.8 Inches                                                                    |
| Compatible Devices      | Personal Computer, Bluetooth Headphones/Speakers                              |
| Media Type              | Micro SD                                                                      |
| Supported Standards     | MP3, AAC, WAV, FLAC, OGG, APE, PCM, WMA, ALAC, AIFF, DSF, DFF (Native DSD256) |
| Battery Average Life    | 50 Hours                                                                      |
| Item Weight             | 0.2 Kilograms                                                                 |
| Manufacturer            | AGXOV                                                                         |
| UPC                     | 788195744755                                                                  |



Image: The AGXOV P40's professional ATJ2167 audio core, highlighting its lossless decoding capabilities.

## 7. WARRANTY AND SUPPORT

The AGXOV P40 HiFi MP3 Player comes with a standard manufacturer's warranty. For warranty claims, technical support, or any inquiries, please refer to the contact information provided on the product packaging or the official AGXOV website.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**<https://manuals.plus/asin/B0GKNS48WK>**

More documents and user manuals: **<https://manuals.plus/>**