

Relaxdays 10052275_746

Relaxdays Foldable Football Table Instruction Manual

Model: 10052275_746

1. INTRODUCTION

Thank you for choosing the Relaxdays Foldable Football Table. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new football table. Please read these instructions carefully before assembly and use, and retain them for future reference.

This football table is designed for recreational play, offering entertainment for both children and adults. Its foldable design allows for convenient storage when not in use.

2. SAFETY INFORMATION

- **Warning:** Not suitable for children under 36 months due to small parts that can be swallowed, posing a choking hazard.
- Adult supervision is recommended for young children during play.
- Ensure all screws and fasteners are securely tightened before and during use to prevent instability.
- Do not climb on or stand on the table.
- Keep hands and fingers clear of moving rods during play to avoid injury.
- Place the table on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Please check the package contents against the list below. If any parts are missing or damaged, please contact customer support.

- 1 x Football table (in individual parts)
- 3 x Balls
- Mounting material (screws, tools, etc.)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow the included assembly instructions carefully. It is recommended to have two adults for assembly.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the parts list provided in the separate assembly guide.
3. Assemble the main table frame according to the diagrams. Ensure all connections are firm.
4. Attach the playing surface and side panels.
5. Insert the player rods, ensuring the players are oriented correctly (classic 1-2-5-3 setup).
6. Attach the non-slip handles to the player rods.
7. Install the manual goal counters on each side of the table.
8. Once assembled, ensure the table is stable and all fasteners are tightened.



Figure 1: Product dimensions for setup. The table measures approximately 78 cm (height) x 122 cm (width) x 61 cm (depth).

5. OPERATING INSTRUCTIONS

5.1 Playing the Game

- Place a ball into one of the side ball throws.
- Each player controls their set of rods to move the football figures and strike the ball.
- The objective is to score goals in the opponent's net.



Figure 2: Close-up of the football figures and rods, illustrating the player setup.

5.2 Goal Counters

- The table is equipped with manual goal counters on each side.
- After a goal is scored, manually adjust the counter to record the point.
- The counters track points from 0 to 9.



Figure 3: Manual goal counter for tracking scores.

5.3 Folding for Storage

- To fold the table, ensure all balls are removed from the playing surface.
- Follow the specific folding mechanism instructions provided in the separate assembly guide.
- Once folded, the table can be stowed away to save space. The folded depth is approximately 19 cm.

6. MAINTENANCE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Rod Lubrication:** Periodically apply a small amount of silicone-based lubricant to the player rods where they pass through the table frame to ensure smooth movement.
- **Fastener Check:** Regularly check all screws and bolts for tightness. Re-tighten if necessary to maintain stability and safety.
- **Storage:** When not in use, especially for extended periods, store the folded table in a dry, cool place away

from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

- **Rods are stiff/difficult to move:** Apply silicone lubricant to the rods. Check for any obstructions or bent rods.
- **Table is wobbly:** Ensure all assembly screws are fully tightened. Verify the table is on a flat, level surface.
- **Missing parts after assembly:** Double-check the packaging. If parts are genuinely missing, contact customer support with your purchase details.

8. SPECIFICATIONS

- **Model Number:** 10052275_746
- **Product Dimensions (H x W x D):** Approximately 78 x 122 x 61 cm (30.71 x 48.03 x 24.02 inches)
- **Folded Depth:** Approximately 19 cm
- **Item Weight:** Approximately 13.2 kg (29.8 pounds)
- **Ball Diameter:** Approximately 3.2 cm
- **Material:** MDF, Plastic, Iron
- **Assembly Required:** Yes
- **Batteries Required:** No

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.