Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pamray WL20

Pamray WL20 47 Inch Reversible L-Shaped Gaming Desk

Instruction Manual

Introduction

Thank you for choosing the Pamray WL20 47 Inch Reversible L-Shaped Gaming Desk. This manual provides detailed instructions for assembly, usage, and maintenance to ensure you get the most out of your new desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Pamray 47 Inch L-Shaped Gaming Desk configured for a multi-monitor setup in a home office.

Safety Information

- This desk has a maximum weight capacity of**150 lbs (65 kg)**. Do not exceed this limit to prevent damage or injury.
- Always assemble the desk according to the included instructions for proper stability and safety.
- Keep small parts away from children during assembly to avoid choking hazards.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten if necessary.
- Avoid placing hot items directly on the desk surface without protection.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desk panels (Engineered Wood)
- Metal frame components
- X-shaped back braces
- Adjustable leg pads
- Storage bag
- Headphone hook
- Assembly hardware (screws, bolts, etc.)
- Assembly tools (e.g., Allen wrench)
- Instruction manual

Assembly Instructions

Assembly is designed to be straightforward. All necessary tools and clear instructions are included. For a visual guide, scan the Transparency QR Code on the packaging to access comprehensive installation videos.

Reversible & Space-Smart Design

This desk features a reversible L-shaped design, allowing it to be configured as a 47-inch corner desk (for both left and right corners) or an extended 63-inch straight desk. Choose the configuration that best suits your space and needs.



Image: Visual representation of the desk's reversible design, illustrating straight and L-shaped configurations.

Step-by-Step Assembly Overview:

1. **Unpack and Identify Parts:** Lay out all components and hardware. Refer to the parts list in the included manual to ensure everything is present.
2. **Assemble the Frame:** Connect the metal frame components using the provided screws. Ensure the X-shaped back braces are installed for stability.
3. **Attach Desk Panels:** Secure the engineered wood desk panels to the assembled metal frame.
4. **Install Accessories:** Attach the storage bag and headphone hook to your preferred side of the desk.
5. **Adjust Leg Pads:** Level the desk by adjusting the leg pads to compensate for uneven flooring.

6. **Final Check:** Ensure all connections are tight and the desk is stable before placing items on it.



Image: Detailed dimensions of the desk in both L-shaped and straight configurations.

Usage and Features

Ample Desktop Space

The 47-inch desk provides approximately 6.89 square feet of functional workspace, comfortably accommodating a dual-monitor setup, laptop, keyboard, and other essential accessories. It is suitable for home office, gaming, or study use.

Integrated Storage

The desk includes a convenient side storage bag, ideal for books, documents, or other office supplies. A headphone hook is also provided to keep your headphones easily accessible and your workspace tidy.



Image: Close-up view of the side storage bag, demonstrating its capacity for books and documents.



Image: The Pamray 47 Inch L-Shaped Gaming Desk, highlighting the headphone hook and storage bag.

Sturdy Structure

The desk's stability is enhanced by two reinforced X-shaped back braces and a heavy-duty steel frame, providing long-lasting durability. Adjustable leg pads allow for leveling on uneven surfaces, ensuring a stable workspace.

Maintenance

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the powder-coated finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the engineered wood surface.

- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Overloading:** Do not exceed the stated weight capacity of 150 lbs (65 kg).

Troubleshooting

Desk is Wobbly:

- Ensure all assembly screws and bolts are fully tightened.
- Adjust the leg pads on the bottom of the desk legs to compensate for uneven flooring.

Missing Parts:

- Carefully check all packaging materials. Small parts can sometimes be overlooked.
- If parts are genuinely missing, contact Pamray customer support with your purchase details.

Difficulty with Assembly:

- Review the step-by-step instructions provided in the manual.
- Watch the installation videos by scanning the QR code on the packaging for visual guidance.

Specifications

Feature	Detail
Brand	Pamray
Model Number	WL20brown47
Model Name	WL20
Product Dimensions (D x W x H)	15.75"D x 47"W x 29.21"H
Color	Brown
Shape	Rectangular (Reversible L-shaped)
Desk Design	Computer Desk
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	Reversible
Item Weight	10.2 kg
Maximum Weight Recommendation	150 lbs (65 kg)
Included Components	Headphone Hook, Storage Bag

Customer Support

For any questions, missing parts, or assistance with assembly, please contact Pamray customer support. Refer to your purchase documentation for specific contact information or visit the official Pamray website.
We are committed to providing excellent service and ensuring your satisfaction with our products.

© 2023 Pamray. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GKS7V1MB

More documents and user manuals: **https://manuals.plus/**