Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pamray WL20

Pamray WL20 47-Inch Reversible L-Shaped Gaming Desk User Manual

1. Introduction

Thank you for choosing the Pamray WL20 47-Inch Reversible L-Shaped Gaming Desk. This desk is designed to provide a versatile and efficient workspace for gaming, studying, or home office use. Its reversible design allows for configuration as an L-shaped corner desk or a straight desk, adapting to various room layouts. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your desk.

Image 1.1: The Pamray WL20 L-Shaped Desk configured for a dual workspace.

2. Safety Information

Please read and follow these safety guidelines to prevent injury and damage to your desk:

- **Assembly:** Assemble the desk on a soft, clean surface (e.g., carpet) to prevent scratches. Ensure all screws are tightened securely before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 150 lbs (65 kg) for the desktop. Distribute weight evenly.
- **Stability:** Ensure the desk is placed on a level surface. Use the adjustable leg pads to compensate for uneven flooring.
- **Liquids:** Keep liquids away from the desk surface to prevent damage to electronic devices and the desk material.
- **Children:** Keep small parts away from children during assembly. Do not allow children to climb or play on the desk.
- **Moving:** When moving the desk, lift it rather than dragging it to prevent damage to the legs and floor.

3. Package Contents

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
A	Main Desktop Panel	1
B	Side Desktop Panel	1

Item	Description	Quantity
C	Corner Connector Panel	1
D	Leg Frames (various types)	Set
E	Crossbars / Support Beams	Set
F	X-shaped Back Braces	2
G	Adjustable Leg Pads	Set
H	Storage Bag	1
I	Headphone Hook	1
J	Hardware Pack (Screws, Bolts, Washers)	1
K	Assembly Tools (Allen Wrench, Screwdriver)	1 Set

4. Setup and Assembly Instructions

Follow these steps carefully to assemble your Pamray WL20 desk. It is recommended to have two people for easier assembly.

1. **Prepare the Workspace:** Clear an open area and lay down a blanket or cardboard to protect the desk components and your floor during assembly.
2. **Assemble the Leg Frames:** Attach the crossbars (E) to the leg frames (D) using the provided hardware (J). Ensure all connections are finger-tight at this stage.
3. **Attach X-shaped Back Braces:** Secure the X-shaped back braces (F) to the rear leg frames using the designated screws. These braces enhance the desk's stability.
4. **Attach Adjustable Leg Pads:** Screw the adjustable leg pads (G) into the bottom of each leg frame. These will help level the desk on uneven surfaces.
5. **Configure Desk Shape:** Decide whether you want to assemble the desk in an L-shape (left or right orientation) or as a straight desk. The panels are designed to be reversible.

Image 4.1: Desk configuration options.

6. **Attach Desktop Panels:** Carefully place the main desktop panel (A), side desktop panel (B), and corner connector panel (C) onto the assembled leg frames. Align the pre-drilled holes with the holes on the frame. Secure them using the appropriate screws from the hardware pack (J). **Do not overtighten.**
7. **Install Storage Bag and Headphone Hook:** Attach the storage bag (H) to the side of the desk frame using its integrated hooks or fasteners. Mount the headphone hook (I) to the desired location on the desk frame.
8. **Final Tightening:** Once all components are in place and aligned, go back and securely tighten all screws and bolts using the provided tools (K). Ensure the desk is stable and level.

5. Operating Instructions

5.1 Reversible Configuration

The Pamray WL20 desk is designed for flexibility. You can configure it as a left-sided L-shape, a right-sided L-shape, or a straight desk. This flexibility is achieved during the assembly process by orienting the desktop panels and leg frames as desired. If you wish to change the configuration after initial assembly, you will need to partially disassemble the desktop panels and reassemble them in the new desired orientation.

5.2 Using the Storage Bag

The included storage bag provides convenient access to books, documents, or other small items, helping to keep your desktop clutter-free. Simply place items into the bag. Ensure the weight inside the bag does not exceed 10 lbs.

Image 5.1: Integrated storage bag.

5.3 Using the Headphone Hook

The headphone hook allows you to hang your headphones or headset, keeping them within easy reach and off the desktop. This helps to maintain an organized and efficient workspace.

Image 5.2: Pamray WL20 desk in straight configuration.

6. Maintenance and Care

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or furniture polish, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood surface.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Heat:** Do not place hot items directly on the desk surface. Use coasters or protective pads.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.

7. Troubleshooting

Problem	Possible Cause	Solution
Desk is wobbly	Uneven floor; loose screws; incorrect assembly of X-braces.	Adjust leg pads to level the desk. Tighten all screws. Ensure X-braces are correctly installed and tightened.
Parts do not align	Incorrect orientation of parts; screws overtightened too early.	Loosen all screws, re-align parts, then tighten gradually. Refer to assembly diagrams. Ensure parts are not forced.
Storage bag does not fit	Incorrect attachment point; bag orientation.	Ensure the bag is attached to the designated frame section and oriented correctly.

8. Specifications

Feature	Detail
Model Name	WL20
Product Dimensions (L-shape)	47"W x 47"D x 29.21"H (approximate, based on configuration)
Product Dimensions (Straight)	63"W x 15.75"D x 29.21"H (approximate, based on configuration)

Feature	Detail
Desktop Material	Engineered Wood
Frame Material	Metal
Weight Capacity (Desktop)	150 lbs (65 kg)
Weight Capacity (Storage Bag)	10 lbs
Net Weight	10.2 kg (22.5 lbs)
Special Features	Reversible L-shape, Storage Bag, Headphone Hook, Adjustable Leg Pads

Image 8.1: Detailed dimensions of the Pamray WL20 desk.

9. Warranty and Support

Pamray is committed to providing high-quality products. For any warranty claims, missing parts, or technical support, please contact the retailer from whom you purchased this product or visit the official Pamray store page on Amazon for further assistance. Please have your purchase receipt and model information (WL20) ready when contacting support.

Pamray Store: Visit the Pamray Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GKSC59JV

More documents and user manuals: **https://manuals.plus/**