

Ausic P36

Ausic 12-inch 20L Portable Misting Fan

Model: P36

- [Introduction](#)   [Components](#)   [Setup](#)   [Operation](#)   [Maintenance & Support](#)   [Troubleshooting](#)   [Specifications](#)   [Safety](#)   [Warranty](#)

1. INTRODUCTION

Thank you for choosing the Ausic 12-inch 20L Portable Misting Fan. This manual provides essential information for the safe and efficient use of your new misting fan. Please read these instructions carefully before operation and retain for future reference.

This portable misting fan is designed to provide effective cooling for both indoor and outdoor environments, featuring a powerful fan, customizable misting functions, a large capacity battery, and convenient portability with a telescopic handle and rolling wheels.

2. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main components of your Ausic Misting Fan:

- **12-inch Fan Head:** Provides powerful airflow.
- **Misting Nozzles:** Integrated for water mist dispersion.
- **Control Panel:** Located on the fan base for manual operation.
- **Remote Control:** For convenient adjustment of settings.
- **20L Water Bucket:** Serves as the water reservoir and a portable base with storage.
- **Telescopic Handle:** For easy pulling and transport.
- **Rolling Wheels:** Facilitate movement of the unit.
- **LED Light:** Integrated lighting with dual brightness modes.
- **Charging Port:** For recharging the internal battery.



Figure 2.1: The Ausic Misting Fan in use, demonstrating continuous and intermittent misting functions.

### 3. SETUP INSTRUCTIONS

#### 3.1 Unpacking

Carefully remove all components from the packaging. Inspect for any damage. Keep packaging materials for storage or return if necessary.

#### 3.2 Initial Charging

Before first use, fully charge the fan's built-in 30000mAh battery. Use the provided USB charging cable (approx. 12 hours for full charge) or a fast-charging adapter (approx. 6 hours for full charge).

# 30000mAh Large Battery

Power Through the Day, Cool Down in a Breeze.

**Low Fan:**  
 $60 \pm 3$  H

**High Fan:**  
 $10 \pm 1$  H

**High Fan+Mist:**  
 $6.5 \pm 0.5$  H

**Two charging methods:**

**Adapter:**  $6 \pm 0.5$  H

**USB:**  $12 \pm 0.5$  H

Figure 3.1: The fan features a 30000mAh battery with two charging options for convenience.

### 3.3 Filling the Water Tank

The 20L bucket serves as the water tank. Open the lid of the bucket and fill it with clean water. Ensure the water level does not exceed the maximum fill line. Close the lid securely after filling.

### 3.4 Assembly and Portability

The fan head securely attaches to the 20L water bucket. The unit is equipped with rolling wheels and a telescopic handle for easy transport. Extend the telescopic handle when moving the fan, similar to a suitcase.

# More Features



- Remote Control

- 1H/2H/4H/8H Timer

- 100° Rotation

- 90° Auto Oscillation





Figure 3.2: The fan's telescopic handle and rolling wheels allow for easy movement.



Figure 3.3: The fan's design allows for convenient storage and transport in vehicles.

## 4. OPERATING INSTRUCTIONS

The fan can be operated using the control panel on the unit or the included remote control.

### 4.1 Power On/Off

Press the power button on the control panel or remote to turn the fan on or off.

### 4.2 Fan Speed Adjustment

Cycle through the 4 available fan speeds (Low, Mid, M.High, High) by pressing the speed button. The speeds deliver airflow from 8.2 ft/s to 18.7 ft/s.

# 12-inch Powerful Fan

## Brushless Motor:

Higher  
**30%**  
torque

Lower  
**30%**  
noise

## 4 Gear Wind Speed:

 **Low 8.2 $\pm$ 0.6 ft/s**

 **Mid 12.2 $\pm$ 0.6 ft/s**

 **M.High 15.8 $\pm$ 0.6 ft/s**

 **High 18.8 $\pm$ 0.6 ft/s**



Figure 4.1: The fan features a brushless motor for quiet operation and 4 adjustable wind speeds.

## 4.3 Misting Modes

Select from three misting modes:

- **Continuous Mist:** Provides a steady stream of mist.
- **Intermittent Mist (1s/1.5s):** Mists for 1 second, pauses for 1.5 seconds.
- **Intermittent Mist (0.5s/1s):** Mists for 0.5 seconds, pauses for 1 second.

The maximum mist output is approximately 2 liters per hour. A full 9-liter tank can provide 8-10 hours of continuous misting.

## 4.4 Oscillation and Tilt

The fan offers 90° wide horizontal oscillation and 100° vertical tilt for comprehensive airflow coverage. Use the oscillation button on the control panel or remote to activate or deactivate oscillation.

# LONG-DISTANCE, WIDE - RANGE COOLING FAN

Take the heat out of your workout




Figure 4.2: The fan provides long-distance, wide-range cooling with adjustable oscillation.

## 4.5 Timer Function

Set the fan to operate for a specific duration using the timer function. Available settings are 1, 2, 4, or 8 hours.

## 4.6 LED Light

Activate the integrated LED light for illumination. Choose between two brightness modes (soft glow or bright beam) by pressing the light button.

## 4.7 Remote Control

The remote control allows for convenient adjustment of power, fan speed, mist mode, timer, LED light, and oscillation from a distance.

## 5. MAINTENANCE

### 5.1 Cleaning the Fan Blades

Ensure the fan is turned off and unplugged before cleaning. Use a soft, damp cloth to wipe dust from the fan blades and grille. Do not use abrasive cleaners or immerse the fan in water.

## 5.2 Cleaning the Water Tank and Misting Nozzles

Regularly empty and clean the 20L water bucket to prevent mineral buildup and bacterial growth. Use a mild detergent and rinse thoroughly. For misting nozzles, use a soft brush or cotton swab to gently clear any blockages.

## 5.3 Storage

When not in use for extended periods, ensure the fan is clean, dry, and fully charged. Store it in a cool, dry place away from direct sunlight and extreme temperatures. The bucket design allows for compact storage.

## 6. TROUBLESHOOTING

- Fan does not turn on:**  
Check if the battery is charged. Connect the fan to a power source and allow it to charge. Ensure the power button is pressed firmly.
- No mist is produced:**  
Check if the water tank is filled. Ensure the misting nozzles are not clogged. Clean the nozzles if necessary. Verify that the misting function is activated.
- Weak airflow:**  
Increase the fan speed setting. Ensure the fan grille is not obstructed by dust or debris.
- Remote control not working:**  
Check the remote control battery. Ensure there are no obstructions between the remote and the fan's receiver. Note that some external signals, such as from a TV remote, may inadvertently activate or interfere with the fan's functions.
- Unusual noise:**  
Turn off the fan and inspect for any foreign objects obstructing the fan blades. If the noise persists, contact customer support.

## 7. SPECIFICATIONS

|                     |                                                            |
|---------------------|------------------------------------------------------------|
| Brand               | Ausic                                                      |
| Model Name          | P36                                                        |
| Model Number        | P36                                                        |
| Power Source        | Battery Powered                                            |
| Battery Capacity    | 30000mAh                                                   |
| Water Tank Capacity | 20 Liters                                                  |
| Fan Speeds          | 4 (8.2 ft/s; 12.2 ft/s; 15.6 ft/s; 18.7 ft/s)              |
| Misting Modes       | Continuous, Intermittent (1s/1.5s), Intermittent (0.5s/1s) |
| Oscillation         | 90° Horizontal                                             |
| Vertical Tilt       | 100°                                                       |
| Timer Settings      | 1H, 2H, 4H, 8H                                             |
| LED Light           | Dual Brightness Modes                                      |
| Noise Level         | 45 Decibels                                                |
| Product Dimensions  | 8.5"D x 17.7"W x 17.3"H                                    |
| Material            | Plastic                                                    |
| Control Method      | Button Control, Remote Control                             |

## 8. SAFETY INFORMATION

- Always place the fan on a stable, level surface to prevent tipping.
- Do not insert fingers or other objects through the fan grille when the fan is operating.
- Keep the fan away from open flames, heat sources, and flammable materials.
- Do not use the fan in areas with excessive humidity or where it may come into contact with standing water, other than the designated water tank.
- Ensure the charging port is dry before connecting the charging cable.
- Only use the provided charging cable and adapter, or compatible replacements, for charging.
- Keep out of reach of children and pets.
- Do not attempt to disassemble or repair the fan yourself. Contact qualified service personnel for repairs.
- Empty the water tank when moving the fan over uneven terrain to prevent spills.

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. If you encounter any issues or require technical assistance, please contact Ausic customer support through the retailer's platform or the official Ausic website. Please have your model number (P36) and purchase details ready when contacting support.

© 2026 Ausic. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GKV17RKZ>

More documents and user manuals: <https://manuals.plus/>