

JOC H799BT

JOC Quranic Radio H799BT User Manual

Model: H799BT | Brand: JOC

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your JOC Quranic Radio H799BT. This device is a portable digital player pre-loaded with an extensive library of Islamic audio content, including Quranic recitations, interpretations, lessons, sermons, supplications, and educational materials for children. Please read these instructions carefully before operating the device and retain them for future reference.

2. SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Avoid extreme temperatures, direct sunlight, or dusty environments.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from strong magnetic fields.
- Use only the provided charging cable and a compatible power adapter.
- Keep out of reach of small children to prevent choking hazards from small parts.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- JOC Quranic Radio H799BT (Red)
- USB Charging Cable
- Rechargeable Battery
- User Manual / Code Guide (Printed)
- 32GB Memory Card (pre-loaded with content)

الفهرس الخاص بالمصحف المعلم الناطق

نسأل الله أن ينفع بع ويتقبله منا ويجزي كل من ساهم في هذا العمل خير الجزاء

القرآن مقسم صفحات بصوت	صفحة	ركن التفسير	صفحة	ركن التعليم والشرح والفقه	صفحة
المنشاوي	٢	تفسير السعدي (القرآن كاملاً)	٢٣	كيف تتعلم القرآن	٣٧
محمد جبريل		تفسير العدوي (بعض السور)	٢٤	كتائب الموازين	٣٦
فارس عباد	١٦، ١٧، ١٨، ١٩، ٢٠، ٢١	تفسير القرآن للأطفال (بعض السور)	٢٤	حروف ومعاني	٤٣
إبراهيم الأخضر		تفسير قصار السور (محمود الخضيري)	٣١	فضل القرآن	٤٣
السديس		برنامج قرآن تفسر السنة	٢٤	فضائل آية الكرسي	٤٣
القرآن مقسم الى سور بصوت القارئ		ركن الأطفال		شرح التجويد (أيمن سويدان)	٣٤
الطبلأوي	٣، ٤، ٥	قصص الأنبياء للأطفال	٢٤	المصحف الجامع بأحكام التلاوة	٣٤
الحصري المعلم	٣، ٤، ٥	تحفة للأطفال	٣١	برنامج دقيقة فقهية	٣٥
رواية ورش الحصري	٣، ٤، ٥	كيف نربي أبنائنا	٤٣	سلسلة تعليم القرآن	٣٧
سعد الغامدي	٣، ٤، ٥	مهارات في تربية الأطفال	٤١	فتاوى الشيخ حسن عبدالغفار	٣٩
احمد نعينع	٣، ٤، ٥	قاعدة نور البيان	٤١	فواصل طبية متنوعة (مفيد جدا)	٤٠
مصطفى إسماعيل	٣، ٤، ٥	كيف نتعلم القرآن	٤١	سلسلة فن تدبير القرآن	٤٢
بندر بليلة	٣، ٤، ٥	احكام التجويد	٤٣	الطول الشرعية للمشكلات	٤٣
محمد أيوب	٣، ٤، ٥	احكام التلاوة	٢٤	شرح متن الجزارية	٤٣
المنشاوي	٦، ٧، ٨	قصة الحج	٤٣	فتاوى ابن عثيمين	٣٠
العجمي	٦، ٧، ٨	أناشيد قصص الأنبياء	٢٤	قصة الحروب الصليبية	٢٧
مشاري راشد	٦، ٧، ٨	سلسلة اذكاري	٢٤	سلسلة التتار	٢٧
الشريم	٦، ٧، ٨	ركن السيرة والصحابة والقصص		تعليم احكام التلاوة	٢٥
الحذيفي	٦، ٧، ٨	قصص الأنبياء للعدوي (بعضها)	٢٢	حصن المسلم	٢٩، ٢٨
وديع اليمني	٦، ٧، ٨	قصص الأنبياء خالد سويدان	٢٦	كيف تكسب مليارات الحسنات	٤٣
ماهر المعقلي	٦، ٧، ٨	السيرة النبوية	٤١	منوعات	
محمود البنا	٦، ٧، ٨	سلسلة الصديق للسرجاني	٢٧	الرقية الشرعية	٣٣
ابوبكر الشاطري	٩، ١٠، ١١	سلسلة لمحات في السيرة	٤١	أسماء الله الحسني الشيخ عبدالرازق البدر	٣٦
خالد القحطاني	٩، ١٠، ١١	عبقريه سيدنا محمد	٢٢	انكار الصباح والمساء	٤١
ناصر القطامي	٩، ١٠، ١١	عبقريه الصديق	٢٢	طرق اغواء الشيطان	٤٣
محمد حسان	٩، ١٠، ١١	عبقريه خالد	٢٢	نظرات في سورة الانفال	٤٣
ماجد فاروق	٩، ١٠، ١١	عبقريه عثمان	٢٢	الحياه الزوجية السعيدة	٤٣
صلاح بو خاطر	٩، ١٠، ١١	عبقريه عمر	٢٢	أناشيد إسلامية متنوعة	٤٤
حاتم فريد	٩، ١٠، ١١	عبقريه الامام على	٢٢	قصص واقعية في دقائق معدودة	٤٤
عبدالله كامل	٩، ١٠، ١١	دروس دعوية			
ياسر الدوسري	٩، ١٠، ١١	مقاطع دعوية مدتها قصيرة	٣٨		
سامي الدوسري	١٢، ١٣	مقاطع دعوية متنوعة	٤٤		
السيد متولي	١٢، ١٣	مقاطع دعوية للجزارية	٤٤		
محمد البراك	١٢، ١٣	إبراهيم الدرويش	٣١		
محمود عمر ابو عبد الملك	١٢، ١٣	محمد بفته	٣١		
احمد النفيسي	١٢، ١٣	الحويني	٣١		
طارق عبد الحكيم	١٤	سلسلة فلنستعد لر مضان	٣١		
ابو العنين شعيشع	١٤	عبد المحسن الأحمد	٣٢		
عبد الفتاح شعشاعي	١٤	نروس الشيخ الشنقيطي	٣٣		
محمد رفعت	١٤	سلسلة موازين	٣٦		
شيرزاد طاهر	١٤	الشيخ عائض القرني	٣٦		
القرآن مقسم أجزاء بصوت القارئ		سلسلة العبادات (د/عامر بهجت)	٣٧		
عبدالباسط	١٥	مقاطع دعوية لشيخو متنوعة	٣٨		
الحصري	١٥	مقاطع دعوية للعرفي	٣٨		
التراويج	١٥	سلسلة خايف عليك	٤٣		
السديس	١٥	سلسلة اشرطة الساعة	٤٣		
الشريم	١٥	سلسلة الباعث الحثيث	٤٣		
المحسني	١٥	سلسلة عشاق الجنة	٤٣		
القرآن مقسم ارباع بصوت القارئ		سلسلة الطريق إلى الجنة	٤٣		
المنشاوي	٢٢	سلسلة السيرة النبوية	٤١		

Image 3.1: Contents of the JOC Quranic Radio H799BT package. This includes the red radio unit, a USB charging cable, a rechargeable battery, and a printed code guide/manual.

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your JOC Quranic Radio H799BT.

Front Panel



Image 4.1: Front view of the JOC Quranic Radio H799BT. Key features include the large speaker grille, a digital display, and a numeric keypad for content selection.

- **Speaker:** For audio output.
- **Digital Display:** Shows track numbers, radio frequency, and other information.
- **Numeric Keypad (0-9):** Used to enter codes for specific audio tracks or radio frequencies.
- **M (Mode) Button:** Switches between different modes (e.g., Quran player, FM radio).
- **Play/Pause Button:** Starts or pauses audio playback.
- **Previous/Next Track Buttons:** Navigates between audio tracks or radio stations.
- **Scan Button:** In FM mode, automatically scans and saves radio stations.

Side Panel



Image 4.2: Side view of the JOC Quranic Radio H799BT. Visible ports include the USB charging port, a microSD card slot, and an extendable antenna for FM radio reception.

- **Extendable Antenna:** For improved FM radio reception.
- **USB Port:** For charging the device.
- **MicroSD Card Slot:** To insert the pre-loaded memory card.
- **Headphone Jack:** For private listening.
- **Power Switch:** Turns the device ON/OFF.

5. SETUP

1. **Insert Battery:** Open the battery compartment cover on the back of the device. Insert the provided rechargeable battery, ensuring correct polarity (+/-). Close the cover securely.
2. **Insert Memory Card:** Locate the MicroSD card slot on the side of the device. Gently insert the pre-loaded 32GB memory card until it clicks into place.
3. **Charge Device:** Connect the USB charging cable to the device's USB port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will illuminate. Charge the device fully before first use (approximately 2-3 hours).
4. **Power On:** Slide the Power Switch to the 'ON' position. The digital display will light up.

6. OPERATING INSTRUCTIONS

Your JOC Quranic Radio H799BT is designed for easy navigation through its vast audio library. The device comes with a printed Code Guide (refer to Image 3.1) that lists specific codes for each audio track and section. Use this guide in conjunction with the numeric keypad to access content.

6.1 Navigating Audio Content

1. **Select Mode:** Press the **M (Mode)** button to switch to the audio playback mode (usually indicated by a track number on the display).
2. **Enter Code:** Refer to your printed Code Guide. Locate the desired content (e.g., a specific Surah, a reciter, a lesson). Each item has a unique code. Use the **Numeric Keypad (0-9)** to enter this code.

3. **Confirm Selection:** After entering the code, the device will typically start playing the corresponding audio automatically. If not, press the **Play/Pause** button.
4. **Adjust Volume:** Use the volume control knob (if present, or dedicated buttons) to adjust the audio level.
5. **Skip Tracks:** Use the **Previous/Next Track** buttons to move to the previous or next audio file within the current section.

6.2 Content Categories

The pre-loaded 32GB memory card contains over 10,000 audio clips organized into several main categories. Your printed Code Guide provides the exact codes for each sub-category and individual track.

- **Quran Recitations:** Features 47 different recitations by 41 prominent reciters. Content is organized by Surah, Juz (parts), Pages, and Quarters for easy access.
- **Children's Education Corner:** Includes engaging content such as Stories of the Prophets, simplified Tajweed rules, Noor Al-Bayan lessons, and educational Islamic songs.
- **Prophet's Biography and Companions:** Contains series like 'Abbasid Geniuses', stories of the Prophet's companions, and insights into the Prophet's life.
- **Da'wah (Call to Islam) Corner:** A collection of influential lectures and sermons from renowned scholars.
- **Interpretation and Fiqh (Jurisprudence):** Features complete Tafsir (Quranic interpretation) by scholars like Al-Saadi and Al-Khudairi, detailed Tajweed explanations, various Fatwas, and valuable scientific lessons.
- **Miscellaneous:** Includes daily supplications (Adhkar), 'Hisn Al-Muslim' (Fortress of the Muslim), legal Ruqyah, and various Islamic songs.

6.3 FM Radio Operation

1. **Switch to FM Mode:** Press the **M (Mode)** button until 'FM' or a radio frequency appears on the display.
2. **Extend Antenna:** Fully extend the telescopic antenna for optimal reception.
3. **Auto Scan:** Press the **Scan** button to automatically search for and save available FM radio stations.
4. **Manual Tuning:** Use the **Previous/Next Track** buttons to fine-tune the frequency or select saved stations. Alternatively, enter a specific frequency using the **Numeric Keypad**.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, even if not in active use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Battery is discharged or incorrectly inserted.	Charge the battery. Ensure the battery is inserted with correct polarity.
No sound.	Volume is too low or headphones are connected.	Increase the volume. Disconnect headphones if using the speaker.

Problem	Possible Cause	Solution
Cannot find desired audio content.	Incorrect code entered or memory card issue.	Verify the code with the printed Code Guide. Ensure the memory card is properly inserted.
Poor FM radio reception.	Antenna not extended or weak signal.	Fully extend the antenna. Try moving to a different location for better signal.

9. SPECIFICATIONS

- **Brand:** JOC
- **Model:** H799BT
- **Color:** Red
- **Special Features:** Divided Recitations, Children's Education Corner, Da'wah Corner, Interpretation Corner
- **Product Dimensions (L x W x H):**22 cm x 16 cm x 5 cm
- **Included Components:** Radio
- **Item Weight:** 425 grams
- **Compatible Devices:** Memory Card
- **Unit Count:** 1
- **Manufacturer:** Roxy Store
- **Country of Origin:** China

10. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. Please refer to the warranty information provided with your purchase for details on coverage and duration. For technical support, service, or warranty claims, please contact the retailer or manufacturer directly using the contact information provided on your purchase receipt or the product packaging. For additional resources or frequently asked questions, you may visit the manufacturer's official website if available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question