

[Manuals.plus](#) /

› [Lyromix](#) /

› Lyromix 10 x 15FT Large Outdoor Dog Kennel Instruction Manual

Lyromix Lyromix Outdoor Dog Kennel

Lyromix 10 x 15FT Large Outdoor Dog Kennel Instruction Manual

Model: Lyromix Outdoor Dog Kennel

1. INTRODUCTION

The Lyromix 10 x 15FT Large Outdoor Dog Kennel provides a sturdy and spacious enclosure for dogs, allowing them to play, rest, and enjoy fresh air while offering protection from sun and rain. This manual contains essential information for the correct assembly, safe operation, and proper maintenance of your dog kennel.

2. SAFETY INFORMATION

- Always ensure all components are securely fastened before allowing your pet into the kennel.
- Regularly inspect the kennel for any signs of wear, damage, or loose parts. Tighten or replace components as necessary.
- Ensure the kennel is placed on a level surface to prevent instability.
- Adult assembly is required. Keep children and pets away during the assembly process.
- Do not allow children to play unsupervised near or inside the kennel.
- This kennel is designed for dogs. Do not use it for other animals or purposes.
- Ensure proper ventilation, especially during hot weather.
- Anchor the kennel securely to the ground to prevent tipping or movement in strong winds.

3. PACKAGE CONTENTS

Please verify that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- Galvanized Steel Frame Tubes
- Chain Link Mesh Netting
- Waterproof UV-Resistant PE Roof Cover
- Metal Cable Ties / Fasteners
- Fixing Rods
- Adjustable Feeding Device (with bowls)
- Secure Lock Mechanism

4. SETUP AND INSTALLATION

It is recommended that two people carry out the assembly process for efficiency and safety. Ensure you have adequate space for assembly.

4.1. Prepare the Area

Choose a level, clear area for the kennel installation. The dimensions of the assembled kennel are approximately 177.6"L x 118.6"W x 51.5"H (without roof height).





Figure 1: Product Dimensions. Please ensure the net is pulled tight during installation.


4.2. Assemble the Frame

Connect the galvanized steel tubes to form the base and side frames. Ensure all connections are secure. The frame uses 1.2-inch diameter tubing with 1mm thickness for durability.


ours



Heavy-Duty Wire (1.2mm)
Built for strong dogs




Reinforced, Taut Mesh
Less wobble, more stability



304 Stainless Steel Fasteners
Weather-resistant and secure

Others



Lightweight Wire



Sagging Mesh



Plastic Fasteners

Figure 2: Frame and Mesh Quality. The kennel features heavy-duty 1.2mm wire, reinforced taut mesh, and 304 stainless steel fasteners for enhanced stability and weather resistance.

4.3. Install the Chain Link Mesh

1. Unroll the chain link mesh carefully.
2. Insert the provided fixing rods into the net along the vertical edges.
3. Attach the mesh to the vertical posts of the frame using the fixing rods and secure them with the provided clamps.
4. Secure the mesh to the horizontal frame tubes using the metal cable ties. It is crucial to pull the net as tight as possible and secure it at each knot to prevent sagging and ensure the dog cannot escape.
5. During installation, separate any overlapping or crossed portions of the netting. Failing to do so may result in insufficient length or an uneven fit.
6. Once the net is installed, if it is too long, fold back the excess and secure it in place with additional ties to resolve the issue.

Upgraded Heavy-Duty Chain-Link Mesh

Stronger & More Durable – Bite-Resistant and Built to Last



Figure 3: Upgraded Heavy-Duty Chain-Link Mesh. This mesh is designed to be stronger and more durable, effectively preventing dogs from bending the wire to escape.

4.4. Install the Roof Cover

Position the waterproof, UV-resistant PE cover over the top frame. Secure it firmly to the frame using the integrated grommets and ties. Ensure the cover is taut to prevent water accumulation and provide maximum shade.



Figure 4: Anti-UV & Waterproof Cover. The roof cover provides protection from sun and rain, ensuring a comfortable environment for your dog.

4.5. Install the Feeding Device and Lock

Attach the adjustable feeding device to the designated section of the kennel. Ensure it can be easily raised and lowered to accommodate different dog sizes. Install the secure lock mechanism on the main gate.



Three-level Adjustable Feeding Device

Meet the eating habits of dogs of different sizes

The Feeding Door Above Can Be Opened

Feeding no longer becomes troublesome

Figure 5: Three-level Adjustable Feeding Device. This feature allows for convenient feeding without entering the kennel and can be adjusted for dogs of various sizes.

5. OPERATING INSTRUCTIONS

5.1. Using the Adjustable Feeding Device

The kennel is equipped with a three-level adjustable feeding device. To use, simply slide the feeding door upwards to access the bowls. Adjust the height of the bowls by repositioning the support bars to suit your dog's height. Ensure the feeding door is securely closed after use.

5.2. Securing the Gate

The main gate features a secure lock. Always ensure the lock is properly engaged when your dog is inside the kennel to prevent accidental opening or escape.

6. MAINTENANCE

- **Regular Cleaning:** Clean the kennel regularly with mild soap and water. Rinse thoroughly and allow to dry completely to prevent rust and mildew.
- **Mesh Inspection:** Periodically check the chain link mesh for any damage, bends, or loose connections. Repair or replace damaged sections promptly to maintain security.
- **Fastener Check:** Ensure all metal cable ties and frame connections remain tight. Re-tighten any loose fasteners to maintain the kennel's structural integrity.
- **Roof Cover Care:** Clean the roof cover as needed. Inspect for tears or damage, especially after severe weather. Ensure it remains securely attached to provide optimal protection.
- **Ground Anchoring:** Verify that the kennel's base is still securely anchored to the ground, especially if placed in an area prone to strong winds.

7. TROUBLESHOOTING

- **Kennel feels unstable/flimsy:** Ensure all frame connections are fully inserted and tightened. Double-check that the chain link mesh is pulled taut and secured at every possible point with the metal cable ties. Proper tensioning of the mesh is critical for stability.
- **Mesh appears too short or tangled:** During installation, carefully separate any overlapping or crossed portions of the netting. If the net is still too long after installation, fold back the excess and secure it with additional ties.
- **Dog attempting to escape:** Verify that the mesh is tightly secured to the frame and that the gate lock is fully engaged. Consider adding additional anchors to the base if the dog is attempting to lift or move the kennel.
- **Water accumulation on roof:** Ensure the roof cover is installed tautly and that its slope allows for proper water runoff. Clear any debris from the roof regularly.

8. SPECIFICATIONS

Feature	Detail
Brand	Lyromix
Model Number	Lyromix Outdoor Dog Kennel
Product Dimensions (L x W x H)	177.6" x 118.56" x 51.48"
Material	Metal (Galvanized Steel)
Special Features	Lockable, Weather Resistant
Included Components	Bowl, Cover
Target Species	Dog
Breed Recommendation	Large
UPC	717018978459
Warranty	1 Year

9. WARRANTY AND SUPPORT

9.1. Warranty Information

This Lyromix dog kennel comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or natural disasters.

9.2. Customer Support

For any questions, concerns, or assistance with your Lyromix dog kennel, please refer to the contact information provided at the point of purchase or visit the official Lyromix website for support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GL2FR4Z5>

More documents and user manuals: <https://manuals.plus/>