

Tchibo B0GL2QKT2R

Tchibo USB Electric Lighter User Manual

Model: B0GL2QKT2R

1. INTRODUCTION

Thank you for choosing the Tchibo USB Electric Lighter. This modern and practical device is designed for convenience and environmental friendliness. Featuring a sleek silver-grey design and a compact size, it offers reliable performance for various lighting needs. This manual provides essential information for safe and efficient use, setup, operation, and maintenance of your electric lighter.

2. SAFETY INSTRUCTIONS

- Keep out of reach of children. This is not a toy.
- Do not expose the lighter to water, moisture, or other liquids.
- Avoid exposing the lighter to direct sunlight or temperatures above 50°C (122°F).
- Do not touch the electric arc. It can cause burns.
- Do not attempt to disassemble, repair, or modify the lighter. Contact customer service for assistance.
- Do not use the lighter near flammable materials or explosive atmospheres.
- Ensure the lighter is turned off when not in use and during charging.
- Use only the provided USB cable or a certified equivalent for charging.

3. PRODUCT OVERVIEW

The Tchibo USB Electric Lighter is a flameless, rechargeable device that uses an electric arc to ignite candles, stoves, and other items. Its compact design makes it easy to handle and store.



Image 1: Tchibo USB Electric Lighter in use, igniting a candle. The lighter features a sleek silver-grey finish and a long, slender body for easy reach.

4. SETUP: CHARGING THE LIGHTER

1. Locate the USB charging port on the lighter.

2. Connect the provided USB charging cable to the lighter's port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter, power bank).
4. The charging indicator light will illuminate during charging. Once fully charged, the light may change color or turn off, depending on the model.
5. A full charge typically takes approximately 1-2 hours. Do not overcharge the device.

The USB rechargeable feature makes this lighter an eco-friendly alternative to traditional gas lighters.

5. OPERATING INSTRUCTIONS

1. **Power On:** Slide the safety switch (if present) to the "ON" position or press the power button.
2. **Activate Arc:** Press and hold the ignition button. An electric arc will appear between the electrodes at the tip of the lighter.
3. **Ignite:** Carefully bring the electric arc into contact with the wick of a candle, gas burner, or other ignitable material.
4. **Power Off:** Release the ignition button to turn off the arc. If there is a safety switch, slide it back to the "OFF" position when finished.

The lighter is designed for ease of use and provides a reliable ignition source without flame.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the lighter. Do not use abrasive cleaners or solvents. Ensure the electrodes are free from debris for optimal performance.
- **Storage:** Store the lighter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the lighter frequently. Charge it when the indicator suggests low battery.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lighter does not turn on/arc does not activate.	Low battery. Safety switch is off. Electrodes are dirty.	Charge the lighter fully. Ensure the safety switch is in the "ON" position. Gently clean the electrodes with a dry cotton swab.
Lighter not charging.	Faulty USB cable or power source. Charging port is damaged.	Try a different USB cable or power source. Contact customer support if the port appears damaged.
Arc is weak or inconsistent.	Low battery. Electrodes are dirty or worn.	Recharge the lighter. Clean the electrodes. If the issue persists, contact customer support.

8. SPECIFICATIONS

Brand: Tchibo

Model: B0GL2QKT2R

Color: Grey (Silver-Grey)

Dimensions (L x W x H): 8U x 2G x 1Kl cm (Approx. 8 x 2 x 1 cm)

Charging: USB Rechargeable

Type: Electric Arc Lighter

9. WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your Tchibo USB Electric Lighter, please contact Tchibo customer service. Refer to your purchase receipt or the official Tchibo website for contact details.

You can visit the Tchibo Store on Amazon for more product information.