Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINGBO SYCF5415

WINGBO 54-inch Flush Mount Ceiling Fan with Light

Model: SYCF5415

Important Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to follow these instructions could result in electric shock, fire, or serious personal injury.

- **WARNING:** To reduce the risk of electric shock, ensure electricity has been turned off at the circuit breaker or fuse box before beginning installation.
- **WARNING:** All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- **WARNING:** To reduce the risk of fire, electric shock, or personal injury, mount the fan directly to the building structure and ensure the support is capable of holding the fan's weight.
- Do not use the fan with a dimmer switch not specifically designed for ceiling fans.
- Ensure the fan blades are at least 7 feet (2.1 meters) from the floor.
- Do not bend the blade holders during installation, balancing, or cleaning.

Package Contents

Carefully unpack all components and ensure you have received all items listed below. If any parts are missing or damaged, contact customer service before proceeding with installation.



Image: All components included in the WINGBO 54-inch ceiling fan package.

- Fan Motor Assembly
- 5 Solid Wood Blades
- Mounting Bracket / Canopy
- Remote Control
- LED Light Module and Diffuser
- Hardware Pack (screws, wire nuts, washers)
- Installation Instructions Manual

Setup and Installation

The WINGBO 54-inch Flush Mount Ceiling Fan is designed for straightforward installation. For a visual guide, please refer to the official installation video provided below. Always ensure power is disconnected at the circuit breaker before starting any electrical work.

Installation Video Guide

Your browser does not support the video tag.

Video: Official installation guide for the WINGBO 54-inch Ceiling Fan with Lights. This video demonstrates the step-by-step process of assembling and mounting the fan.

Step-by-Step Installation Overview

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure it is firmly attached to the building structure.
3. **Hang the Fan Motor Assembly:** Carefully lift the fan motor assembly and hang it onto the mounting bracket using the provided safety cable. This allows for hands-free wiring.
4. **Electrical Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the manual. Typically, this involves connecting live, neutral, and ground wires. Use the provided wire nuts to secure connections.



Image: Connecting the electrical wires during installation. Ensure all connections are secure and follow local electrical codes.

5. **Secure the Canopy:** Once wiring is complete, carefully push the fan motor assembly up and secure the canopy to the mounting bracket with screws.
6. **Attach Fan Blades:** Attach the five solid wood blades to the motor housing using the provided screws and washers. Ensure all screws are tightened securely.



Image: Attaching one of the five solid wood blades to the fan motor assembly.

7. **Install LED Light Kit:** Connect the LED light module wires to the fan's light wires. Secure the LED module and then attach the light diffuser by twisting or screwing it into place.



Image: Installing the LED light module and securing the light diffuser.

8. **Restore Power:** Once all steps are complete, restore power at the circuit breaker and test the fan's functions.

Operating Instructions

Your WINGBO ceiling fan is controlled by a convenient remote control, offering various settings for optimal comfort and ambiance. The fan also supports an optional wall switch for basic ON/OFF functionality, which remembers the last fan speed setting.

Remote Control Functions



Image: The remote control for the WINGBO ceiling fan, detailing each button's function.

- **Fan ON/OFF:** Press the power button to turn the fan on or off.
- **Fan Speed Control:** Adjust between 6 fan speeds to customize airflow.
- **Natural Wind Mode:** Activates a variable speed setting that mimics natural breezes for enhanced comfort.
- **Forward/Reverse Function:** Changes the direction of blade rotation for seasonal use (see Reversible DC Motor section).
- **Timer Setting:** Set the fan to automatically turn off after 1, 4, or 8 hours.
- **Light ON/OFF:** Turns the integrated LED light on or off.
- **Color Temperature Control (3CCT):** Cycle through Warm Light (3000K), Neutral Light (4000K), and Cold Light (6000K).
- **Brightness Control:** Adjust the light brightness from 20% to 100% (stepless dimming).

3 Color Temperatures and Stepless Dimming

The integrated LED light offers three distinct color temperatures to suit your mood and activity, along with stepless

dimming for precise brightness control. The fan features a memory function that recalls your last light choice.



Image: Demonstrating the 3 Color Temperatures (3000K, 4000K, 6000K) and stepless dimming feature of the fan light.

Reversible DC Motor for All Seasons

The energy-efficient DC motor allows for reversible blade rotation, optimizing comfort and energy savings throughout the year.



Image: Explaining the reversible DC motor function for summer cooling and winter air circulation.

- **Summer Mode (Counter-Clockwise):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Clockwise):** Draws warm air up towards the ceiling, circulating it throughout the room to reduce heating costs.

6 Adjustable Speeds

Choose from six distinct fan speeds to achieve your desired level of airflow, from a gentle breeze for sleeping to a strong wind for active environments.



Image: Visual representation of the 6 adjustable fan speeds and their recommended uses.

Quiet Operation

The DC motor ensures quiet operation, making it suitable for bedrooms and other areas where minimal noise is desired.



Image: The WINGBO ceiling fan operating quietly in a bedroom, emphasizing its low noise level for undisturbed sleep.

Product Overview Video

Your browser does not support the video tag.

Video: A brief overview of the WINGBO 54-inch wooden ceiling fan with light, showcasing its design and features in a living space.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your WINGBO ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents, as these can damage the finish. For the light diffuser, wipe gently with a dry or slightly damp cloth.
- **Blade Checks:** Periodically check that all blade screws are tight. Over time, screws can loosen, causing the fan to wobble.
- **Dust Removal:** Regularly dust the fan blades and motor housing to prevent dust buildup, which can affect performance and appearance.

- **No Lubrication Needed:** The DC motor is permanently lubricated and does not require additional oiling.

Troubleshooting

If you encounter any issues with your WINGBO ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker/fuses. Ensure all wire connections are secure. Replace remote battery or re-pair remote according to instructions.
Light does not work	Loose wire connection to light kit; LED module faulty; Remote control issue.	Check light kit wiring. If LED module is faulty, contact support. Ensure remote battery is good and light button is pressed.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws. Use a balancing kit (not included) if necessary. Ensure mounting bracket is securely fastened to the ceiling.
Remote control not working	Low or dead battery; Remote not paired with fan; Obstruction between remote and receiver.	Replace remote battery. Re-pair remote with fan (refer to specific pairing instructions if available). Ensure clear line of sight.

Specifications

- **Brand:** WINGBO
- **Model Number:** SYCF5415
- **Product Dimensions:** 54"D x 54"W x 11.22"H
- **Color:** Charcoal Gray
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** DC
- **Style:** Modern
- **Room Type:** Bedroom, Covered Outdoor, Dining Room, Kitchen, Living Room
- **Special Feature:** 5 Blades
- **Recommended Uses For Product:** Indoor, Covered Outdoor
- **Mounting Type:** Flush Mount
- **Controller Type:** Remote Control
- **Number of Speeds:** 6
- **Wattage:** 40 watts
- **Number of Blades:** 5
- **Control Method:** Remote
- **Standby Power Shutoff:** Energy Efficient
- **Is Product Cordless:** No
- **Motor Type:** DC
- **Smart Home Compatibility:** Not Smart Home Compatible
- **Installation Type:** Flush Mount
- **Material:** Wood (Blades)
- **Finish Type:** Brushed

- **Included Components:** Remote

Note: For covered outdoor use, ensure the fan is not exposed to direct rainfall or standing water.



Image: WINGBO ceiling fan installed in a covered outdoor space.

Warranty and Support

WINGBO provides a **2-year after-sales service** for this product. If any part of your ceiling fan is damaged or you require assistance, please do not hesitate to contact our customer support team.
For support, please visit the WINGBO store on Amazon or contact us through the platform where you purchased the product. Please have your model number (SYCF5415) and purchase date available when contacting support.

© 2026 WINGBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GL7MKGV8

More documents and user manuals: **https://manuals.plus/**