

[Manuals.plus](#) /

› [BESTEK](#) /

› BESTEK 500W Pure Sine Wave Power Inverter DC 12V to AC 110V Car Converter Instruction Manual

BESTEK MRZ5011BU-PD30W

BESTEK 500W Pure Sine Wave Power Inverter

Model: MRZ5011BU-PD30W

INTRODUCTION

The BESTEK 500W Pure Sine Wave Power Inverter converts 12V DC power from your vehicle's battery into 110V AC power, similar to a standard household outlet. This inverter is designed to safely power sensitive electronic devices, making it ideal for laptops, medical equipment like CPAP machines, and various tools. Its pure sine wave output ensures compatibility and prevents damage to your electronics, and is recommended by most cordless power tool manufacturers for extended battery life.



Image: The BESTEK 500W Pure Sine Wave Power Inverter in use, connected to various electronic devices such as a laptop, fan, and drone charger, demonstrating its versatility.

Safety Information

This inverter incorporates multiple protection mechanisms to ensure safe operation for both the device and your connected electronics. Always adhere to the following safety guidelines:

- **Overload Protection:** The inverter will automatically cut off AC power if the load exceeds 500W. If the red indicator light flashes, turn the inverter off and then back on to reset.
- **Short-Circuit Protection:** Prevents damage from electrical shorts.
- **Over-voltage Protection:** Safeguards against excessive input voltage.
- **Low Voltage Protection:** Prevents battery drain by shutting down if input voltage is too low.
- **Overheating Protection:** A built-in fan activates automatically, and the inverter shuts down if it overheats.

- **Reverse Connection Protection:** Protects against incorrect battery terminal connections.

Ensure proper ventilation around the inverter during operation. Do not expose the inverter to water, rain, or excessive moisture. Keep out of reach of children.

Isolation Voltage Protection

Protection Perfectly for your device between
Input DC 12V/Output DC 5V USB and Output AC 120V



Overload
Protection



Short-Circuit
Protection



Over-voltage
Protection



Low Voltage
Protection



Overheating
Protection



Reverse Polarity
Protection




Image: An internal diagram of the BESTEK 500W Power Inverter, illustrating its various protection circuits and cooling fan for enhanced safety and durability.

PRODUCT OVERVIEW

The BESTEK 500W Pure Sine Wave Power Inverter is designed for efficiency and versatility. It features a robust aluminum alloy housing with unique ventilation holes and an integrated cooling fan for optimal thermal management. The front panel includes multiple output ports for various charging needs.

Key Features:


- **500W Continuous Power:** Provides stable power for a wide range of devices.
- **Dual AC Outlets:** Two 110V AC outlets for powering standard appliances.
- **High-Speed Charging Ports:** One 30W PD USB-C port and one 4.2A USB-A port for fast charging mobile devices.
- **Pure Sine Wave Output:** Delivers clean power suitable for sensitive electronics.
- **Advanced Cooling System:** Textured aluminum housing and an automatic cooling fan prevent overheating.

Power Inverter Fast Charger

500W
PD30W




BESTEK PD 30W



⚡ 100%

Other PD 15W



50%

Image: The BESTEK 500W Power Inverter highlighting its fast charging capabilities, including a 30W PD USB-C port and a 4.2A USB-A port, with a visual comparison of charging speed.

Great Power Output, Fast Charging

Input DC 12V/Output DC 5V USB/30W USB C
and Output AC 120V



Intelligent
Identification



1*USB



1*PD 30W



2*AC Outlets



Image: A detailed view of the BESTEK 500W Power Inverter showing its DC 12V input and AC 120V output, along with USB-C and USB-A charging ports.

SETUP INSTRUCTIONS

Follow these steps to properly set up your BESTEK 500W Pure Sine Wave Power Inverter:

1. **Choose Power Source:** The inverter can be connected to your vehicle's battery using the provided alligator clamps

or to a cigarette lighter socket.

2. Battery Connection (for higher power draw):

- Ensure the inverter is turned off.
- Connect the red alligator clamp to the positive (+) terminal of your 12V battery.
- Connect the black alligator clamp to the negative (-) terminal of your 12V battery.
- Ensure connections are secure and tight.

3. Cigarette Lighter Connection (for lower power draw, typically up to 150W):

- Ensure the inverter is turned off.
- Insert the cigarette lighter plug firmly into your vehicle's 12V cigarette lighter socket.
- Note: The cigarette lighter connection uses a 15-amp fuse designed for your vehicle.

4. **Placement:** Place the inverter on a stable, dry surface with adequate ventilation. Avoid placing it in direct sunlight or near heat sources.

5. **Power On:** Once connected, switch the inverter's power button to the 'ON' position. The green indicator light should illuminate.

Your browser does not support the video tag.

Video: An official BESTEK video demonstrating the features and setup of the 500W Pure Sine Wave Power Inverter, including its various ports and applications.

OPERATING INSTRUCTIONS

Once the inverter is properly set up and powered on, you can begin connecting your devices:

1. **Connect AC Devices:** Plug your 110V AC devices into the dual AC outlets. Ensure the total wattage of connected devices does not exceed 500W. This inverter is only compatible with three-prong plugs.
2. **Connect USB Devices:** Use the 30W PD USB-C port or the 4.2A USB-A port to charge compatible USB devices.
3. **Monitor Load:** Pay attention to the inverter's indicator lights. A green light indicates normal operation. If the red light flashes, it signifies an overload or other protection activation.
4. **Power Off:** When finished, first disconnect all devices from the inverter, then switch the inverter's power button to the 'OFF' position, and finally disconnect it from the power source (battery or cigarette lighter).



Professional Grade Power for Tough Jobs

Runs Power Tools & Protects Sensitive Instruments




Image: The BESTEK 500W Power Inverter positioned in a car, demonstrating its use as a mobile power source for a laptop and other electronic devices.



Image: The BESTEK 500W Power Inverter being used in an outdoor camping or RV environment, providing power for various appliances.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your inverter:

- **Cleaning:** Keep the inverter clean and free from dust and debris. Use a dry cloth to wipe the exterior. Do not use liquid cleaners.
- **Ventilation:** Ensure the ventilation holes are not blocked. Periodically check for any obstructions.
- **Fuse Replacement:** The inverter is protected by replaceable fuses. For battery connections, it uses dual 40-amp/32-volt external fuses, which can be accessed and replaced from the back of the inverter. For cigarette lighter connections, a 15-amp fuse specific to your vehicle is used. Always replace fuses with ones of the same type and rating.
- **Storage:** When not in use for extended periods, store the inverter in a cool, dry place, disconnected from any power source.

TROUBLESHOOTING

If you encounter issues with your inverter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Inverter not turning on / No power output	Loose connection, low battery voltage, blown fuse, faulty power source.	Check all connections. Ensure battery voltage is sufficient (12V). Replace fuses if blown. Test the power source (cigarette lighter or battery).
Red light flashing / Overload shutdown	Connected devices exceed 500W, short circuit in connected device.	Disconnect all devices. Turn the inverter off and then back on to reset. Reduce the total wattage of connected devices. Check devices for faults.

Problem	Possible Cause	Solution
Inverter overheats and shuts down	Blocked ventilation, excessive ambient temperature, prolonged high load.	Ensure ventilation holes are clear. Move inverter to a cooler environment. Reduce the load on the inverter.
Buzzing noise from connected appliance	Some inductive loads (e.g., motors) may produce a slight buzz with pure sine wave inverters, though less common than with modified sine wave.	This is usually normal and harmless. If excessive, try a different appliance or consult the appliance's manual.

SPECIFICATIONS

Feature	Specification
Brand	BESTEK
Model Number	MRZ5011BU-PD30W
Power Source	Battery Powered
Input Voltage	12 volts DC
Output Voltage	110 volts AC
Continuous Output Power	500 watts
Electrical Output Waveform	Pure Sine Wave
Frequency	60 hertz
USB-C Output	30W PD
USB-A Output	4.2A
Item Dimensions (L x W x H)	2"L x 2"W x 2"H
Item Weight	16 ounces
Certifications	ETL Certified
Recommended Uses	RV, camping, emergency situations, outdoor, road trips, solar, truck

Universal Compatibility with True sine wave


Fully applicable for all appliances under 500Watts




Image: A diagram illustrating the universal compatibility of the BESTEK 500W Pure Sine Wave Power Inverter with various appliances and their typical power requirements, such as laptops, game consoles, and CPAP machines.

Pure Sine Wave vs Modified Sine Wave

Why It Matters?



Safe for All Electronics like Laptop, Phone



May Damage Sensitive Electronics



Image: A visual comparison between Pure Sine Wave and Modified Sine Wave outputs, explaining why Pure Sine Wave is safer for sensitive electronics.

WARRANTY AND SUPPORT

BESTEK is committed to providing high-quality products and excellent customer service.

- **Product Warranty:** The inverter comes with a 12-month product replacement warranty.

- **Customer Support:** BESTEK offers 24/7 technical support and attentive customer service.
- **Certifications:** The inverter is ETL-certified, ensuring safety and quality standards are met.

For any questions or dissatisfaction with your purchase, please contact BESTEK customer service for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question