

[Manuals.plus](#) /

› [HOOBRO](#) /

› HOOBRO TV Stand and Rolling TV Stand Bundle Instruction Manual (Models BB122UDDS01 & BB37DS01)

HOOBRO BB122UDDS01 & BB37DS01

HOOBRO TV Stand and Rolling TV Stand Bundle Instruction Manual

Models: BB122UDDS01 & BB37DS01

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the product.
- Place the TV stand on a level surface to prevent tipping.
- Do not exceed the maximum load capacity of 110 lbs (50 kg) for the TV stand.
- Keep children and pets away from the assembly area.
- For the rolling TV stand, ensure casters are locked when stationary to prevent accidental movement.
- Route power cords safely to avoid tripping hazards and damage.

2. PRODUCT OVERVIEW

This bundle includes two distinct entertainment units: the HOOBRO TV Stand (BB122UDDS01) and the HOOBRO Rolling TV Stand (BB37DS01).

HOOBRO TV Stand (BB122UDDS01)

A stationary TV console designed for TVs up to 55 inches, featuring open storage shelves, a power center with outlets and USB ports, and an adjustable LED light strip.



Image: The HOOBRO TV Stand (BB122UDDS01) in a living room setting, showcasing its LED lighting, charging station, and storage capabilities.

HOOBRO Rolling TV Stand (BB37DS01)

A mobile TV stand with an adjustable mount for TVs ranging from 23 to 50 inches. It includes multiple storage shelves and offers the flexibility of casters for mobility or adjustable feet for stationary use.



Image: The HOOBRO Rolling TV Stand (BB37DS01) with a TV mounted, highlighting its compact design and storage options.

3. SETUP AND ASSEMBLY

Both TV stands are designed for straightforward assembly. An illustrated manual and necessary tools are included with your product. Follow the step-by-step instructions provided in the separate assembly guide for each unit.

General Assembly Steps:

1. Unpack all components and verify against the parts list in the assembly guide.
2. Identify and separate hardware (screws, bolts, etc.).
3. Follow the numbered steps in the assembly guide, attaching components as instructed.
4. Ensure all connections are secure but do not overtighten.

Specific Setup for HOOBRO TV Stand (BB122UDDS01):

- **Power Center Installation:** The integrated power strip with 2 outlets and 2 USB ports can be positioned at the front or back of the central compartment for convenient access. Secure it firmly once its location is chosen.
- **LED Light Strip:** Attach the LED light strip as per the assembly guide. Ensure the connection to the power center is secure.



Image: The smart controller for the RGB LED light strip, showing options for 21 colors, 8 brightness levels, and 8 lighting modes.

Specific Setup for HOOBRO Rolling TV Stand (BB37DS01):

- **Casters or Adjustable Feet:** Decide whether to install the four casters (two lockable) for mobility or the four adjustable feet for stationary use. Install only one set.
- **Adjustable TV Mount:** Assemble the TV mount according to the instructions. This mount is designed to fit 23-50 inch TVs. Ensure the TV is securely attached to the mount.

Smooth Casters and Adjustable Feet

Switch easily between moving and stationary modes.



Image: Detail of the smooth casters and adjustable feet, illustrating how to switch between mobile and stationary modes.

4. OPERATING INSTRUCTIONS

HOOBRO TV Stand (BB122UDDS01):

- **Power Center:** Plug the TV stand's power cord into a wall outlet. Use the 2 AC outlets and 2 USB ports to power and charge your devices.
- **LED Light Strip:** Use the provided smart controller to adjust the LED light strip. You can select from 21 colors, 8 brightness levels, and 8 lighting modes to create your desired ambiance.
- **Device Placement:** The open bottom shelf features a mesh design for improved heat dissipation, ideal for game consoles and other media devices.

HOOBRO Rolling TV Stand (BB37DS01):

- **Mobility:** If casters are installed, unlock the two lockable casters to move the stand smoothly. Lock them when the stand is in its desired position to prevent accidental movement.
- **Stationary Use:** If adjustable feet are installed, ensure they are properly adjusted to level the stand and provide stability.
- **TV Placement:** This stand is designed for 23-50 inch televisions. Ensure your TV is securely mounted and balanced.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the stand and shelves to prevent buildup.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Cable Management:** Keep cables tidy and organized to prevent damage and ensure safety.

- **LED Strip Care:** Avoid bending or pulling the LED strip excessively. If the strip malfunctions, contact customer support.

6. TROUBLESHOOTING

TV Stand (BB122UDDS01) Issues:

- **LED Light Strip Not Working:**
 - Ensure the power cord is securely plugged into a working outlet.
 - Check the connection between the LED strip and the power center.
 - Verify the remote control batteries are functional.
- **Charging Ports Not Working:**
 - Confirm the TV stand's power cord is plugged in.
 - Test with a different device or cable.

Rolling TV Stand (BB37DS01) Issues:

- **Stand is Unstable:**
 - If using adjustable feet, ensure they are all making firm contact with the floor and are adjusted to level the stand.
 - If using casters, ensure the lockable casters are engaged when stationary.
 - Verify all assembly hardware is tightened.
- **Difficulty Moving (with casters):**
 - Ensure the caster locks are disengaged.
 - Check for any obstructions on the floor.

7. SPECIFICATIONS

HOOBRO TV Stand (BB122UDDS01)

- **Dimensions:** 47.2"L x 11.8"W x 17.7"H (120cm L x 30cm W x 45cm H)
- **TV Compatibility:** Up to 55 inches
- **Load Capacity:** 110 lbs (50 kg)
- **Power Center:** 2 AC Outlets, 2 USB Ports
- **Lighting:** Adjustable RGB LED Light Strip (21 colors, 8 brightness, 8 modes)
- **Features:** Ventilated mesh shelves for heat dissipation




Image: Detailed dimensions of the HOOBRO TV Stand (BB122UDDS01), including length, width, height, and load capacity.

HOOBRO Rolling TV Stand (BB37DS01)

- **Dimensions:** Approximately 20.5"W x 14.6"D x 46.7"H (52cm W x 37cm D x 118.5cm H)
- **TV Compatibility:** 23-50 inches
- **Mobility:** 4 casters (2 lockable) or 4 adjustable feet
- **Features:** Adjustable TV mount, multiple storage shelves






Image: Detailed dimensions of the HOOBRO Rolling TV Stand (BB37DS01), including width, depth, height, and compatible TV sizes.

↓↓↓
Load Capacity:
110lb
(50kg)



Ventilated Mesh Shelves



Sturdy Construction



Adjustable Feet

Image: Features overview, including load capacity, ventilated mesh shelves, sturdy construction, and adjustable feet, applicable to both units where relevant.

8. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please refer to the contact information provided with your purchase or visit the official HOOBRO website. Please have your model number (BB122UDDS01 or BB37DS01) and purchase details ready when contacting support.