

Nespresso ENV200WCA

Nespresso Vertuo Up Coffee and Espresso Machine (ENV200WCA) User Manual

Comprehensive instructions for setup, operation, maintenance, and troubleshooting of your Nespresso Vertuo Up coffee and espresso machine.

1. PRODUCT OVERVIEW

The Nespresso Vertuo Up coffee and espresso machine offers a streamlined coffee experience with its slim, modern design and rapid 3-second heat-up time. It provides an effortless way to prepare both hot and iced coffee beverages. The machine features a dedicated Coffee Creations mode for concentrated brews, ideal for iced and milk-based recipes, ensuring rich flavor with less dilution.

Key features include:

- Advanced Centrifusion technology for unique taste and smooth crema.
- Over 40 premium and flavored coffees available in 7 cup sizes: Ristretto, Espresso, Double Espresso, Gran Lungo, Mug, XL Coffee, Carafe.
- Dedicated Coffee Creations mode for concentrated brews for iced and milk-based recipes.
- Rapid 3-second heat-up time for quick brewing.
- Automatic shut-off after 2 minutes of inactivity.
- Slim design with a smooth-opening lever for intuitive operation.
- 1.4L rotating water tank for flexible placement and easy refilling.
- Connectivity to the Nespresso Smart App for real-time alerts, customization, and maintenance guidance.
- Aluminum-sealed capsules to preserve coffee freshness.



The Nespresso Vertuo Up machine utilizes Centrifusion technology to produce coffee with a signature velvety crema.

2. SETUP

2.1 Unpacking and Initial Placement

Carefully remove all components from the packaging. The box includes the Nespresso Vertuo Up machine, a Nespresso Capsule Starter Set, and this user manual. Place the machine on a stable, flat surface. The 1.4L water tank is designed to rotate, allowing for optimal placement on your countertop, whether positioned behind or to either side of the machine.

UNFORGETTABLE COFFEE EXPERIENCES

Experience the Vertuo system: over 50 premium and flavored coffees across 7 cup sizes. Hot, over ice, or in a coffee recipe, featuring exclusive partner brands.

Enjoy a one-of-a-kind taste experience.



The machine features a rotatable 1.4L water tank for flexible kitchen configurations.

2.2 Initial Rinse

Before first use, perform an initial rinse cycle to clean the internal components. Fill the water tank with fresh drinking water. Place a container (minimum 0.5L) under the coffee outlet. Close the machine head without inserting a capsule and press the brew button. The machine will perform a quick rinse cycle. Repeat this process two to three times until the water runs clear.

2.3 Nespresso Smart App Connection

For enhanced features and maintenance alerts, connect your machine to the Nespresso Smart App. Download the app using the QR codes provided below or search for "Nespresso Smart App" in your device's app store. Follow the in-app instructions to pair your machine via Bluetooth and connect it to your Wi-Fi network. This allows for

customization of coffee size and temperature, and provides easy access to maintenance guidance.

NESPRESSO SMART APP

Connect your machine to the App for:

- Cup customization, adapt temperature and cup size.
- Easy maintenance and troubleshooting.
- Step-by-step recipe guidance.



Scan the QR codes to download the Nespresso Smart App for iOS or Android devices.

Download for [iOS](#) | Download for [Android](#)

3. OPERATING INSTRUCTIONS

3.1 Brewing Coffee or Espresso

1. **Fill Water Tank:** Ensure the water tank is filled with fresh drinking water.
2. **Power On:** Press the brew button to turn on the machine. It heats up in approximately 3 seconds.
3. **Insert Capsule:** Open the machine head by lifting the lever. Insert a Nespresso Vertuo capsule into the capsule holder. Close the machine head and lock the lever.
4. **Place Cup:** Position an appropriate-sized cup under the coffee outlet. The adjustable cup support accommodates various cup sizes.
5. **Start Brewing:** Press the brew button. The machine will automatically recognize the capsule type and brew the coffee to the optimal size and parameters.
6. **Enjoy:** Your coffee or espresso is ready. The machine will automatically eject the used capsule into the capsule container.

UPLIFT YOUR DAY WITH EFFORTLESS PRECISION

Combining slim, modern design with convenient, rapid heat-up, Vertuo Up is ready to brew in 3 seconds - delivering an effortless and unforgettable coffee experience, whether hot or iced.



The Vertuo Up machine offers brewing simplicity with rapid heat-up and one-touch operation.

3.2 Coffee Creations Mode

The Coffee Creations mode allows for concentrated brews, ideal for preparing iced coffee or milk-based recipes. To activate this mode, press the dedicated Coffee Creations button (if available on your model) or select the appropriate setting via the Nespresso Smart App. This mode delivers a more intense coffee extract that maintains its flavor when diluted with ice or milk.



VERTUO UP
MAKE IT EASY, MAKE IT HOT OR ICED.


7 Cup Sizes
Brew seven sizes of coffee.


Bluetooth & WiFi
Easy care, coffee customisation on the Nespresso Smart App.


Coffee Creations mode
Concentrated brew made easy. Ice it, milk it, and savor.

Prepare refreshing iced coffee easily with the Coffee Creations mode.

3.3 Available Cup Sizes and Recipes

The Vertuo Up machine supports a variety of coffee types and cup sizes, including:

- **Espressos:** Ristretto (25 ml), Espresso (40 ml), Double Espresso (80 ml)
- **Large Cups:** Gran Lungo (150 ml), Mug (230 ml), XL Coffee (355 ml), Carafe (535 ml)
- **Over Ice:** Iced Coffee (80 ml), Cold Brew Style (355 ml)



A LARGE VARIETY OF PREMIUM AND FLAVOURED COFFEES

ESPRESSOS

Ristretto 25 ml Single 40 ml Double 80 ml

LARGE CUPS

Gran Lungo 150 ml Mug 230 ml XL Coffee 355 ml Carafe 535 ml

OVER ICE

Iced Coffee 80 ml Cold Brew Style 355 ml

BARISTA CREATIONS

Cappuccino* Latte*
*To be prepared using a milk frother

Explore a wide variety of coffee sizes and recipes with your Vertuo Up machine.

4. MAINTENANCE

4.1 Cleaning

Regular cleaning ensures optimal performance and hygiene. All removable parts, such as the water tank, capsule container, and drip tray, are easy to clean. The steel grates on the cup holder are designed for hygiene and can be

removed for washing. Wipe the exterior of the machine with a damp cloth. Do not immerse the machine in water.

4.2 Descaling

Descaling is essential to remove mineral buildup and maintain the machine's efficiency. The Nespresso Smart App will provide alerts when descaling is recommended. Follow the instructions provided in the app or refer to the Nespresso website for detailed descaling procedures using a Nespresso descaling solution.

4.3 Capsule Recycling

Nespresso Vertuo capsules are made from aluminum and are recyclable. Nespresso offers free, prepaid recycling bags to facilitate the recycling process. 80% of Nespresso capsule aluminum is sourced from recycled materials. Participate in the recycling program to minimize environmental impact.

CHOOSE TO RECYCLE

Hermetically sealed, our aluminum capsules preserve the freshness of roasted ground coffee.

80% of Nespresso capsule's aluminum is from a recycled source.

Help to recycle with us by using our free, prepaid recycling bags.



Nespresso aluminum capsules are recyclable; use the provided recycling bags.

5. TROUBLESHOOTING

If you encounter issues with your Nespresso Vertuo Up machine, consider the following common solutions:

- **Machine Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet.
- **No Coffee Dispensed:** Check if the water tank is filled and properly seated. Ensure a capsule is correctly inserted and the machine head is locked. Perform an initial rinse cycle if the machine is new or has not been used for a while.
- **Coffee Not Hot Enough:** Adjust the temperature settings via the Nespresso Smart App. Ensure the machine has completed its heating cycle before brewing.
- **App Connectivity Issues:** Verify your Wi-Fi connection and ensure Bluetooth is enabled on your mobile device. Restart both the machine and your device if connection problems persist.
- **Leaking:** Check that the water tank is correctly positioned and not overfilled. Ensure the drip tray is properly installed.

For more detailed troubleshooting, consult the Nespresso Smart App or the official Nespresso website.

6. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	Nespresso
Model Number	ENV200WCA
Capacity	1.4 Liters
Colour	White
Product Dimensions (D x W x H)	39.1D x 22.1W x 25.7H Centimetres
Item Weight	9 Pounds
Special Feature	Auto Shut-Off
Coffee Maker Type	Espresso Machine
Specific Uses for Product	Americano, Cappuccino, Coffee, Espresso, Iced Coffee, Latte
Operation Mode	Fully Automatic
Wattage	940 watts
Voltage	120 Volts
Human Interface Input	Buttons
Coffee Input Type	Pod
Power Source Type	AC adapter
Compatible Coffee Pods	Nespresso Vertuo Carafe, Nespresso Vertuo Coffee (Mug), Nespresso Vertuo Double Espresso, Nespresso Vertuo Espresso, Nespresso Vertuo Gran Lungo
Is the item dishwasher safe?	No
Country of Origin	Indonesia
Manufacturer	DeLonghi

7. WARRANTY

The Nespresso Vertuo Up Coffee and Espresso Machine (Model ENV200WCA) is covered by a **1-Year Manufacturer's Warranty**. Please retain your proof of purchase for any warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or visit the official Nespresso website.

8. SUPPORT

For further assistance, product registration, or to order Nespresso capsules and accessories, please utilize the

following resources:

- **Nespresso Smart App:** Provides real-time alerts, personalized coffee settings, and guided maintenance procedures.
- **Nespresso Club:** Access exclusive services, rewards, and experiences. Discover more at www.nespresso.com.
- **Online Support:** Visit the official Nespresso website for FAQs, troubleshooting guides, and contact information for customer service.