

[Manuals.plus](#) /

› [GOVO](#) /

› GOVO GoSurround 975 Pro Soundbar User Manual

GOVO GOSURROUND 975 PRO

GOVO GoSurround 975 Pro Soundbar System User Manual

Model: GOSURROUND 975 PRO

INTRODUCTION

This manual provides essential information for the safe and correct operation of your GOVO GoSurround 975 Pro Soundbar System. Please read this manual thoroughly before using the product and retain it for future reference. The GOVO GoSurround 975 Pro is a 2.1 channel soundbar system designed to enhance your home audio experience with powerful sound and versatile connectivity.

WHAT'S IN THE BOX

Carefully unpack all items and ensure you have received all components listed below. If any item is missing or damaged, please contact customer support.

- 1 x GOVO GoSurround 975 Pro Soundbar
- 1 x Wired Subwoofer
- 1 x Remote Control
- 1 x Audio Cable
- 1 x User Manual (this document)
- 1 x Warranty Card




Image: The GOVO GoSurround 975 Pro Soundbar and its accompanying subwoofer, illustrating a typical 2.1 channel home theater setup.


PRODUCT FEATURES

The GOVO GoSurround 975 Pro offers a range of features designed to deliver a high-quality audio experience:

- **Powerful 400W RMS Output:** Delivers dynamic, room-filling sound.
- **2.1 Channel Audio:** Provides immersive sound with a dedicated soundbar and wired subwoofer.
- **High-Performance Drivers:** Equipped with 6 strategically placed drivers for clear, high-definition audio.
- **Versatile Connectivity:** Supports HDMI (ARC), Optical, AUX, USB, and Bluetooth v5.3.
- **Customizable EQ Modes:** Select from Music, Movie, and News modes to optimize audio for different content.
- **LED Display:** Provides visual feedback for settings and modes.
- **8-inch Subwoofer:** Delivers deep and powerful bass.



Image: The GOVO GoSurround 975 Pro Soundbar and Subwoofer, highlighting its 400W power output.



Feel the Driver's Force

Massive output, richer lows, and room-filling clarity

Image: An exploded view of the soundbar, showcasing its internal high-performance audio drivers.

SETUP

1. Physical Placement

- Place the soundbar directly in front of your television, centered for optimal sound dispersion.
- Position the subwoofer on the floor near the soundbar. Experiment with placement to find the best bass response for your room. Avoid placing it in a corner if bass becomes too boomy.
- Ensure adequate ventilation around both the soundbar and subwoofer.

2. Connections

Connect the subwoofer to the soundbar using the provided wired connection. Then, choose one of the following audio connection methods to connect the soundbar to your TV or other audio source:

1. **HDMI (ARC):**

Connect an HDMI cable (not included) from the HDMI ARC port on your TV to the HDMI ARC port on the soundbar. This allows audio to be sent from the TV to the soundbar and often enables TV remote control of the soundbar volume. Ensure your TV's HDMI ARC feature is enabled in its settings.

2. **Optical:**

Connect an optical cable (not included) from the Optical OUT port on your TV to the Optical IN port on the soundbar. Select 'Optical' as the audio output on your TV.

3. **AUX:**

Use the provided 3.5mm audio cable to connect your audio source (e.g., TV headphone jack, smartphone) to the AUX IN port on the soundbar.

4. **USB:**

Insert a USB drive containing audio files into the USB port on the soundbar. The soundbar will automatically switch to USB mode and begin playback.

5. **Bluetooth:**

For wireless connection, refer to the 'Bluetooth Pairing' section under Operating Instructions.

After making connections, plug the power cables for both the soundbar and subwoofer into a wall outlet.

OPERATING INSTRUCTIONS

1. Controls

The soundbar can be controlled using the included remote control or the integrated buttons on the unit.

Command Your Sound

Total control. Zero complications



Image: Close-up of the soundbar's control panel, showing buttons for volume, input, play/pause, power, and light control.

- **Power Button:** Turns the soundbar ON or OFF.
- **Input Button:** Cycles through available input sources (HDMI ARC, Optical, AUX, USB, Bluetooth).
- **Volume Up/Down:** Adjusts the master volume level.
- **Play/Pause:** Controls media playback in Bluetooth or USB mode.
- **Light Button:** Controls the LED lighting feature.

2. Bluetooth Pairing

1. Press the Input button on the soundbar or remote control until 'BT' appears on the LED display.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select 'GOVO GoSurround 975 Pro' from the list.
4. Once paired, the soundbar will indicate a successful connection, and you can stream audio from your device.

3. EQ Modes

Use the remote control to switch between the following Equalizer (EQ) modes:

- **Music Mode:** Optimized for music playback, enhancing clarity and bass.
- **Movie Mode:** Designed for cinematic content, providing a wider soundstage and enhanced dialogue.
- **News Mode:** Focuses on vocal clarity, ideal for news broadcasts or podcasts.

MAINTENANCE

To ensure the longevity and optimal performance of your soundbar system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar and subwoofer. Do not use liquid cleaners, aerosols, or abrasive materials.
- **Ventilation:** Ensure that the ventilation openings are not blocked. Proper airflow prevents overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Moisture:** Keep the soundbar and subwoofer away from water and high humidity.

TROUBLESHOOTING

If you encounter issues with your GOVO GoSurround 975 Pro, refer to the following common solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cables are securely plugged in. Check the power outlet with another device.
No sound	Incorrect input selected; Volume too low; Mute activated; Incorrect TV audio settings	Press the Input button to select the correct source. Increase volume. Deactivate mute. Check TV audio output settings (e.g., set to PCM for Optical).
Bluetooth pairing fails	Soundbar not in pairing mode; Device too far; Interference	Ensure soundbar is in BT mode. Move device closer. Turn off other Bluetooth devices. Try re-pairing.
Remote control not working	Batteries depleted; Obstruction between remote and soundbar	Replace batteries. Ensure clear line of sight to the soundbar's sensor.
Bass is weak or distorted	Subwoofer not connected; Subwoofer volume too low; Incorrect EQ mode	Check subwoofer connection. Adjust subwoofer volume (if available) or master volume. Switch to Music or Movie EQ mode.

SPECIFICATIONS

Feature	Specification
Model Name	GOSURROUND 975 PRO
Brand	GOVO
Speaker Maximum Output Power	400 Watts RMS
Number of Audio Channels	2.1

Feature	Specification
Subwoofer Speaker Diameter	8 Inches
Connectivity Technology	Bluetooth v5.3, HDMI (ARC), Optical, AUX, USB
Bluetooth Range	Up to 10 meters
Audio Output Mode	Surround
Control Method	Remote Control
Product Features	LED Light
Item Dimensions (D x W x H)	85D x 15W x 34H Centimeters
Item Weight	9250 Grams
Compatible Devices	Home Theater, Laptop, Projector, Streaming Device, Television

WARRANTY AND SUPPORT

Warranty Information

The GOVO GoSurround 975 Pro Soundbar System comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your purchase receipt and warranty card for any warranty claims.

The warranty does not cover damages caused by:

- Accident, misuse, abuse, neglect, or improper installation.
- Unauthorized repairs or modifications.
- Power surges or lightning strikes.
- Normal wear and tear.

Customer Support

For technical assistance, warranty claims, or product inquiries, please contact GOVO customer support. Refer to the contact information provided on your warranty card or the official GOVO website.

Manufacturer: DPAC VENTURES LLP, Govo

Importer Contact Information: DPAC Ventures LLP, Second Floor, No 1202,100ft Road HAL 2nd Stage,Indranagar, Domlur, Bengaluru, Karnataka, India, 560008

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GLN78MP6>

More documents and user manuals: <https://manuals.plus/>