

- [Manuals.plus](#) /
- > [GOVO](#) /
 - > GOVO GoSurround 1000 Pro 5.2.4 Channel Soundbar System User Manual

GOVO GOSURROUND 1000 PRO

**GOVO GoSurround 1000 Pro 5.2.4 Channel Soundbar System
User Manual**

Model: GOSURROUND 1000 PRO

INTRODUCTION

Thank you for choosing the GOVO GoSurround 1000 Pro 5.2.4 Channel Soundbar System. This manual provides essential information for setting up, operating, and maintaining your new sound system. Please read it thoroughly before use to ensure optimal performance and safety.




The GOVO GoSurround 1000 Pro system integrated into a home entertainment setup.

WHAT'S IN THE BOX

Carefully unpack all components and ensure you have received the following items:

- 1 x GOVO GoSurround 1000 Pro Soundbar
- 2 x Satellite Speakers
- 2 x 6.5-inch Subwoofers
- 1 x Remote Control
- 1 x Audio Cable
- 1 x User Manual (this document)
- 1 x Warranty Card



All included components of the GOVO GoSurround 1000 Pro sound system.

SETUP

1. Placement

- **Soundbar:** Place the soundbar centrally below your TV. Ensure it is on a stable, flat surface or securely wall-mounted.
- **Subwoofers:** Position the two subwoofers on the floor, ideally near the soundbar, for optimal bass distribution.
- **Satellite Speakers:** Place the wireless satellite speakers behind your listening position, to the left and right, for an immersive surround sound experience.

2. Connections

Connect the soundbar to your TV or other audio sources using the appropriate cables.

- **HDMI ARC:** For the best audio quality and TV remote control integration, connect an HDMI cable from the soundbar's HDMI ARC port to your TV's HDMI ARC port.
- **Optical:** If your TV does not have HDMI ARC, use an optical cable to connect the soundbar's OPTICAL IN port to your TV's optical output.
- **AUX:** For analog audio sources, connect a 3.5mm AUX cable to the soundbar's AUX IN port.
- **USB:** Insert a USB drive into the USB port for direct media playback.



AUX



HDMI(ARC)



OPTICAL



USB

Versatile Connectivity

One Bar. Unlimited Ways to Connect & Enjoy



Detailed view of the soundbar's connectivity ports.

3. Power On

Connect all components to a power outlet. The soundbar, subwoofers, and satellite speakers will automatically pair wirelessly. Press the power button on the soundbar or remote control to turn on the system.

OPERATING INSTRUCTIONS


1. Basic Controls

The soundbar can be controlled using the integrated touch controls on the unit or the included remote control.

- **Power:** Turns the system on or off.
- **Mode:** Cycles through input sources (HDMI ARC, Optical, AUX, USB, Bluetooth).
- **Volume Up/Down:** Adjusts the master volume.
- **Play/Pause:** Controls media playback (for Bluetooth/USB modes).

Integrated Controls

Command the Room, Master the Atmosphere



Integrated touch controls on the GOVO GoSurround 1000 Pro soundbar.

2. Bluetooth Pairing

To connect a Bluetooth device:

1. Press the 'Mode' button on the soundbar or remote until 'BT' appears on the LED display.
2. Enable Bluetooth on your device (smartphone, tablet, etc.) and search for 'GOVO GoSurround 1000 Pro'.
3. Select the soundbar from the list to pair. A confirmation sound will indicate successful pairing.

3. EQ Modes

The soundbar features three pre-set equalizer modes to optimize audio for different content:

- **Music Mode:** Enhanced for musical playback, providing balanced highs, mids, and bass.
- **Movie Mode:** Optimized for cinematic experiences, emphasizing dialogue clarity and dynamic sound effects.
- **News Mode:** Designed for clear vocal reproduction, ideal for news broadcasts or podcasts.

Use the 'EQ' button on the remote control to cycle through these modes.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your sound system.

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofers, and satellite speakers. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure adequate airflow around all components to prevent overheating. Do not block ventilation openings.
- **Environment:** Avoid exposing the system to extreme temperatures, humidity, direct sunlight, or dusty environments.
- **Power:** Disconnect the power cable from the wall outlet if the system will not be used for an extended period.

TROUBLESHOOTING

If you encounter issues with your GOVO GoSurround 1000 Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty.	Check power connections; try a different outlet.
No sound	Incorrect input source; volume too low; cables loose.	Select correct input mode; increase volume; check all audio cables.
Bluetooth not connecting	Soundbar not in pairing mode; device too far; interference.	Ensure soundbar is in BT mode; move device closer; restart both devices.
No surround sound	Satellite speakers not paired; audio source not 5.1/5.2.4.	Ensure satellite speakers are powered and paired; check audio source settings.
Remote control not working	Batteries depleted; obstruction; remote out of range.	Replace batteries; remove obstructions; ensure line of sight to soundbar.

SPECIFICATIONS

Detailed technical specifications for the GOVO GoSurround 1000 Pro:

- **Model Name:** GOSURROUND 1000 PRO
- **Brand:** GOVO
- **Speaker Maximum Output Power:** 800 Watts RMS
- **Number of Audio Channels:** 5.2.4
- **Subwoofer Speaker Diameter:** 6.5 Inches (Dual Subwoofers)
- **Connectivity Technology:** Bluetooth v5.3, HDMI ARC, Optical, AUX, USB, Wi-Fi
- **Audio Output Mode:** Surround (Dolby Atmos Enabled)
- **Frequency Response:** 44.1 KHz
- **Control Method:** Remote, Integrated Touch Controls
- **Maximum Bluetooth Range:** 10 Metres
- **EQ Modes:** Music, Movie, News
- **Item Dimensions (D x W x H):** 95D x 33.6W x 30.2H Centimeters
- **Item Weight:** 11300 Grams
- **Country of Origin:** India

The Heart of the Party

Boost your sound system with thunderous bass impact

with 6.5x2" Explosive Driver

Dual Subwoofer



Precision in Every Beat

Satellite speakers that bring out the finer details in music

with 2.25"x6 Drivers



 Dolby Atmos

The dual 6.5-inch subwoofers provide powerful bass.

WARRANTY AND SUPPORT

Warranty Information

The GOVO GoSurround 1000 Pro comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your purchase receipt for warranty claims.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact GOVO customer support:

- **Manufacturer:** DPAC VENTURES LLP
- **Contact Information:** DPAC Ventures LLP, Second Floor, No 1202, 100ft Road HAL 2nd Stage, Indiranagar, Domlur, Bengaluru, Karnataka, India, 560008
- Please refer to the warranty card included in your package for specific contact details or visit the official GOVO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GLNGCCQW>

More documents and user manuals: <https://manuals.plus/>