

## DurayLoly B0GLNX2GTZ

# DurayLoly Ergonomic Office Chair with Adjustable Arms and Footrest (Model B0GLNX2GTZ)

Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your DurayLoly Ergonomic Office Chair, Model B0GLNX2GTZ. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

## SAFETY INFORMATION

---

- Do not exceed the maximum weight capacity of 400 lbs (181 kg).
- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten if necessary.
- Keep hands and feet clear of moving parts during adjustment.
- Use the chair on a flat, stable surface to prevent tipping.
- Do not stand on the chair.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components are present. Refer to the assembly video for visual identification of parts.

- Chair Backrest
- Chair Seat with Armrests
- Chair Base (5-star metal base)
- PU Caster Wheels (5x)
- Gas Lift Cylinder
- Footrest Assembly

- Mounting Plate/Mechanism
- Hardware Pack (screws, washers, Allen wrench)

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your DurayLoly Ergonomic Office Chair. A detailed assembly video is provided for visual guidance.



**Video 1: Easy Assembly Chair** - This video demonstrates the step-by-step assembly process for the office chair, including attaching the base, casters, gas lift, and seat components.

### 1. Assemble the Chair Base:

Attach the five legs to the central hub of the chair base using the provided screws. Ensure they are securely fastened. Insert the five PU caster wheels into the ends of the legs until they click into place.

### 2. Install the Gas Lift:

Insert the gas lift cylinder into the central hole of the assembled chair base.

### 3. Attach the Mounting Plate to the Seat:

Align the mounting plate (mechanism) with the pre-drilled holes on the underside of the chair seat. Secure it with the appropriate screws. Ensure the 'FRONT' arrow on the mechanism points towards the front of the seat.

### 4. Attach Armrests to the Seat:

Secure the adjustable armrests to the sides of the seat using the designated screws.

### 5. Connect Seat to Base:

Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.

### 6. Attach Backrest:

Align the backrest with the mounting points on the seat and secure it with the remaining screws.

## OPERATING INSTRUCTIONS

---

Your DurayLoly Ergonomic Office Chair offers multiple adjustments for personalized comfort.



**Video 2: Big and Tall Office Chair with Adjustable Arms and Back** - This video demonstrates the various adjustable features of the chair, including armrests, backrest recline, and footrest operation.

- **Height Adjustment:** Locate the lever under the seat on the right side. Pull the lever up to raise the seat. While seated, pull the lever up to lower the seat. Release the lever to lock the height.
- **Backrest Recline (95°-155°):** Use the lever on the left side under the seat to adjust the backrest angle. Pull the lever up to recline, and push it down to lock the desired position.
- **Adjustable Armrests (5-level):** The armrests can be adjusted to five different positions. Lift the armrest slightly and move it to the desired angle. They can also fold down completely to allow for cross-legged sitting.
- **Retractable Footrest:** Pull the footrest out from under the seat. Flip the padded section up to extend it. Push it back under the seat when not in use.
- **360° Swivel and Mobility:** The chair features smooth-rolling PU caster wheels and a 360-degree swivel function for easy movement and rotation.
- **Side Storage Pockets:** Utilize the convenient pockets on the armrests for storing small items like remote

controls or books.

## Visual Guide to Features



**Figure 1: Product Dimensions.** This image illustrates the overall dimensions of the chair, including height, width, and depth, along with the maximum load capacity of 400 lbs.



Figure 2: Reclining Backrest. Shows the chair's backrest adjustable from 95° to 155°, allowing for various relaxation positions.

## Soft and comfortable seat cushion

Spring washer with pressure relief support



**Figure 3: Comfortable Seat Cushion.** Details the internal structure of the seat cushion, featuring high-density foam and spring support for even weight distribution.

# Chairs with various seating positions

One set can meet your needs for various sitting postures



Figure 4: Various Seating Positions. Illustrates the chair's versatility for different activities like leisure, entertainment, work, and even interacting with pets.

## 5-level adjustable armrests

You can sit however you want



Five claws



Level 3 upgrade air rod



360° Swivel casters



Figure 5: Base Components. Highlights the sturdy five-claw base, gas lift, and quiet 360° swivel casters.



**Figure 6: 5-Level Adjustable Armrests.** Demonstrates the range of motion for the armrests, allowing for customized comfort and cross-legged sitting.

## MAINTENANCE

---

- **Cleaning:** For the teddy fleece fabric, gently vacuum regularly to remove dust and debris. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner following the product instructions, testing on an inconspicuous area first.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they are tight. Re-tighten as needed to maintain stability and safety.
- **Caster Care:** Keep the caster wheels free of hair and debris to ensure smooth rolling.

## TROUBLESHOOTING

---

- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged or disengaged as required. Check if the gas lift cylinder is properly seated in the base and seat mechanism.
- **Chair is wobbly:** Verify that all assembly screws are securely tightened. Check the chair base for any damage or unevenness.
- **Casters not rolling smoothly:** Inspect caster wheels for trapped debris (hair, lint) and clean them. Ensure they are fully inserted into the chair base.

- **Backrest does not recline/lock:** Check the recline lever and mechanism for any obstructions. Ensure the lever is fully pushed or pulled to engage the lock.

## SPECIFICATIONS

---

<b>Brand</b>	DurayLoly
<b>Model</b>	B0GLNX2GTZ
<b>Material</b>	Teddy Fleece Fabric
<b>Product Dimensions (D x W x H)</b>	19.7"D x 24.4"W x 48.43"H
<b>Special Features</b>	Adjustable, Ergonomic, Wheels, Retractable Footrest, Adjustable Armrests, Spring Cushion
<b>Maximum Load Capacity</b>	400 lbs
<b>Assembly Required</b>	Yes

## WARRANTY AND SUPPORT

---

This product is covered by standard manufacturer warranties. For specific warranty details, claims, or technical support, please refer to the warranty card included in your package or contact DurayLoly customer service directly. Protection plans are available for extended coverage.