



[Manuals.plus](#) /

> [Aivituvin](#) /

> Aivituvin AIR7006 Mobile Chicken Coop Instruction Manual

Aivituvin AIR7006

Aivituvin AIR7006 Mobile Chicken Coop Instruction Manual

Model: AIR7006 | Brand: Aivituvin

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Aivituvin AIR7006 Mobile Chicken Coop. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. This coop is designed to provide a secure and comfortable habitat for 4-6 chickens, featuring a robust design and user-friendly access for daily care.

SAFETY INFORMATION

- Always ensure all parts are securely fastened during assembly and before placing animals inside.
- Regularly inspect the coop for any signs of wear, damage, or loose components. Repair or replace as necessary.
- Position the coop on a level, stable surface to prevent tipping.
- Be aware of potential predators in your area and consider additional reinforcement if needed, as the coop is designed for general predator resistance but may require extra measures depending on local wildlife.
- Keep children and pets away from the assembly area.
- Wear appropriate safety gear, such as gloves, during assembly to prevent injury.

ASSEMBLY INSTRUCTIONS

The Aivituvin AIR7006 chicken coop is designed for straightforward assembly with pre-drilled holes and labeled parts. It is recommended to have at least two people for assembly.

Before You Begin:

- Unpack all components and verify against the parts list (not provided in this document, refer to your packaging).
- Ensure you have the necessary tools, typically a screwdriver or cordless drill.
- Choose a clear, flat area for assembly.

Assembly Steps:

1. **Construct the Base Frame:** Begin by assembling the powder-coated all-steel frame components. Ensure all connections are tight and stable. This forms the foundation for the entire structure.
2. **Install the Wire Pen:** Attach the wire pen sections to the base frame. The wire pen extends activity space and supports the nesting box area.
3. **Assemble the Main Coop Structure:** Build the solid fir wood sections of the main coop, including the resting area and nesting box. Follow the labeled parts for correct orientation.
4. **Attach the Roof Components:** Secure the asphalt roof over the nesting and sleeping areas. Install the removable waterproof rain cover over the activity run.
5. **Integrate User-Friendly Features:** Install the dual-side removable pull-out tray, roosting bars, and sliding windows. Attach the built-in wheels to the frame for mobility.
6. **Install Doors and Ramps:** Secure all six access doors and the sliding door with ramp connecting the resting area to the run. Ensure all latches function correctly for predator resistance.

Humanization Chicken Coop with Wheels and Removable tray



Figure 1: Overview of the Aivituvin AIR7006 Chicken Coop, highlighting its six access areas and overall dimensions (85.6"L x 40.6"W x 48.2"H).

Aivituvin Mobile All-Around Iron Frame Chicken Coop!



Figure 2: Detail of the coop's sturdy metal frame and thick fir wood construction, emphasizing durability.

SETUP

Once assembled, select an appropriate location for your chicken coop. The built-in wheels allow for easy relocation across various terrains.

- **Location:** Choose a level, well-drained area that offers some shade during hot weather and protection from strong winds.
- **Mobility:** Utilize the built-in wheels to move the coop to your desired location. Ensure the coop is stable once positioned.
- **Initial Inspection:** Before introducing chickens, perform a final check to ensure all doors are secure, latches are functional, and there are no gaps that could allow predators access.



Figure 3: The removable pull-out tray and durable wheels facilitate easy setup and cleaning.

Specialized and Luxurious Chicken House



Figure 4: The strong metal iron frame and durable wheels allow for easy movement of the coop.

OPERATING INSTRUCTIONS

The Aivituvin AIR7006 coop offers various features for the daily care and comfort of your poultry.

- **Nesting Box:** The large 3-section nesting box provides a private and secure area for hens to lay eggs. Access the nesting box via its dedicated door for egg collection.
- **Resting Area:** The elevated resting area provides a safe and dry space for chickens to sleep, equipped with two round-edge roosting bars for comfort.
- **Activity Run:** The spacious ground-level run allows chickens to forage and exercise. The sliding door and ramp connect the resting area to the run, allowing you to secure poultry at night.
- **Ventilation:** Two sliding windows in the sleeping area can be adjusted to provide adequate airflow and natural light.
- **Access Doors:** Utilize the six strategically placed access doors for feeding, watering, and general interaction with your flock.



Figure 5: Chickens can easily access the elevated resting area and the spacious nesting box.



Figure 6: The nesting box features multiple compartments and secure access points.

MAINTENANCE

Regular maintenance ensures the longevity and hygiene of your chicken coop.

- **Cleaning the Tray:** The dual-side removable pull-out tray allows for effortless cleaning. Slide the tray out from either the front or back, empty waste, and clean thoroughly.
- **Bedding:** Replace bedding in the resting area and nesting box regularly to maintain hygiene. Ensure bedding does not obstruct the pull-out tray mechanism.
- **Roof Cover:** The waterproof rain cover should be cleaned periodically and inspected for tears or damage. Ensure it is properly secured to provide all-weather protection.
- **Wood and Frame Inspection:** Periodically check the fir wood for any signs of weathering, cracking, or splintering. Inspect the steel frame for rust or loose connections.
- **Door Latches:** Verify that all door latches are functioning correctly to prevent predator access.



Sliding Door

Figure 7: The waterproof rain cover provides essential all-weather protection for the activity run.

TROUBLESHOOTING

- **Difficulty Moving Coop:** Ensure the wheels are free of debris and rotate smoothly. Check that the ground surface is relatively even.
- **Tray Sticking During Cleaning:** If the pull-out tray is difficult to remove, check for excessive bedding or waste accumulation. Ensure the tray is properly aligned within its runners.
- **Predator Concerns:** While the coop features secure latches, local predators may require additional measures. Consider adding extra wire mesh or securing the coop to the ground if predator activity is high in your area.
- **Weather Damage:** In extreme weather conditions, inspect the wood and roof cover for damage. Apply wood sealant periodically to enhance weather resistance.
- **Wood Splitting:** Small splits in the wood can occur due to natural expansion and contraction. Monitor these; for larger splits affecting structural integrity, consider wood glue or reinforcement.

SPECIFICATIONS

| | |
|---------------------------------------|---|
| Brand | Aivituvin |
| Model Number | AIR7006 |
| Product Dimensions (L x W x H) | 85.6" x 40.6" x 48.2" |
| Material | Fir Wood, Powder-Coated Steel Frame |
| Color | Brown |
| Target Species | Chicken |
| Special Features | Mobile (with wheels), Removable Pull-Out Tray, Waterproof Rain Cover, 3-Section Nesting Box, 6 Access Doors, Predator-Resistant Latches |

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Aivituvin website. Keep your purchase receipt as proof of purchase.