

[Manuals.plus](#) /

> [Yanosaku](#) /

> Yanosaku 46" Rattan Shoe Cabinet (Model SR004-OAK) Instruction Manual

## Yanosaku SR004-OAK

# Yanosaku 46" Rattan Shoe Cabinet (Model SR004-OAK) Instruction Manual

Model: SR004-OAK

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your Yanosaku 46" Rattan Shoe Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

---

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly.
- Do not overtighten screws during assembly to avoid damaging the material.
- Use the provided anti-tip safety kit to secure the cabinet to a wall, preventing accidental tipping.
- Keep small parts away from children during assembly.
- Maximum weight capacity for the top surface is 80 lbs. Do not exceed this limit.



Image: Close-up of the anti-tip safety kit hardware, showing a metal bracket and screw for wall attachment.

## SETUP AND ASSEMBLY

Your Yanosaku Rattan Shoe Cabinet is designed for straightforward assembly. All necessary hardware, tools, and step-by-step instructions are included. Parts are clearly labeled to facilitate the process.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present and undamaged.
2. **Identify Parts:** Each part is labeled. Refer to the included assembly diagram to identify each piece.
3. **Follow Step-by-Step Instructions:** Assemble the cabinet by following the detailed, illustrated instructions provided in the separate assembly guide.
4. **Install Anti-Tip Kit:** Once assembled, secure the cabinet to a wall using the anti-tip safety kit. This is crucial for stability and safety, especially in households with children or pets.



Image: Diagram showing the overall dimensions of the Yanosaku Rattan Shoe Cabinet, including height (46.06"), width (35.55"), and depth (14.56"). Internal shelf and drawer dimensions are also indicated.

## OPERATING INSTRUCTIONS

The Yanosaku Rattan Shoe Cabinet is designed for efficient and organized storage of footwear and entryway essentials.

### Shoe Storage

- **Adjustable Shelves:** The cabinet features 4 adjustable wooden shelves. These can be repositioned to accommodate various shoe types, from sneakers to tall boots. Each shelf can hold multiple pairs of shoes.
- **Capacity:** The cabinet is designed to store over 25 pairs of shoes, depending on shoe size and type.
- **Open Lower Shelf:** Utilize the open lower shelf for frequently used shoes, providing easy access.



Image: The shoe cabinet with its doors open, revealing multiple adjustable shelves filled with various types of shoes. The image highlights the flexibility of the shelving system.




Image: Close-up view of the adjustable shelf mechanism inside the cabinet, showing the peg holes for height customization.

## Drawer Storage

- **Two Drawers:** The cabinet includes two storage drawers located at the top. These are ideal for storing small shoe care items, keys, mail, or other entryway essentials.
- **Intended Use:** The drawers are designed for small accessories and are not intended for heavy fabric storage.



### Entryway Essentials Storage Spot

Image: The top drawers of the shoe cabinet are shown open, containing small items like keys, a wallet, and other entryway essentials.

## Tabletop Use

- **Spacious Surface:** The large tabletop provides a convenient surface for decorative items, bags, or a secure drop zone for keys and mail due to its raised edge.
- **Weight Limit:** Do not place items exceeding 80 lbs on the tabletop.



### Spacious Countertop

Roomy top for stylish decor and everyday items

Image: Close-up of the cabinet's spacious tabletop, featuring a potted cactus and a diffuser, demonstrating its use for decor and small items.

## MAINTENANCE AND CARE

---

To ensure the longevity and appearance of your Yanosaku Rattan Shoe Cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the smooth, waterproof surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Rattan Care:** The natural rattan weave can be gently dusted with a soft brush or vacuum cleaner with a brush attachment. Avoid excessive moisture.
- **Spills:** Clean spills immediately to prevent staining, especially on the engineered wood surfaces.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or warping of the wood and rattan materials.



Image: Close-up of the natural rattan weave door panel, showcasing its texture and design.

## TROUBLESHOOTING

---

If you encounter issues with your shoe cabinet, refer to the following common problems and solutions:

- **Problem:** Parts are missing or damaged upon arrival.  
**Solution:** Do not proceed with assembly. Contact Yanosaku customer support immediately with your purchase details and a list of missing/damaged parts for assistance.
- **Problem:** Cabinet feels unstable or wobbly after assembly.  
**Solution:** Ensure all screws are securely tightened. Verify that the cabinet is placed on a level surface. Re-check the anti-tip safety kit installation to ensure it is properly anchored to the wall.
- **Problem:** Drawers do not slide smoothly.  
**Solution:** Check that the drawer slides are correctly installed and aligned. Ensure no debris is obstructing the tracks. A small amount of silicone lubricant can be applied to the slides if needed.
- **Problem:** Doors do not close properly or are misaligned.  
**Solution:** Check the hinge alignment and adjust if necessary. Ensure all hinge screws are tight.

## SPECIFICATIONS

---

Brand	Yanosaku
Model Number	SR004-OAK
Color	Walnut

<b>Material</b>	Engineered Wood
<b>Product Dimensions (D x W x H)</b>	14.56"D x 35.55"W x 46.06"H
<b>Item Weight</b>	76 Pounds
<b>Weight Capacity (Maximum)</b>	80 Pounds (Top Surface)
<b>Number of Shelves</b>	4 (Adjustable)
<b>Number of Drawers</b>	2
<b>Mounting Type</b>	Floor Mount (with Anti-Tipping feature)
<b>Required Assembly</b>	Yes

## WARRANTY INFORMATION

---

Specific warranty details for the Yanosaku 46" Rattan Shoe Cabinet are provided by the manufacturer. Please refer to the documentation included with your purchase or contact Yanosaku customer support for comprehensive warranty terms and conditions.

## CUSTOMER SUPPORT

---

For any questions, concerns, or assistance with your Yanosaku Rattan Shoe Cabinet, please contact the manufacturer or the seller directly. Have your model number (SR004-OAK) and purchase information ready when contacting support.