

[Manuals.plus](#) /

› [Urbanista](#) /

› Urbanista Austin 2 True Wireless Earbuds User Manual

Urbanista Austin 2

Urbanista Austin 2 True Wireless Earbuds User Manual

Model: Austin 2 (1040325)

INTRODUCTION

Thank you for choosing Urbanista Austin 2 True Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read these instructions carefully before use.

SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping, impacting, or disassembling the device.
- Keep out of reach of children and pets.
- Do not use the earbuds at high volume for extended periods to prevent hearing damage.
- Exercise caution when using earbuds in situations requiring awareness of your surroundings.

PACKAGE CONTENTS

- Urbanista Austin 2 True Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual

PRODUCT OVERVIEW

The Urbanista Austin 2 earbuds are designed for comfort and clear audio, featuring noise-reducing microphones and touch controls.



Image: Urbanista Austin 2 earbuds and charging case. The design incorporates noise-reducing microphones for enhanced call clarity.

The earbuds feature an ergonomic design for a secure and comfortable fit, suitable for extended wear.

ALL DAY COMFORT



ERGONOMICALLY SHAPED TO FIT YOUR EAR.

Image: A hand holding the Urbanista Austin 2 charging case with the earbuds nestled inside, illustrating their compact and comfortable design.

SETUP

1. Charging the Earbuds and Case

- Place the earbuds into the charging case. Ensure they are correctly seated.
- Connect the USB-C charging cable to the charging port on the case and to a power source.
- The LED indicator on the case will show charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.

2. Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED on the earbuds.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Urbanista Austin 2" from the list of detected devices.

4. Once connected, the earbud LEDs will stop flashing.

3. Multipoint Connection

The Austin 2 supports multipoint connection, allowing simultaneous connection to two devices.

1. Connect the earbuds to your first device as described in "Initial Pairing."
2. Disable Bluetooth on the first device. The earbuds will re-enter pairing mode.
3. Connect the earbuds to your second device.
4. Re-enable Bluetooth on the first device. The earbuds should automatically connect to both devices.




Image: A person wearing an Urbanista Austin 2 earbud, symbolizing the seamless Bluetooth 6.0 and multipoint connection capabilities.

OPERATING INSTRUCTIONS

Touch Controls

The Austin 2 earbuds feature intuitive touch controls on the stem of each earbud.

Action	Function
Tap once (Left/Right)	Play/Pause Music, Answer/End Call
Tap twice (Right)	Next Track
Tap twice (Left)	Previous Track
Tap three times (Left/Right)	Activate Voice Assistant
Press and hold (Left/Right)	Reject Call

Sound Modes (EQ Presets)

The Austin 2 offers three equalizer presets to optimize your listening experience:

- **Default:** Balanced sound profile.
- **Bass Boost:** Enhanced low frequencies for a richer bass.
- **Voice:** Optimized for clear vocals and speech.

To switch between sound modes, refer to the specific instructions in the full product manual or the Urbanista app (if available).

PRESET SOUND MODES



3 EQ PRESETS
VOICE , BASS BOOST AND DEFAULT

Image: Two Urbanista Austin 2 earbuds, highlighting the feature of three distinct EQ presets for customized sound.

MAINTENANCE

Cleaning

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure charging contacts are clean and free of debris.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store in a cool, dry place away from direct sunlight.

Water Resistance

The Urbanista Austin 2 earbuds are water-resistant. This means they are protected against splashes and sweat, making them suitable for workouts and light rain. They are not designed for submersion in water or

exposure to pressurized water.

TROUBLESHOOTING

Issue	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Urbanista Austin 2" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back in the case, close, then reopen. Check earbud battery level.
Low volume	Adjust volume on both your device and the earbuds. Ensure earbuds are clean and properly seated in your ears.
Charging issues	Check charging cable and power adapter. Ensure charging contacts on earbuds and case are clean.

SPECIFICATIONS

25 HOURS TOTAL PLAYTIME



**5 HOURS
SINGLE PLAYTIME**

**20 HOURS
IN THE CASE**



Image: The Urbanista Austin 2 charging case with earbuds, illustrating the impressive 25 hours of total playtime.

- **Model Name:** Austin 2
- **Model Number:** 1040325
- **Connectivity:** Bluetooth 6.0 Wireless
- **Ear Placement:** In Ear
- **Noise Control:** Passive Noise Cancellation
- **Impedance:** 32 Ohms
- **Frequency Response:** 20000 Hz
- **Control Type:** Touch Control
- **Battery Life:** Up to 5 hours (earbuds), 20 hours (with charging case) - Total 25 hours
- **Additional Features:** Microphone Included, Multipoint Pairing, Water Resistant
- **Material:** Plastic

WARRANTY AND SUPPORT

Urbanista products are covered by a limited warranty. For detailed warranty information, product support, or to register your product, please visit the official Urbanista website or contact their customer service. Keep your proof of purchase for warranty claims.