MINISO Miniso-stitch-nl-001

MINISO Disney Stitch Minimalist Night Light User Manual

Model: Miniso-stitch-nl-001

1. Introduction

Thank you for purchasing the MINISO Disney Stitch Minimalist Night Light. This product is designed to provide gentle, ambient lighting and serve as a decorative item. Please read this manual carefully before use to ensure proper operation and maintenance.

2. Important Safety Information

- Keep the device away from water and high humidity.
- Do not expose to direct sunlight or extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- Keep out of reach of small children to prevent choking hazards from small parts.
- Use only the recommended power source (if applicable).

3. Package Contents

Verify that all items are present in the package:

- MINISO Disney Stitch Minimalist Night Light (Mushroom-shaped variant)
- User Manual

4. Setup

4.1 Unboxing

1. Carefully remove the night light from its packaging.
2. Inspect the device for any signs of damage. If damaged, do not use and contact customer support.

4.2 Power Source (Battery Installation)

This night light operates on batteries (not included). Follow these steps to install batteries:

1. Locate the battery compartment cover on the bottom of the night light.
2. Open the cover.
3. Insert the required batteries (e.g., 3 x AAA, specific type not provided in product data, please refer to product packaging for exact type) ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

4.3 Placement

Place the night light on a stable, flat surface in your desired location. Ensure it is not near heat sources or in areas where it could be easily knocked over.



Image: The MINISO Disney Stitch Minimalist Night Light, featuring a mushroom-shaped lamp with a sitting Stitch figure, placed on a surface, ready for use.

5. Operating Instructions

5.1 Turning On/Off

The night light features a simple push-button switch for operation.

1. To turn on the night light, press the button located on the base of the unit.
2. To turn off the night light, press the button again.



Image: A detailed view highlighting the simple push-button switch on the base of the night light, indicating ease of operation.

5.2 Light Function

The night light provides a soft, ambient glow, ideal for creating a calming atmosphere in bedrooms or other spaces. It is designed as a sleep companion, offering gentle illumination without harsh brightness.



Image: The MINISO Disney Stitch Minimalist Night Light illuminated, casting a soft, warm glow, suitable for nighttime use.

6. Maintenance

6.1 Cleaning

To clean the night light:

- Ensure the device is turned off and disconnected from any power source (if applicable).
- Wipe the surface with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the plastic and acrylic materials.
- Avoid getting moisture into any openings.

6.2 Storage

When not in use for extended periods, store the night light in a cool, dry place. If using batteries, remove them before

storage to prevent leakage.

7. Troubleshooting

Problem	Possible Cause	Solution
Night light does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with new batteries if necessary.
Light is dim.	Batteries are low.	Replace batteries.
Switch is unresponsive.	Internal malfunction.	Contact customer support. Do not attempt to repair.

8. Specifications

Feature	Detail
Model Number	Miniso-stitch-nl-001
Product Dimensions (D x W x H)	0.01"D x 0.01"W x 0.01"H (Note: These dimensions appear to be placeholder values. Please refer to product packaging for accurate measurements.)
Approximate Dimensions (Mushroom variant)	4.9 inches (Height) x 3.2 inches (Width) x 2.2 inches (Stitch figure height)
Lamp Type	Night Light
Color	Minimalist (Blue/Mint tones)
Material Type	ABS Plastic, Acrylic, Plastic
Switch Type	Push Button
Manufacturer	MINISO



Image: Visual representation of the approximate dimensions for the mushroom-shaped night light variant, showing height and width.

9. Warranty and Support

For warranty information or customer support, please refer to the contact details provided on the product packaging or contact the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.
Manufacturer: MINISO

© 2024 MINISO. All rights reserved. Disney elements © Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question