

[Manuals.plus](#) /

> [Brighttown](#) /

> Brighttown Battery Operated Wall Sconces (Model B0GMSKQ75J) Instruction Manual

Brighttown B0GMSKQ75J

Brighttown Battery Operated Wall Sconces Instruction Manual

Model: B0GMSKQ75J

INTRODUCTION

This manual provides instructions for the Brighttown Battery Operated Wall Sconces. These wireless, rechargeable wall lights feature dimmable magnetic bulbs and remote control, designed for versatile indoor lighting and decor. Please read these instructions carefully before installation and use.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation.

- 2 x Metal Lamp Holders
- 2 x White Fabric Shades
- 2 x E26 USB Rechargeable LED Light Bulbs
- 2 x Type-C USB Charging Cables
- 1 x Remote Control
- 1 x Installation Accessories Kit
- 1 x User Manual



Image: Contents of the Brighttown Wall Sconces package, including two sconce units, a remote control, and charging cables.

SETUP AND INSTALLATION

The Brighttown wall sconces are designed for easy, wire-free installation. No electrical wiring is required.

1. **Assemble the Sconce:** Attach the fabric lampshade to the metal lamp holder. Secure it with the provided ring.

2. **Mount the Base:** Use the included installation accessories to securely mount the metal lamp base to your desired wall location. Ensure the mounting surface is suitable.
3. **Insert the Bulb:** The E26 USB rechargeable LED bulb features a magnetic base. Simply place the bulb into the socket of the assembled sconce. The magnetic connection will hold it in place.
4. **Charge the Bulbs:** Before first use, fully charge the LED bulbs using the provided Type-C USB charging cables. A green light indicates a full charge.

Your browser does not support the video tag.

Video: This video demonstrates the installation process for the Brightown Battery Operated Wall Sconce, showing how to assemble the components and mount the sconce to a wall.



Image: Detailed view of the sconce dimensions and key components, including the magnetic bulb, brushed metal finish, and fabric lampshade.

E26 Detachable Charging with Magnetic Base



- No need to screw and unscrew a bulb multiple times
- Our magnetic design makes charging and replacing bulbs faster and easier than ever



Image: Illustration of the E26 detachable magnetic base, highlighting the ease of removing the bulb for charging without unscrewing.

OPERATING INSTRUCTIONS

The wall sconces are controlled using the included remote control or the touch control on the bulb.

Remote Control Functions:

- **Power On/Off:** Press the power button to turn the lights on or off.
- **Brightness Adjustment:** Use the brightness buttons (up/down arrows) to select from 4 brightness levels (15%, 30%, 60%, 100%).
- **Color Temperature:** Select between 3000K (Warm White), 4000K (Natural White), and 6000K (Cool White) using the dedicated buttons.
- **RGB Lighting Modes:** Choose from 10 vibrant RGB lighting modes for various ambient effects.
- **Timer Function:** Activate the smart timer mode for automatic shutoff (e.g., 30 minutes, 60 minutes).
- **Memory Function:** The lights retain your last brightness and color settings when turned off and on.

Touch Control (on bulb):

- A simple touch on the bulb's control area can cycle through basic light settings or turn the light on/off. Refer to the bulb's specific instructions for detailed touch control functionality.

Your browser does not support the video tag.

Video: This video demonstrates the various color and dimming options available with the remote control for the Brightown Wall Sconces.




Image: Visual representation of the dimmable feature, showing the sconce light at 15%, 30%, 60%, and 100% brightness levels.

Color Temperatures Adjustable



Image: Displays the adjustable color temperatures (Warm, Natural, Cool White) and their appearance in various indoor environments.

FEATURES

- **Wireless and Rechargeable:** Equipped with E26 USB rechargeable LED bulbs, offering complete wire-free operation.
- **Dimmable and Multi-Color:** Features 3000K-6000K color temperature adjustment, 4 brightness levels (15%-100%), and 10 RGB lighting modes.
- **Timer Function:** Includes a smart timer for automatic shutoff, conserving battery life.
- **Memory Function:** Retains customized brightness and color settings after being turned off.
- **Magnetic Design:** Detachable magnetic base allows for easy removal of bulbs for charging and replacement.
- **Remote Control:** Conveniently adjust settings from a distance.

Battery Operated Wall Sconce



10 Colors
Dimming



Magnetic
Head



3 Color
Temperatures



Timing
function



Image: Overview of the sconce features, including color options, magnetic attachment, color temperature, and timer, shown in a bedroom setting.

RGB Mood Light for Every Scene



Image: Demonstrates the RGB mood lighting capability of the sconces, showing different colors illuminating a living room.

MAINTENANCE

- **Charging:** The LED bulbs are USB rechargeable. When the battery is low, remove the bulb from the magnetic base and connect it to a Type-C USB charging cable. A green light indicates a full charge. Charging time is approximately 3 hours for up to 20 hours of working time, depending on brightness and color settings.
- **Cleaning:** Wipe the metal lamp holders and fabric shades with a soft, dry cloth. Do not use abrasive cleaners or liquids that could damage the finish or electrical components.
- **Bulb Replacement:** If a bulb needs replacement, ensure it is an E26 USB rechargeable LED bulb compatible with the magnetic base.

USB Rechargeable Wall Sconce



Charging Time: 3 Hours



Green Light When Full Charged

Working Time: 20 Hours



Touch Control

Image: Details on the USB rechargeable bulb, including charging indicators, charging duration, and estimated working time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Bulb is not charged. Remote control battery is dead. Bulb not properly seated in magnetic base.	Charge the bulb fully. Replace remote control battery. Ensure bulb is securely attached to the magnetic base.
Remote control not working.	Remote battery is dead. Obstruction between remote and bulb. Remote is too far from the bulb.	Replace remote battery. Remove any obstructions. Move closer to the bulb (Infrared connectivity).
Light flickers or dims unexpectedly.	Low battery.	Recharge the bulb.

SPECIFICATIONS

- **Brand:** Brightown
- **Model:** B0GMSKQ75J
- **Color:** Gold (Fixture), White (Shade)
- **Material:** Metal (Fixture), Fabric (Shade)
- **Light Source:** LED
- **Bulb Base:** E26 (Magnetic)
- **Number of Light Sources:** 2
- **Brightness:** Up to 300 Lumens
- **Color Temperature:** 3000K (Warm White), 4000K (Natural White), 6000K (Cool White)
- **Control Method:** Remote Control, Touch Control
- **Power Source:** Battery Powered (USB Rechargeable)
- **Indoor/Outdoor Usage:** Indoor
- **Item Dimensions (L x W x H):** 6"L x 4"W x 24"H
- **Water Resistance Level:** Not Water Resistant
- **Connectivity Protocol:** Infrared

WARRANTY AND SUPPORT

Brightown prioritizes product quality and customer satisfaction. These wall sconces are covered by a **5-year warranty** (60 months) for long-term protection.

For any product issues, please contact our professional support team via Amazon message. We guarantee a 24-hour response and will offer troubleshooting or replacement solutions as needed.

