

[Manuals.plus](#) /

› [LITTLE TREE](#) /

› LITTLE TREE Solid Wood TV Stand RCY114 Instruction Manual

LITTLE TREE RCY114

LITTLE TREE Solid Wood TV Stand Instruction Manual

Model: RCY114

1. SAFETY INFORMATION

Please read and understand all safety information before assembly and use. Failure to follow these instructions may result in injury or product damage.

- **Weight Limit:** Do not load more than 220 lb (100 kg) on the tabletop.
- **Sharp Edges:** Be cautious of sharp edges during assembly and handling.
- **Assembly:** Always follow the assembly instructions carefully to prevent injury and ensure stability.
- **Stability:** Ensure the TV stand is placed on a flat, stable surface.
- **Children:** Keep small parts and packaging materials away from children.

2. INCLUDED COMPONENTS

Before beginning assembly, verify that all parts and hardware are present. If any components are missing or damaged, please contact customer support.

Package Contents:

- 1 x LITTLE TREE Solid Wood TV Stand (disassembled components)
- Assembly Hardware (screws, dowels, etc.)
- Assembly Tool (e.g., Allen wrench)

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your TV stand. It is recommended to assemble on a soft, clean surface to prevent scratches.

1. Step 1: Attach Legs

Attach the legs to the main tabletop using the provided screws. Ensure they are aligned correctly.

2. Step 2: Tighten Screws

Using the included tool, tighten all screws securely. Do not overtighten.

3. Step 3: Insert Dowels

Insert dowels into the pre-drilled holes on the connecting panels.

4. Step 4: Align and Secure Panels

Align the panels with the dowels and secure them with bolts. Repeat this process for all remaining components.

5. Step 5: Final Check

Once all components are assembled, gently shake the stand to ensure it is stable. Tighten any loose connections if necessary.



Image 1: Dimensions diagram for the TV stand, showing measurements of 62.99 inches width, 15.75 inches depth, and 23.62 inches height.



Image 2: Detail showing the 1.57-inch thickened design of the solid wood top surface, highlighting its robust construction.



Image 3: Close-up view of the natural grain and texture of the solid fir wood used in the TV stand construction.

4. OPERATING INSTRUCTIONS

The LITTLE TREE Solid Wood TV Stand is designed to support televisions up to 65 inches and provide storage for media devices and accessories.

- **Placement:** Position the TV stand on a level, stable floor surface.
- **TV Placement:** Carefully place your television on the center of the top surface. Ensure the TV base fits within the stand's dimensions.
- **Storage:** Utilize the two-tiered design for organizing media players, gaming consoles, remote controls, and other entertainment accessories.
- **Weight Distribution:** Distribute weight evenly across the shelves and tabletop to maintain stability.



Image 4: The TV stand in a living room setting, supporting a television and displaying decorative items on its two tiers.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and appearance of the Solid Wood TV Stand. This video highlights the solid wood construction and thickened structure, and shows the stand accommodating a 55 to 65-inch TV.

5. MAINTENANCE

Proper care will ensure the longevity and appearance of your solid wood TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that can damage the wood finish.
- **Spills:** Clean spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or cracking of the wood.
- **Humidity:** Maintain a consistent humidity level in the room to prevent wood from expanding or contracting.
- **Tighten Hardware:** Periodically check and tighten all screws and bolts to ensure the stand remains stable.

6. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbling:** Ensure the stand is on a level surface. Check all assembly hardware and tighten any loose screws or bolts.
- **Scratches:** Minor scratches can sometimes be touched up with a wood repair marker or furniture polish matching the walnut finish.
- **Damaged Parts:** If a part is broken or severely damaged, do not attempt to repair it yourself. Contact customer support for replacement parts.

7. SPECIFICATIONS

Brand	LITTLE TREE
Model Number	RCY114
Color	Walnut
Material Type	Solid Fir Wood
Item Dimensions (L x W x H)	62.99" x 15.75" x 23.62" (160 cm x 40 cm x 60 cm)
Item Weight	33.03 Pounds (14.98 kg)
Maximum Tabletop Load Capacity	220 lb (100 kg)
Recommended TV Size	Up to 65 inches
Assembly Required	Yes

8. WARRANTY AND SUPPORT

For warranty information, replacement parts, or any questions regarding your LITTLE TREE Solid Wood TV Stand, please contact the manufacturer or your retailer directly.

Keep your purchase receipt and model number (RCY114) handy for faster service.

