

Decofy JPSY03-DC-BG07-102

Decofy Farmhouse Nightstand with Charging Station

MODEL: JPSY03-DC-BG07-102

[Safety Information](#) [Package](#)

[Contents](#) [Assembly](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or product damage.

- Do not place items exceeding the maximum weight recommendation of **100 pounds (45.4 kg)** on the tabletop.
- The open shelf has a maximum weight capacity of **12 pounds (5.4 kg)**.
- The drawer has a maximum weight capacity of **20 pounds (9.1 kg)**.
- Ensure the nightstand is properly assembled and all connections are secure to maintain stability and prevent tipping or collapse.
- Keep small parts and packaging materials away from children during assembly.
- Use only the provided hardware and tools, or a standard screwdriver. Do not use power drills as they may damage the engineered wood.
- Place the nightstand on a flat, stable surface.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Nightstand panels (top, side, back, bottom, drawer components)
- Hardware kit (screws, hex bolts, dowels, drawer slides, handle)
- Built-in Charging Station (with 2 AC outlets, 1 USB port, 1 Type-C port, and 4.9 ft power cord)
- Assembly Guide

3. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward and typically takes about 20 minutes. A screwdriver is the recommended tool. Avoid using power tools to prevent damage.

Preparation:

- Clear a spacious, clean area for assembly.
- Unpack all components and lay them out, checking against the parts list in the included Assembly Guide.
- Identify all hardware.

Step-by-Step Assembly:

1. **Attach Legs:** Secure the legs to the bottom panel using the provided screws. Tighten them with the included tool or a screwdriver.
2. **Install Tabletop Support Brackets:** Insert the tabletop support brackets into the pre-drilled holes on the side panels.
3. **Secure Legs to Brackets:** Attach the legs to the support brackets using the hex bolts. Ensure all connections are firm.
4. **Assemble Drawer:** Follow the specific instructions in the Assembly Guide to construct the drawer, including attaching the handle and drawer slides.
5. **Integrate Charging Station:** Carefully place the charging station into its designated cutout on the tabletop. Secure it with the provided screws.
6. **Final Check:** Once all parts are assembled, gently flip the nightstand upright. Double-check all screws and connections for tightness.

Dual Zone Storage —

Effortless Hide and Show



Image: Nightstand dimensions and weight limits. Top: 100 lbs (45.4 kg), Open Shelf: 12 lbs (5.4 kg), Drawer: 20 lbs (9.1 kg).

Video: Official Decofy video demonstrating bedside table solutions, including assembly and features.

4. OPERATING INSTRUCTIONS (CHARGING STATION)

The Decofy Farmhouse Nightstand features a convenient built-in charging station to keep your devices powered and your bedside tidy.

Using the Charging Station:

1. **Power Connection:** Plug the 4.9 ft power cord from the charging station into a standard 125V AC wall outlet.
2. **AC Outlets:** Use the two standard AC outlets (125V-12A) for devices such as lamps, alarm clocks, or other small electronics.
3. **USB Ports:** Connect your USB-compatible devices (e.g., smartphones, tablets, wireless earbuds) to the 5V-2A USB port for charging.
4. **Type-C Port:** Connect your Type-C compatible devices to the 5V-2A Type-C port for charging.

Ensure devices are compatible with the specified voltage and amperage to prevent damage.

Built-in Charging Station



2 AC Outlets
125V-12A



1 USB Ports
5V-2A



1 Type-C Port
5V-2A



Power Cord
4.9 Feet

Image: Detail of the built-in charging station with 2 AC outlets, 1 USB port, and 1 Type-C port.

5. MAINTENANCE

Proper care will help maintain the appearance and longevity of your Decofy nightstand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the painted finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.

- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent damage to the tabletop.

6. TROUBLESHOOTING

If you encounter issues with your nightstand, refer to the following common solutions:

Loose or Wobbly Nightstand:

- Check all assembly screws and bolts. Tighten any that are loose.
- Ensure the nightstand is on a level surface. Adjust if necessary.

Drawer Not Sliding Smoothly:

- Verify that the drawer slides are correctly installed and aligned.
- Check for any obstructions in the drawer tracks.
- Ensure the drawer is not overloaded, exceeding its 20 lb (9.1 kg) weight limit.

Charging Station Not Working:

- Confirm the nightstand's power cord is securely plugged into a functional wall outlet.
- Test the wall outlet with another device to ensure it has power.
- Ensure your device's charging cable is properly connected to the charging station's ports.
- Verify that your device is compatible with the charging station's output (5V-2A for USB/Type-C, 125V-12A for AC outlets).

If problems persist, contact Decofy customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Decofy
Model Name	JPSY03-DC-BG07-102
Product Dimensions (D x W x H)	15.7"D x 17.7"W x 23.6"H (40cm D x 45cm W x 60cm H)
Item Weight	38.4 pounds (17.4 kg)
Maximum Weight Recommendation (Top)	100 pounds (45.4 kg)
Maximum Weight Recommendation (Open Shelf)	12 pounds (5.4 kg)
Maximum Weight Recommendation (Drawer)	20 pounds (9.1 kg)
Frame Material	Engineered Wood

Color	Pure White + Walnut
Charging Station	2 AC Outlets (125V-12A), 1 USB Port (5V-2A), 1 Type-C Port (5V-2A)
Power Cord Length	4.9 feet
Number of Drawers	1
Number of Items	2 (Set)
Tools Recommended For Assembly	Screwdriver

8. WARRANTY & SUPPORT

Decofy products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the documentation included with your purchase or visit the official Decofy website.

If you have any questions, require replacement parts, or need assistance with assembly or operation, please contact Decofy customer support. Our team is available to help ensure your satisfaction.

Contact Information: Please refer to your purchase receipt or the Decofy brand store for the most current customer support contact details.

© 2026 Decofy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question