

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› Zebronics Blanc 100 Rechargeable Wireless Mouse User Manual

ZEBRONICS Blanc 100

Zebronics Blanc 100 Rechargeable Wireless Mouse User Manual

Model: Blanc 100

INTRODUCTION

The Zebronics Blanc 100 is a versatile rechargeable wireless mouse designed for seamless multi-device use. It offers dual-mode connectivity, adjustable sensitivity, and an ergonomic design for comfortable operation. This manual provides detailed instructions for setting up, operating, and maintaining your mouse.

PACKAGE CONTENTS

- Mouse - 1 Unit
- USB Nano Receiver - 1 Unit
- Charging cable - 1 Unit
- Quick user Guide - 1 Unit

PRODUCT FEATURES

- **Dual Mode Connectivity:** Supports 2.4GHz wireless with USB nano receiver and Bluetooth mode for easy connection to multiple devices.
- **Adjustable DPI Control:** Offers 3-level DPI switch (1000 / 1600 / 2400) with an indicator for precise cursor control.
- **Rechargeable Battery:** Built-in rechargeable battery with Type-C charging support.
- **6-Button Functionality:** Includes left, right, scroll, and additional controls for enhanced productivity.
- **Silent Operation:** Designed for quiet clicks, ensuring a distraction-free work environment.
- **Ergonomic Design:** Lightweight and comfortable for extended use.


SETUP GUIDE

1. Charging the Mouse

Before first use, ensure the mouse is fully charged. Connect the provided Type-C charging cable to the mouse's charging port and to a USB power source (e.g., computer USB port, USB wall adapter).

Built-in Rechargeable Battery

Provides long-lasting wireless use



Type C Charging

Enables fast and convenient recharging



Image: The mouse features a built-in rechargeable battery and a convenient Type-C charging port for quick and easy power replenishment.

2. Connecting via 2.4GHz Wireless (USB Nano Receiver)

1. Locate the USB Nano Receiver, usually stored in a compartment on the underside of the mouse.
2. Plug the USB Nano Receiver into an available USB port on your computer.
3. Turn on the mouse using the On/Off switch located on the bottom.
4. Switch the mode selector on the bottom of the mouse to the 2.4GHz position (indicated by a symbol or text).
5. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use.

Dual Mode 2.4GHz + BT

Dual mode connectivity with 2.4GHz wireless and Bluetooth for seamless multi-device use



Image: Demonstrates the dual mode connectivity, showing the mouse connected to a laptop via 2.4GHz wireless.

3. Connecting via Bluetooth

1. Turn on the mouse using the On/Off switch.
2. Switch the mode selector on the bottom of the mouse to the Bluetooth position (indicated by a BT symbol or text).
3. On your device (computer, tablet, smartphone), go to Bluetooth settings.
4. Search for new devices. The mouse should appear as "ZEB-BLANC 100" or similar.
5. Select the mouse to pair. Once paired, the mouse is ready for use.


OPERATING INSTRUCTIONS

1. Power On/Off and Mode Switching

The mouse features an On/Off switch and a mode switch on its underside. Use the On/Off switch to conserve battery when not in use. The mode switch allows you to toggle between 2.4GHz wireless and Bluetooth connectivity.

Silent Operation

Quiet clicks for distraction-free work



High Precision

Smooth and accurate cursor control



Image: Location of the Mode Switch and On/Off Switch on the mouse's underside, and the layout of the 6 buttons.

2. DPI Adjustment

The mouse offers three DPI levels (1000 / 1600 / 2400) for adjusting cursor sensitivity. Press the DPI button, located on the top of the mouse, to cycle through the settings. An indicator light will briefly show the current DPI level.

Upto 2400 3 Level DPI

3-level DPI adjustment
up to 2400 DPI for precise
tracking and control



Image: The DPI switch indicator light, which helps identify the current sensitivity setting.

3. Button Functions

The mouse is equipped with 6 responsive buttons:

- **Left Click:** Primary function.
- **Right Click:** Secondary function, typically opens context menus.
- **Scroll Wheel:** Scrolls content vertically. Can also be pressed for middle-click functionality.
- **DPI Button:** Adjusts cursor sensitivity (1000/1600/2400 DPI).
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Backward Button:** Navigates backward in web browsers or file explorers.



Mode & Power Switch

6 responsive buttons with a mode and power switch for enhanced control

On / Off Switch

6 Buttons

Right

Scroll Wheel

Left

DPI

Forward

Backward

Image: The mouse in use, demonstrating its silent click and precise tracking capabilities.

MAINTENANCE

Cleaning

To clean your mouse, gently wipe its surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. Ensure no liquid enters the mouse.

Storage

When not in use for extended periods, turn off the mouse to conserve battery. Store it in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- Mouse not responding:

- Ensure the mouse is turned on.
- Check the battery level and charge if necessary.
- Verify the correct connection mode (2.4GHz or Bluetooth) is selected.
- For 2.4GHz, ensure the USB Nano Receiver is securely plugged into a working USB port.
- For Bluetooth, ensure Bluetooth is enabled on your device and the mouse is properly paired. Try re-pairing if issues persist.

• **Intermittent connection:**

- Move the mouse closer to the receiver or Bluetooth device.
- Avoid using the mouse on highly reflective or transparent surfaces.
- Minimize interference from other wireless devices.

• **Cursor movement is erratic:**

- Clean the optical sensor on the underside of the mouse.
- Try using the mouse on a different surface or a mouse pad.
- Adjust the DPI setting to a lower value if movement is too fast.

SPECIFICATIONS

Brand	ZEBRONICS
Model Name	Blanc 100
Connectivity Technology	Bluetooth, 2.4GHz USB
Movement Detection Technology	Optical
DPI Levels	1000 / 1600 / 2400
Button Quantity	6
Special Features	Silent Clicks, Ergonomic Design, Adjustable DPI, Rechargeable
Compatible Devices	Laptop, Personal Computer, Smartphone, Tablet
Minimum OS Support	Mac OS 10.15+, Windows 10, Windows 11
Item Weight	79 Grams
Item Dimensions (L x W)	11.8L x 6.2W Centimeters
Country of Origin	China

WARRANTY AND SUPPORT

Warranty Information

This Zebronics Blanc 100 Wireless Mouse comes with a**1-year carry-in service center warranty** from the date of purchase. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal use conditions.

Customer Support

For any technical assistance, troubleshooting, or warranty-related queries, please contact Zebronics customer support. Refer to the official Zebronics website or the contact information provided in your Quick User Guide for the most up-to-date support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question