

[Manuals.plus](#) /

› [NEWBULIG](#) /

› NEWBULIG Mini Fridge with Freezer 3.2 Cu.Ft (Model NW-BX-SM01-SR) User Manual

NEWBULIG NW-BX-SM01-SR

NEWBULIG Mini Fridge with Freezer 3.2 Cu.Ft (Model NW-BX-SM01-SR) User Manual

INTRODUCTION

Thank you for choosing the NEWBULIG Mini Fridge with Freezer. This appliance is designed for convenient food and beverage storage in compact spaces such as offices, dorms, and bedrooms. It features a dual-door design with separate freezer and refrigerator compartments, an adjustable thermostat, and energy-efficient operation. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety.

This compact mini fridge measures approximately 17.7 inches (D) x 18.7 inches (W) x 34 inches (H), offering a total capacity of 3.2 cubic feet. It includes a 0.75 Cu.Ft upper freezer, a 1.85 Cu.Ft main refrigerator compartment, and a 0.6 Cu.Ft dedicated beverage zone.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance must be properly installed and located in accordance with the Installation Instructions before it is used.
- Do not allow children to climb, stand, or hang on the shelves in the refrigerator. They could damage the refrigerator and seriously injure themselves.
- Do not touch the cold surfaces in the freezer compartment when hands are damp or wet. Skin may stick to these extremely cold surfaces.
- Unplug the refrigerator before cleaning or making any repairs.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended

by the manufacturer.

- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present and in good condition:

- 1 x NEWBULIG 3.2 Cubic Feet Two Door Mini Fridge with Freezer
- 1 x Crisper Drawer
- 2 x Removable Shelves
- 1 x User Manual

SETUP

1. Placement

Place the refrigerator on a flat, solid surface strong enough to support the unit when fully loaded. Allow at least 4 inches of space between the back and sides of the refrigerator and any adjacent walls to ensure proper air circulation. Avoid direct sunlight or heat sources.

3.2 Cu.Ft Mini Fridge and Freezer



No Space Limits
Cool Everywhere



Image: Front view of the mini fridge with dimensions (17.7" W x 18.7" D x 34.0" H).



Image: The mini fridge placed in a bedroom, demonstrating its compact size.

2. Leveling

Ensure the refrigerator is level by adjusting the leveling feet at the bottom. A level appliance operates more efficiently and prevents door alignment issues.

3. Power Connection

Plug the refrigerator into a dedicated 110-volt grounded electrical outlet. Do not use extension cords or adapter plugs.

4. Initial Cooling

After plugging in, allow the refrigerator to cool for at least 2-4 hours before placing food inside. This allows the internal temperature to stabilize.

OPERATING INSTRUCTIONS

1. Temperature Control

The refrigerator features an adjustable thermostat with 7 settings. Turn the dial inside the refrigerator compartment to select your desired temperature. Setting '1' is the warmest, and '7' is the coldest. Adjust the setting based on the amount of food stored and ambient room temperature.

Compact Size Max Capacity



Image: Close-up of the temperature control dial and a table showing corresponding refrigeration and microfreezing temperatures for settings 1-7.

Temperature Settings Guide


Mode	1	2	3	4	5	6	7
Refrigeration	44°F	41°F	37°F	35°F	32°F	27°F	25°F
Microfreezing	40°F	38°F	34°F	32°F	29°F	25°F	23°F

2. Storage Zones

The dual-door design provides distinct storage areas:

- **Upper Freezer (0.75 Cu.Ft):** Ideal for frozen goods like ice cream, frozen meals, and ice cubes.
- **Main Refrigerator Compartment (1.85 Cu.Ft):** Suitable for fresh foods, dairy products, and leftovers. Includes removable shelves and a crisper drawer for fruits and vegetables.

- **Beverage Zone (0.6 Cu.Ft):** Located on the door, designed to hold cans and bottles for easy access.



Double Sliver

17.7'D x 18.7'W x 34.0'H

Image: The interior of the mini fridge with labels indicating the 0.75 Cu.Ft freezer, 1.85 Cu.Ft main refrigerator, and 0.6 Cu.Ft beverage zone.

Your browser does not support the video tag.

Video: An overview of the NEWBULIG Mini Fridge with Freezer, showcasing its features and compartments.

MAINTENANCE

1. Defrosting

This refrigerator features a manual defrost system. When frost accumulates to about 1/4 inch thick in the freezer compartment, it's time to defrost:

1. Unplug the refrigerator from the power outlet.
2. Remove all food items from both compartments and store them in a cooler to prevent spoilage.

3. Leave the doors open to allow frost to melt naturally. You can place towels at the bottom to absorb water.
4. Once all frost has melted, clean and dry the interior thoroughly.
5. Plug the refrigerator back in and allow it to cool for a few hours before returning food.

Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.

2. Cleaning

Regular cleaning helps maintain hygiene and efficiency:

- Unplug the appliance before cleaning.
- Wash the interior with a mild detergent and warm water solution. Use a soft cloth or sponge.
- Clean removable shelves and the crisper drawer with warm, soapy water.
- Wipe down the exterior with a damp cloth. For stainless steel surfaces, use a specialized stainless steel cleaner.
- Ensure all parts are dry before plugging the refrigerator back in.

TROUBLESHOOTING

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "OFF".	Ensure plug is secure; reset circuit breaker; turn temperature control to a desired setting.
Temperature is not cold enough.	Door opened too frequently; large amount of warm food added; poor air circulation; temperature control set too warm.	Minimize door openings; allow warm food to cool before placing inside; ensure proper clearance around unit; adjust temperature control to a colder setting.
Excessive noise.	Refrigerator not level; contact with wall/cabinet; loose parts.	Adjust leveling feet; move unit away from obstructions; check for loose components.
Water on floor.	Drain pan overflowing (during defrost); door not sealing properly.	Ensure drain pan is correctly positioned; check door gasket for proper seal.

SPECIFICATIONS

Feature	Detail
Brand	NEWBULIG
Model Name	NW-BX-SM01-SR
Capacity	3.2 cubic feet (Total)
Freezer Capacity	0.75 Cubic Feet
Fresh Food Capacity	1.81 Cubic Feet
Product Dimensions (D x W x H)	20.47"D x 20.47"W x 35.83"H
Color	Silver

Feature	Detail
Configuration	Compact Freezer-on-Top
Special Features	Adjustable Shelves, Compact, Energy Efficient, Low Noise
Installation Type	Freestanding
Number of Doors	2
Defrost System	Manual
Voltage	110 Volts
Shelf Type	Glass
Cooling Method	Compressor
Adjustable Temperature Control	Yes
Item Weight	41.66 Pounds
Annual Energy Consumption	320 Kilowatt Hours Per Year
Certification	ETL Certified
Refrigerant	R-600A

WARRANTY AND SUPPORT

Warranty Information

This NEWBULIG Mini Fridge with Freezer comes with a **1 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact NEWBULIG customer support. Refer to the contact information provided with your product packaging or visit the official NEWBULIG website for support details.

Online Resources: For additional information and FAQs, please visit the [NEWBULIG Store on Amazon](#).

