

Haier HEB-362TSA-P

Haier 355L Frost Free Triple Inverter Refrigerator

MODEL: HEB-362TSA-P USER MANUAL

Introduction

This manual provides essential information for the safe and efficient operation of your new Haier 355L Frost Free Triple Inverter Double Door Bottom Mount Refrigerator, Model HEB-362TSA-P. Please read these instructions thoroughly before installation and use, and retain them for future reference.

Your refrigerator features a 355-liter capacity, a 2-star energy rating, and a frost-free bottom mount design. Key technologies include Triple Inverter and Dual Fan for efficient cooling, a Digital Touch Display, and 14-in-1 convertible modes.

Safety Information

Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury when using this appliance.

- Ensure the refrigerator is properly grounded.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Unplug the appliance before cleaning or performing maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Setup and Installation

Unpacking

Carefully remove all packaging materials. Inspect the refrigerator for any damage. Report any damage to your retailer immediately.

Placement

- Place the refrigerator on a firm, level surface.
- Allow adequate space around the appliance for proper ventilation (at least 10 cm at the back and sides).
- Avoid direct sunlight or heat sources.
- This is a freestanding installation type.

Electrical Connection

Connect the refrigerator to a dedicated 230 Volt, 50 Hz AC power outlet. Ensure the outlet is properly grounded. The refrigerator features Stabilizer Free Operation, protecting against voltage fluctuations between 110V and 300V without an external stabilizer.




Image: Refrigerator highlighting Stabilizer Free Operation and Auto Connect Home Inverter capabilities.

Initial Operation

After plugging in, allow the refrigerator to operate for at least 2-4 hours before placing food inside. This allows the internal temperature to stabilize.

Operating Instructions

Digital Touch Display

The refrigerator is equipped with a Digital LED Panel on the door, allowing you to adjust settings without opening the door. This panel typically includes controls for Fridge temperature, Freezer temperature, Auto Set, Power Cool, and Turbo Icing functions.



Image: Close-up of the Digital LED Panel on the refrigerator door.

14-in-1 Convertible Modes

Your refrigerator offers 14 convertible modes to adapt to various storage needs. These modes allow you to adjust the temperature settings of both the fridge and freezer compartments to optimize storage for different food types or occasions.



Image: Visual representation of the 14-in-1 convertible modes, showing various temperature settings for fridge and freezer.

Key Features

- **Frost Free Operation:** The auto-defrost feature prevents ice build-up, eliminating the need for manual defrosting.
- **Triple Inverter & Dual Fan Technology:** This technology ensures faster cooling, quieter operation, and reduced energy consumption by optimizing compressor and fan speeds.
- **1 Hour Icing Technology:** Rapidly produces ice cubes within 60 minutes.
- **2X Bigger Vegetable Box:** Provides ample storage space for fresh produce.
- **Bottom Mount Freezer:** Designed to reduce bending by placing the frequently accessed refrigerator compartment at the top.



Image: Interior view of the freezer compartment demonstrating the 1 Hour Icing Technology.



Image: Interior view of the refrigerator compartment highlighting the spacious 2X Bigger Vegetable Box.

Maintenance and Care

Cleaning the Interior

- Always unplug the refrigerator before cleaning.
- Clean the interior with a soft cloth dampened with a solution of mild detergent and warm water.
- Wipe dry with a clean, soft cloth.
- Remove shelves and drawers for thorough cleaning as needed.

Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- For stainless steel finishes, use a specialized stainless steel cleaner.
- Clean the door gaskets regularly to ensure a tight seal.

Condenser Coils

Periodically clean the condenser coils located at the back or bottom of the refrigerator to maintain efficiency. Unplug the appliance before cleaning.

Troubleshooting Guide

Before contacting service, review this section for common issues and solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate	No power supply; power cord unplugged; circuit breaker tripped.	Check power connection; reset circuit breaker.
Refrigerator not cooling properly	Temperature setting too high; door not closed properly; excessive food load; poor ventilation; condenser coils dirty.	Adjust temperature; ensure door seals; do not overload; ensure proper clearance; clean condenser coils.
Unusual noises	Refrigerator not level; items vibrating inside; normal operating sounds (e.g., refrigerant flow, defrost heater).	Level the refrigerator; rearrange items; consult manual for normal sounds.
Water on floor	Drain tube clogged; defrost water overflowing.	Clear drain tube; ensure proper drainage.

Specifications

Feature	Detail
Model Number	HEB-362TSA-P
Brand	Haier
Capacity	355 Liters
Configuration	Freezer-on-Bottom
Colour	Silver
Product Dimensions (D x W x H)	66.5D x 62.3W x 173H Centimeters
Item Weight	67 Kilograms
Defrost System Type	Frost Free
Energy Rating	2 Star
Annual Energy Consumption	255 Kilowatt Hours Per Year
Voltage	230 Volts
Shelf Type	Toughened Glass
Number of Doors	2

Feature	Detail
Number Of Shelves	3
Convertible Freezer	Yes
Additional Features	Digital Temperature Control, Triple Inverter & Dual Fan Technology, Stabilizer Free Operation, Auto Connect Home Inverter, 14-in-1 Convertible Modes, 1 Hour Icing Technology, 2X Bigger Vegetable Box.




Image: Refrigerator dimensions and energy efficiency label.

Warranty Information

Your Haier refrigerator comes with a **1 Year Comprehensive Warranty** on the product and a **10 Years Warranty** on the compressor. This warranty covers manufacturing defects and ensures trusted support and lasting cooling performance. Please refer to the warranty card included with your product for full terms and conditions.

Customer Support

For any service, support, or warranty claims, please contact Haier customer service. You can find contact details on the warranty card or visit the official Haier India website.

Manufacturer Contact Information:

HAIER APPLIANCES INDIA PVT. LTD.,
B-3, MIDC, RANJANGAON, TAL. SHIRUR. DIST. PUNE-412220, MAHARASHTRA, INDIA

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question