

Zasidler White

Zasidler Handheld Sewing Machine & 109-Piece Kit

Model: White

User Manual

1. WELCOME

Thank you for choosing the Zasidler Handheld Sewing Machine Kit. This portable and versatile sewing machine, accompanied by a comprehensive 109-piece sewing kit, is designed for quick repairs, DIY projects, and general sewing tasks. This manual provides essential information for safe and effective use, setup, operation, and maintenance of your new sewing machine.

2. PACKAGE CONTENTS

Your Zasidler Handheld Sewing Machine Kit includes the following items:

- 1 x Handheld Sewing Machine
- 1 x Exquisite Storage Case (Black)
- 1 x Fabric Scissors
- 1 x Yarn Thread Cutter
- 1 x Sewing Seam Ripper
- 22 x Rolls of Polyester Sewing Threads
- 12 x Metal Bobbins with Sewing Threads
- 30 x Assorted Hand Sewing Needles
- 26 x Buttons
- 10 x Safety Pins
- 2 x Sewing Thimbles
- 1 x Needle Threader

- 1 x Soft Tape Measure



Image: Complete 109-piece sewing kit contents, including the handheld sewing machine, threads, needles, scissors, and other accessories, neatly arranged.

3. PRODUCT OVERVIEW

The handheld sewing machine is a compact device designed for ease of use and portability. Familiarize yourself with its key components:

TWO POWER SUPPLY METHODS

1. 6V power adapter (not included)

2. 4 AA batteries (not included)




Image: Detailed diagram illustrating the components of the handheld sewing machine, including the fixed needle screw, tension control, needle, presser foot, rotating wheel, bobbin holder, wire hole, switch, power socket, and battery bay.

- **Fixed Needle Screw:** Secures the needle in place.
- **Tension Control:** Adjusts the thread tension for different fabrics.
- **Needle:** The primary component for stitching.
- **Presser Foot:** Holds the fabric firmly against the feed dogs.
- **Rotating Wheel:** Manually controls needle movement.
- **Bobbin Holder:** Holds the thread bobbin.
- **Wire Hole:** Guides the thread.
- **Switch:** Powers the machine on/off.
- **Power Socket:** For optional 6V power adapter.
- **Battery Bay:** Houses 4 AA batteries.

4. SETUP

4.1 Power Supply

The handheld sewing machine can be powered by two methods:

1. **Batteries:** Insert 4 AA batteries (not included) into the battery bay. Ensure correct polarity.
2. **Power Adapter:** Connect a 6V power adapter (not included) to the power socket.

4.2 Threading the Machine

Proper threading is crucial for smooth operation. Follow these steps:

1. Place a thread bobbin onto the bobbin holder.
2. Guide the thread through the wire hole.
3. Pass the thread through the tension control disc.
4. Thread the needle from front to back using the needle threader if needed.

5. Pull approximately 10 cm of thread through the needle eye.

Your browser does not support the video tag.

Video: Demonstration of unboxing and setting up the Zsidler Handheld Sewing Machine, including threading and battery installation.

5. OPERATING INSTRUCTIONS

Once the machine is threaded and powered, you can begin sewing:

1. Lift the presser foot and place the fabric underneath, aligning the seam with the needle.
2. Lower the presser foot to secure the fabric.
3. Hold the fabric gently with one hand and press the power switch to start sewing.
4. Guide the fabric slowly and steadily through the machine. The speed at which you guide the fabric will determine the stitch length.
5. To finish a seam, press the power switch to stop the machine. Lift the presser foot and gently pull the fabric away. Cut the thread, leaving a small tail.
6. To secure the stitch, tie a knot at the end of the seam.



Wide Range of Uses

This mini portable handheld sewing machine is specially designed for sewing enthusiasts. Whether you're an adult, kid, beginner, or professional, you can easily learn to use it. It works on a variety of fabrics, making it perfect for mending clothes, jeans, shopping bags, pet clothing, or unleashing your DIY creativity.

Image: A person demonstrating the use of the handheld sewing machine on a piece of fabric.

5.1 Knotting Tutorial

After completing a seam, it is important to secure the thread to prevent unraveling. Follow these steps to tie a knot:

Knotting Tutorial




Image: A six-step visual guide demonstrating how to tie a secure knot at the end of a sewn seam.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your sewing machine:

- **Cleaning:** Use a soft brush to remove lint and dust from the needle area and under the presser foot after each use.
- **Needle Replacement:** Replace the needle regularly, especially if it becomes bent, dull, or breaks. To replace, loosen the fixed needle screw, remove the old needle, insert a new one with the flat side facing the back, and tighten the screw.
- **Storage:** Store the machine and accessories in the provided storage case in a dry, cool place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your sewing machine, refer to the following common problems and solutions:

- **Machine not starting:** Check if batteries are correctly inserted or if the power adapter is properly connected. Ensure the power switch is in the 'ON' position.
- **Skipped stitches:** This often indicates a bent or dull needle. Replace the needle. Also, ensure the thread is correctly tensioned and threaded through all guides.
- **Thread breaking:** Check for proper threading, ensure the tension is not too tight, and inspect the needle for burrs or damage. Use good quality thread.
- **Fabric not moving:** Ensure the presser foot is lowered and you are gently guiding the fabric.

For persistent issues, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Zasidler
Color	White
Material	EVA
Product Dimensions (D x W x H)	5.9"D x 9.8"W x 4.3"H
Item Weight	2 Pounds
Power Source	AC/DC (4 AA batteries or 6V adapter)
Is Electric	Yes
UPC	790807214327
Model Number	White
Unit Count	109.0 Count (for the kit)

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the contact information provided with your purchase or visit the official Zasidler website. Keep your purchase receipt for warranty claims.
