

[Manuals.plus](#) /

- › [Safecourt Kitchen](#) /
- › Safecourt Kitchen Slowjuicer SJ500-BL Instruction Manual

## Safecourt Kitchen SJ500-BL

# Safecourt Kitchen Slowjuicer SJ500-BL Instruction Manual

## 1. INTRODUCTION

---

Thank you for choosing the Safecourt Kitchen Slowjuicer SJ500-BL. This premium cold press juicer is designed for efficient juice extraction, preserving nutrients and flavor. Please read this manual carefully before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.



Image 1.1: The Safecourt Kitchen Slowjuicer SJ500-BL, fully assembled and ready for use.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before use.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- Never feed food into the chute with your fingers. Always use the provided safety pusher.
- Do not operate the juicer if any part is damaged or if the power cord is frayed.
- This appliance is for household use only. Do not use outdoors.
- Ensure all parts are correctly assembled before turning on the appliance.
- Do not overload the juicer. Process ingredients gradually.

- Keep the appliance out of reach of children.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x Slow Juicer Motor Base
- 1 x Juicing Assembly (includes auger, strainer, and rotating brush)
- 1 x Feeding Chute Lid
- 1 x Juice Container (700 ml)
- 1 x Pulp Container (700 ml)
- 1 x Safety Pusher
- 1 x Cleaning Brush
- 1 x Instruction Manual (this document)

## 4. ASSEMBLY

---

Follow these steps to assemble your slow juicer:

1. Place the motor base on a stable, flat surface.
2. Align the juicing assembly (which includes the auger, strainer, and rotating brush) with the motor base and gently push down until it clicks into place. Ensure it is securely locked.
3. Insert the auger into the center of the strainer.
4. Place the feeding chute lid onto the juicing assembly. Rotate it clockwise until it locks securely. You should hear a click. The juicer will not operate if the lid is not properly locked.
5. Position the juice container under the juice spout and the pulp container under the pulp spout.

## 5. OPERATING INSTRUCTIONS

---

Before first use, wash all detachable parts thoroughly with warm soapy water and rinse well. Ensure all parts are dry before assembly.

### 5.1 Ingredient Preparation

- Wash all fruits and vegetables thoroughly.
- For most fruits and vegetables, pre-cutting is not necessary due to the 125 mm XL feeding chute. Whole apples, pears, or celery stalks can be inserted directly.
- Remove hard pits from fruits (e.g., peaches, plums, cherries) and large seeds.
- Peel citrus fruits (oranges, lemons, grapefruits) as their peels can impart a bitter taste.
- Cut fibrous ingredients like ginger or leafy greens into smaller pieces to prevent tangling.

### 5.2 Juicing Process

1. Ensure the juicer is correctly assembled and the juice and pulp containers are in place.
2. Plug the power cord into a suitable electrical outlet (230 Volts).

3. Turn the power switch to the 'ON' position.
4. Gradually feed prepared ingredients into the feeding chute. Use the safety pusher to gently guide ingredients down. Do not force ingredients.
5. The juicer will extract juice into the juice container and separate pulp into the pulp container.
6. If ingredients become blocked, turn the switch to the 'REV' (Reverse) position for a few seconds to clear the blockage, then switch back to 'ON'.
7. Once juicing is complete, turn the power switch to 'OFF' and unplug the appliance.

### 5.3 Versatile Use

This slow juicer is also suitable for making fresh oat milk or almond milk. Follow similar steps, ensuring oats or almonds are properly soaked if required by your recipe.

## 6. CLEANING AND MAINTENANCE

---

Regular cleaning ensures the longevity and hygiene of your slow juicer.

1. Always unplug the juicer from the power outlet before cleaning.
2. Disassemble the juicer by rotating the feeding chute lid counter-clockwise and lifting it off. Then, remove the juicing assembly from the motor base.
3. Separate all detachable parts: feeding chute lid, auger, strainer, rotating brush, juice container, and pulp container.
4. Rinse all detachable parts under running water immediately after use to prevent pulp from drying and sticking.
5. Use the provided cleaning brush to remove any stubborn pulp from the strainer mesh and other components.
6. All detachable parts are dishwasher safe. Place them on the top rack of your dishwasher.
7. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
8. Ensure all parts are completely dry before reassembling or storing the juicer.

## 7. TROUBLESHOOTING

---

If you encounter issues with your slow juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; Lid not properly locked; Power switch off.	Ensure power cord is securely plugged in. Check that the lid is fully locked into place. Turn the power switch to 'ON'.
Juicer stops during operation or ingredients are blocked.	Overload of ingredients; Fibrous ingredients tangled.	Turn the switch to 'REV' (Reverse) for a few seconds, then back to 'ON'. If blockage persists, turn off, unplug, disassemble, and clear the blockage manually. Cut fibrous ingredients into smaller pieces.

Problem	Possible Cause	Solution
Excessive vibration or noise.	Improper assembly; Hard ingredients.	Disassemble and reassemble all parts, ensuring they are correctly aligned and locked. Process hard ingredients slowly.
Low juice yield or wet pulp.	Ingredients not suitable for juicing; Overfeeding.	Ensure ingredients are fresh. Feed ingredients slowly and allow the juicer to process them fully.

## 8. SPECIFICATIONS

---

Technical details for the Safecourt Kitchen Slowjuicer SJ500-BL:

- **Model Number:** SJ500-BL
- **Brand:** Safecourt Kitchen
- **Color:** Blue
- **Power:** 220 Watts
- **Voltage:** 230 Volts
- **Number of Speeds:** 2
- **Product Dimensions:** 15 cm (D) x 15 cm (W) x 47 cm (H)
- **Feeding Chute:** 125 mm XL
- **Blade Material:** Stainless Steel
- **Construction Materials:** BPA-free Tritan, Stainless Steel
- **Care Instructions:** Dishwasher safe parts
- **Power Source:** Corded Electric
- **Automatic Shut-off Function:** No
- **Noise Level:** Quiet operation

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Safecourt Kitchen website. Keep your proof of purchase for any warranty claims.

If you experience any issues not covered in this manual, please contact Safecourt Kitchen customer service for assistance.