

[Manuals.plus](#) /

› [Safecourt Kitchen](#) /

› Safecourt Slow Juicer SJ500 User Manual

Safecourt Kitchen SJ500

Safecourt Slow Juicer SJ500 User Manual

Model: SJ500

1. INTRODUCTION

Thank you for choosing the Safecourt Slow Juicer SJ500. This appliance is designed to extract maximum juice from fruits and vegetables with minimal waste, preserving nutrients and flavor. Its powerful motor, extra-large feed chute, and cold-press technology make juicing efficient and convenient. This manual provides essential information for safe operation, assembly, use, maintenance, and troubleshooting to ensure optimal performance and longevity of your juicer.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain for future reference.

- Always ensure the juicer is properly assembled before operation.
- Do not operate the appliance with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Always use the food pusher provided.
- Unplug the juicer from the power outlet before cleaning, assembling, disassembling, or when not in use.
- Do not immerse the motor base in water or any other liquid.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the appliance outdoors.
- Ensure the appliance is placed on a stable, level, and dry surface during use.
- Avoid contact with moving parts.

3. PRODUCT OVERVIEW

The Safecourt Slow Juicer SJ500 is designed for efficient and easy juicing. Familiarize yourself with its components

before use.



Image 3.1: Safecourt Slow Juicer SJ500 with included accessories.

What's Included:

- 1 x Safecourt Slow Juicer (Motor Base, Juicing Chamber, Auger, Filter, Lid)
- 1 x Juice Container (700 ml)
- 1 x Pulp Container (700 ml)
- 1 x Food Pusher
- 1 x Cleaning Brush

Warum Safecourt? Der klare Unterschied.



Safecourt

- ✓ 125 mm XL-Einfüllöffnung – ganze Früchte, kein Vorschneiden
- ✓ Neueste Edelstahl-Pre-Cutter-Technologie
- ✓ Leistungsstarker & leiser Motor (10 Jahre Garantie)
- ✓ 30 % mehr Saft, minimaler Trester
- ✓ Einfache Reinigung & spülmaschinengeeignet
- ✓ Ebenfalls geeignet für Hafer- & Nussmilch
- ✓ Hergestellt aus BPA-freiem Tritan – sicher & geschmacksneutral



Andere

- ✗ Kleine Einfüllöffnung – Obst muss vorgeschnitten werden
- ✗ Kunststoff-Pre-Cutter
- ✗ Schwächere Motoren
- ✗ Geringere Saftausbeute
- ✗ Aufwendige Reinigung
- ✗ Nicht immer spülmaschinengeeignet
- ✗ Standard-Kunststoff

Image 3.2: The Safecourt Slow Juicer SJ500 with its accompanying juice container, pulp container, and cleaning brush.

4. SETUP AND ASSEMBLY

Follow these steps to correctly assemble your Safecourt Slow Juicer SJ500 before first use.

1. Place the motor base on a stable, flat surface.
2. Align the juicing chamber with the motor base and rotate it clockwise until it locks securely into place.
3. Insert the filter into the juicing chamber, ensuring it sits correctly.
4. Place the auger (screw) into the center of the filter.
5. Attach the lid to the top of the juicing chamber, aligning the arrows and rotating clockwise until it locks. Ensure the lid is fully locked for the juicer to operate.
6. Position the juice container under the juice spout and the pulp container under the pulp spout.



Image 4.1: Visual guide for assembling the juicer components onto the motor base.

Schnippeln ist Verganenheit

Mit der 125 mm Einfüllöffnung passen ganze Äpfel, Birnen oder Selleriestangen direkt hinein – ganz ohne Schneidebrett und ohne Zeitverlust.



Image 4.2: The fully assembled Safecourt Slow Juicer SJ500, ready for use.

5. OPERATING INSTRUCTIONS

Follow these steps to operate your Safecourt Slow Juicer SJ500.

1. **Preparation:** Wash fruits and vegetables thoroughly. For most items, pre-cutting is not necessary due to the 125mm XL feed chute. Harder items like carrots or celery can be cut into smaller pieces if desired, but the stainless steel pre-cutter is designed to handle whole fruits and vegetables.
2. **Power On:** Plug the juicer into a grounded electrical outlet. Turn the control knob to the 'ON' position.
3. **Juicing:** Slowly feed ingredients into the feed chute. Use the food pusher to gently guide ingredients down. Do not force ingredients into the chute. The powerful motor and cold-press technology will extract the juice.
4. **Reverse Function:** If ingredients get clogged, turn the control knob to the 'REV' (Reverse) position for a few seconds to clear the blockage, then return to 'ON' to continue juicing.
5. **Finish Juicing:** Once all ingredients are juiced, turn the control knob to 'OFF' and unplug the appliance.

30% Mehr saft. Kein Verschwendung.



Mehr
Nährstoffe



Weniger
Abfall



Cremigere
Textur



Image 5.1: Demonstrating the large feed chute, allowing whole fruits to be juiced without pre-cutting.

Dieser Motor schafft alles.



Neu entwickelte
Hochleistungs- Motor-
Technologie



Zuverlässige Power



10 Jahre Garantie
auf den Motor



Kraftvoll und
dennoch leise



Image 5.2: The juicer in operation, showing fresh juice being dispensed into a glass.

Neueste Schneid- & Cold-Press-Technologie auf dem Markt

Mit dem Premium Edelstahl-Klingen wird selbst härtestes Obst und Gemüse mühelos verarbeitet.



Verhindert Verstopfungen



Hohe Saftausbeute



Spart Zeit



Image 5.3: A detailed view of the stainless steel pre-cutter technology inside the juicing chamber.



Image 5.4: The control knob for operating the juicer, featuring ON, OFF, and Reverse (REV) settings.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your Safecourt Slow Juicer SJ500. All removable parts are dishwasher safe for convenience.

1. **Disassembly:** After unplugging the juicer, disassemble the parts in reverse order of assembly: remove the lid, then the auger, filter, and juicing chamber from the motor base.
2. **Rinsing:** Rinse all removable parts under running water to remove any large pulp residue.
3. **Brushing:** Use the provided cleaning brush to thoroughly clean the filter and any other parts with stubborn pulp.
4. **Washing:** All removable parts can be washed by hand with warm, soapy water or placed in the dishwasher.
5. **Drying:** Allow all parts to air dry completely before reassembling or storing.
6. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water.

Gesundheit,
die verbindet.



Image 6.1: Hand-washing a juicer component under a faucet to remove pulp residue.

Einfache Reinigung. Kein Aufwand.

Viele Slow Juicer sind kompliziert in der Bedienung – unserer ist es nicht.
Alle Teile lassen sich leicht auseinandernehmen und im
Handumdrehen reinigen. Mehr Zeit für das, was zählt: frischen Saft.



Image 6.2: Removable parts of the juicer placed in a dishwasher for easy cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your Safecourt Slow Juicer SJ500, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; Lid not properly locked; Power outage.	Ensure the power cord is securely plugged in. Check if the lid is fully locked into place. Verify power supply.
Motor stops during operation or makes unusual noise.	Overload; Ingredients are jammed.	Turn off the juicer, unplug it, and clear any jammed ingredients. Use the 'REV' function to dislodge blockages. Cut hard ingredients into smaller pieces.

Problem	Possible Cause	Solution
Low juice yield or wet pulp.	Ingredients fed too quickly; Filter is clogged.	Feed ingredients slowly. Clean the filter thoroughly before each use.
Leakage from the juicer.	Parts not assembled correctly; Seal is damaged.	Disassemble and reassemble all parts, ensuring they are securely locked. If leakage persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Safecourt Kitchen
Model	SJ500
Color	Beige
Dimensions (P x L x H)	15P x 15l x 47H centimeters
Maximum Power	220 Watt
Voltage	230 Volts
Number of Speeds	2 (ON/REV)
Blade Material	Stainless Steel
Body Material	Tritan and Stainless Steel (BPA-free)
Feed Chute Opening	125 mm (XL)
Care Instructions	Dishwasher safe (removable parts)
Year of Manufacture	2026

9. WARRANTY AND SUPPORT

The Safecourt Slow Juicer SJ500 comes with a **10-year warranty on the motor**, reflecting our commitment to quality and durability. For any questions, technical support, or warranty claims, please contact Safecourt Kitchen customer service through your retailer or the official Safecourt Kitchen website.