Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OEARE B0GQH3WD66

OEARE Portable Air Conditioner User Manual

Model: B0GQH3WD66

1. Introduction

Thank you for purchasing the OEARE Portable Air Conditioner. This 3-in-1 unit functions as an air conditioner (with water and ice packs), a humidifier (with water), and a cooling fan. Designed for efficiency and quiet operation, it provides customizable cooling and humidification for your home environment. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting.



Image 1.1: The OEARE Portable Air Conditioner unit.

2. Safety Information

Please read all safety instructions carefully before using this appliance and keep this manual for future reference. Improper operation may cause damage to the product or personal injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the appliance from the power outlet when not in use, before cleaning, or before moving.
- Keep the appliance out of reach of children and pets.
- Do not block air inlets or outlets. Ensure adequate space around the unit for proper airflow.
- Use only clean water in the water tank. Do not add any chemicals or additives other than specified ice packs.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Place the appliance on a stable, level surface to prevent tipping.

3. Package Contents

Verify that all items are present in the package:

- OEARE Portable Air Conditioner Unit
- Remote Control (x1)
- Ice Packs (x4)
- User Manual (x1)

4. Product Overview

The OEARE Portable Air Conditioner is designed for versatile cooling and air treatment. It features a 3-in-1 design, offering fan, humidification, and cooling functions. The unit is equipped with a user-friendly control panel and a remote control for convenient operation.

4.1. 3-in-1 Functionality

This appliance can operate in three distinct modes:

- **Normal Fan:** Operates as a standard fan without water.
- **Humidifier:** Adds moisture to the air when water is present in the tank.
- **Air Cooler:** Provides enhanced cooling when water and ice packs are used.



Image 4.1: The 3-in-1 functionality of the air conditioner.

4.2. Control Panel and Remote Control

The unit can be operated via the intuitive top control panel or the included remote control. The front display shows the current operating status.



Image 4.2: Control panel and remote control for the unit.

4.3. Water Tank and Ice Packs

The unit features a 6-liter dual water tank structure (upper and lower) and comes with four ice packs for enhanced cooling. The bottom tank is removable for easy cleaning.



Image 4.3: Filling the 6L water tank and using ice packs.

4.4. Mobility and Dimensions

Equipped with four casters and a built-in handle, the unit is easy to move between rooms. No installation, windows, or hoses are required.



Image 4.4: Dimensions of the OEARE Portable Air Conditioner.

5. Setup

Follow these steps to set up your portable air conditioner for first use:

1. **Unpack:** Carefully remove the unit and all accessories from the packaging.
2. **Placement:** Place the unit on a firm, level surface. Ensure there is adequate space around the unit for proper air circulation.
3. **Prepare Ice Packs:** Place the included ice packs in a freezer until they are completely frozen.
4. **Add Ice Packs:** Once frozen, place the ice packs into the bottom water tank.
5. **Fill Water Tank:** Open the lid on the top of the unit and slowly pour clean water into the top water tank. Do not exceed the 'MAX' fill line. Adding water too quickly may cause overflow.
6. **Connect Power:** Plug the power cord into a standard 120V electrical outlet.



Image 5.1: Steps for activating the cooling function with ice packs and water.

6. Operating Instructions

Operate your OEARE Portable Air Conditioner using either the control panel on the unit or the remote control.

6.1. Power On/Off

- Press the **Power** button on the control panel or remote control to turn the unit on or off.

6.2. Adjusting Wind Speed

The unit offers 3 wind speeds: Low, Medium, and High.

- Press the **Speed** button repeatedly to cycle through the available wind speeds.

6.3. Selecting Modes

Choose from 4 wind feeling modes: Normal, Natural, Sleep, and Cooling.

- Press the **Mode** button repeatedly to select your desired mode.
- **Normal Mode:** Provides a continuous strong wind.
- **Natural Mode:** Simulates a gentle, varying breeze.
- **Sleep Mode:** Operates quietly for undisturbed rest.
- **Cooling Mode:** Delivers cool air, especially effective with water and ice packs.



Image 6.1: Available modes and wind speeds.

6.4. Timer Function

Set the unit to automatically shut off after a specified period, up to 12 hours.

- Press the **Timer** button to set the desired operating duration.

6.5. Display Control

To turn off the front display for undisturbed sleep:

- Press and hold the **Fan** button on the unit, or briefly press the**Display** button on the remote control.

6.6. Official Product Videos

Video 6.2: Demonstrates the general operation and remote control usage of the portable air conditioner, including changing speeds.

Video 6.3: Highlights the LED display and the 12-hour auto timer function of the unit.

7. Maintenance

Regular maintenance ensures optimal performance and longevity of your air conditioner.

7.1. Cleaning the Water Tank

The bottom water tank is removable for easy cleaning.

1. Unplug the unit from the power outlet.
2. Carefully remove the bottom water tank.
3. Empty any remaining water.
4. Clean the tank with a soft cloth and mild detergent. Rinse thoroughly with clean water.
5. Allow the tank to air dry completely before reinserting it into the unit.

7.2. General Cleaning

- Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure air inlets and outlets are free from dust and obstructions.

8. Troubleshooting

If you encounter issues with your OEARE Portable Air Conditioner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power button not pressed	Check power cord connection; Ensure outlet is functional; Press Power button.
Weak or no airflow	Air inlets/outlets blocked; Water tank empty (for cooling/humidifying)	Clear any obstructions; Refill water tank.
Not cooling effectively	Water tank empty; Ice packs not frozen or used; High room humidity	Ensure water tank is filled; Use frozen ice packs; Evaporative coolers are less effective in high humidity.
Unusual noise	Unit not on a level surface; Internal component issue	Place on a stable, level surface; If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

Technical specifications for the OEARE Portable Air Conditioner:

Feature	Specification
Brand	OEARE
Model	B0GQH3WD66
Mounting Type	Freestanding
Colour	White

Feature	Specification
Controls Type	Remote Control and Touch
Recommended Uses	Home cooling
Wattage	50 watts
Noise Level	35 Decibels
Number Of Speeds	3
Voltage	120 Volts
Operation Mode	Automatic
Item Dimensions (D x W x H)	59.5D x 25W x 21H Centimetres
Water Tank Capacity	6000ML (6 Liters)
Timer	12-Hour
Included Components	Remote Control X1, Ice Packs X4, User Manual X1

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official OEARE website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GQH3WD66

More documents and user manuals: **https://manuals.plus/**