

Sinbo SHB-7516

Sinbo SHB-7516 Turbo Blender User Manual

Model: SHB-7516

1. INTRODUCTION

Thank you for choosing the Sinbo SHB-7516 Turbo Blender. This manual provides essential information for the safe and efficient use of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not blend hot liquids, as they may eject from the jar and cause burns.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate the blender with the lid in place.

3. PRODUCT OVERVIEW

The Sinbo SHB-7516 Turbo Blender is designed for efficient blending of various ingredients. Familiarize yourself with its main components:

- **Motor Base:** Contains the powerful 1000W motor and control dial.
- **1.5 Litre Glass Jar:** Durable glass container for blending.
- **Blade Assembly:** Stainless steel blades for effective blending.
- **Lid:** Secures the jar during operation.
- **Control Dial:** Used to select speed settings and activate the Turbo function.





Image: Sinbo SHB-7516 Turbo Blender with its 1.5 Litre glass jar filled with fruits and ice, ready for blending. The red motor base and control dial are visible.

4. SETUP

Before using your blender for the first time, ensure all packaging materials are removed and clean the parts as described in the 'Cleaning and Maintenance' section.

1. Place the motor base on a stable, flat, and dry surface.
2. Ensure the blade assembly is securely attached to the bottom of the glass jar.
3. Place the glass jar onto the motor base, aligning it correctly until it locks into position.
4. Add your ingredients to the glass jar. Do not overfill beyond the maximum fill line.
5. Securely place the lid on the glass jar.
6. Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

The Sinbo SHB-7516 offers two speed settings and a Turbo function for versatile blending.

1. **Adding Ingredients:** Ensure the blender is unplugged before adding or removing ingredients. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
2. **Selecting Speed:** Turn the control dial to your desired speed setting (1 or 2). Start with a lower speed for thicker mixtures or to chop ingredients, then increase as needed.

3. **Using Turbo Function:** For short bursts of maximum power, turn the control dial to the 'Turbo' position and hold. Release to stop. This is ideal for crushing ice or achieving a smoother consistency quickly.
4. **Blending Time:** Do not operate the blender continuously for more than 1 minute. Allow the motor to rest for a few minutes between cycles to prevent overheating.
5. **Stopping Operation:** Turn the control dial back to the '0' (off) position. Wait until the blades have completely stopped before removing the lid or jar.



Siklonik hareketle daha hızlı,
daha pürüzsüz karışımlar.



Image: A woman operating the Sinbo SHB-7516 Turbo Blender, blending a purple smoothie to a smooth consistency. This demonstrates the blender in active use.



Buzu saniyeler içinde parçalar,
kusursuz smoothie kıvamı sağlar.



Image: The Sinbo SHB-7516 Turbo Blender with its glass jar filled with ice cubes, illustrating its ice crushing capability. The text overlay indicates efficient ice processing for smoothies.



Image: A top-down view inside the Sinbo SHB-7516 Turbo Blender, showing fruits, berries, and ice cubes being blended into a red mixture, highlighting the cyclonic blending action.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the glass jar from the motor base. Separate the blade assembly from the jar.

- 3. **Clean Jar and Lid:** Wash the glass jar, lid, and blade assembly in warm, soapy water. Rinse thoroughly and dry immediately. Be extremely careful when handling the sharp blades.
- 4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
- 5. **Storage:** Store the blender in a dry place, assembled or disassembled, as preferred.

7. TROUBLESHOOTING

If you encounter issues with your Sinbo SHB-7516 Turbo Blender, refer to the following common problems and solutions:

- **Blender does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check that the glass jar is correctly seated and locked onto the motor base.
- **Ingredients are not blending smoothly:**
 - Add more liquid to the mixture.
 - Cut larger ingredients into smaller pieces.
 - Use the Turbo function for short bursts to dislodge ingredients.
 - Do not overfill the jar.
- **Motor stops during operation:**
 - The blender may have overheated. Unplug it and let it cool down for at least 15-20 minutes before attempting to use it again.
 - Reduce the load by removing some ingredients or adding more liquid.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Sinbo
Model Number	d-00005219 (SHB-7516)
Power	1000W
Jar Capacity	1.5 Litre (Glass)
Speed Settings	2
Turbo Function	Yes
Blades	Stainless Steel
Color	Red
Product Dimensions (D x W x H)	10D x 10G x 10Y milimetre
Product Weight	1 Kilogram

Origin Country

Turkey

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Sinbo website. You can also find more information on the [Sinbo Store on Amazon](#).

© 2026 Sinbo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question