

[Manuals.plus](#) /

> [HYZQ](#) /

> HYZQ Sectional Couch with RGB LED Light, Wireless Charger, USB/Type-C Ports - Instruction Manual

HYZQ B0GQLSMLXR

HYZQ Sectional Couch Instruction Manual

Model: B0GQLSMLXR

INTRODUCTION

Thank you for purchasing the HYZQ Sectional Couch. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your product. Please read this manual thoroughly before assembly and use, and retain it for future reference.


SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 350 lbs per seat.
- Keep children and pets away from the assembly area to prevent injury.
- Avoid exposing the couch to direct sunlight or extreme temperatures to prevent material degradation.
- Do not use abrasive cleaners or harsh chemicals on the fabric or frame.

PRODUCT DIMENSIONS

Refer to the diagram below for detailed product dimensions to ensure proper placement in your living space.

PRODUCT DIMENSIONS



Easy Assembly
40 Minutes



350
LBS
Weight Capacity
350 LBS for Each Seat



Come in
2 Cartons



Image: Diagram illustrating the overall dimensions of the sectional couch, including length (109"), depth (57"), and height (33"), along with individual seat and chaise measurements.

SETUP AND ASSEMBLY

1. Unpacking

1. The sectional couch is shipped in two (2) separate boxes. These packages may arrive at different times. Please ensure you have received both boxes before beginning assembly.
2. Carefully open the boxes and remove all components. Lay them out on a clean, soft surface to prevent scratches.
3. The cushions are vacuum compressed for shipping. After opening their packaging, allow approximately 48 hours for them to fully expand and return to their original shape.
4. Locate the two movable storage ottomans. These are hidden inside the sofa armrests. Tear open the Velcro fasteners on the armrests to retrieve them.

2. Assembly Steps

The assembly process has been simplified for ease. Follow the included hardware and instructions to connect the sectional

pieces. Ensure all connections are firm and secure.

3. Left-Right Conversion

The chaise lounge can be configured on either the left or right side of the main sofa section to suit your room layout.



Image: Depicts the sectional couch configured with the chaise on the left and then on the right, demonstrating its reversible design.

OPERATING INSTRUCTIONS

1. Smart LED Lighting System

The sectional couch features an integrated RGB LED lighting system with a control panel located on the armrest.

Smart Sectional Sofa with Lights and Charging Station




Image: Close-up of the control panel on the sofa armrest, showing buttons for wireless charger, USB port, Type-C port, static light, white light, dynamic light, music sync light, power on/off, brightness adjustment.

- **Power On/Off:** Press the power button on the control panel to turn the LED lights on or off.
- **Static Light Modes:** Select from 7 static color modes to set a consistent ambiance.
- **Dynamic Light Modes:** Choose from 7 dynamic lighting effects for a more vibrant display.
- **Music Sync Mode:** Activate this mode to synchronize the LED lights with music, creating an immersive experience.
- **Brightness Adjustment:** Use the brightness buttons to increase or decrease the intensity of the LED lights.

2. Charging Ports

The couch is equipped with a wireless charger, USB port, and Type-C port for convenient device charging.

- **Wireless Charger:** Place your compatible device on the designated wireless charging pad on the armrest. Ensure the device is properly aligned for charging to begin.
- **USB Port:** Connect your device's USB charging cable to the USB port.
- **Type-C Port:** Connect your device's Type-C charging cable to the Type-C port.

3. Storage Ottomans and Side Pockets

The couch includes two movable storage ottomans and two side pockets for organization.



Image: An overhead view of the sectional couch, highlighting the open storage compartments within the two movable ottomans, filled with items like blankets and books.

- **Storage Ottomans:** Lift the top of the ottomans to access the storage space for blankets, pillows, or other items.
- **Side Pockets:** Use the integrated side pockets on the armrests to store remote controls, magazines, or small personal items.

MAINTENANCE AND CARE

1. Fabric Care (Linen Fabric)

- Regularly vacuum the fabric using a soft brush attachment to remove dust and debris.
- For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- For stubborn stains, use a mild fabric cleaner specifically designed for linen, following the product instructions. Test on

an inconspicuous area first.

- Avoid direct sunlight exposure to prevent fading.

2. Frame and Legs

- Wipe the metal and wood frame components with a soft, damp cloth.
- Ensure all screws and bolts remain tight. Periodically check and tighten if necessary.
- Clean plastic legs with a damp cloth. Avoid harsh chemicals.

3. Cushions

- Fluff and rotate cushions regularly to maintain their shape and extend their lifespan.
- The high-density sponge cushions are designed for resilience; however, consistent pressure in one spot can lead to minor indentations over time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cushions not fully expanded	Vacuum compression from shipping	Allow 48 hours after unpacking for cushions to fully expand. Fluff them periodically.
LED lights not working	Power connection issue, control panel malfunction	Ensure the power cable for the LED system is securely connected. Check the control panel for any visible damage.
Charging ports (wireless, USB, Type-C) not working	Power connection issue, device incompatibility, cable fault	Verify the couch's power connection. Ensure your device is compatible with wireless charging. Try a different charging cable.
Sofa feels unstable or wobbly	Loose connections, uneven floor	Check and tighten all assembly bolts and screws. Ensure the sofa is placed on a level surface.

SPECIFICATIONS

Feature	Detail
Brand	HYZQ
Model Number	B0GQLSMLXR
Type	Sectional
Color	Dark Grey
Material Type	Linen Fabric, Metal, Wood
Seat Fill Material	Foam
Seat Back Fill Material	Foam
Product Dimensions (D x W x H)	57"D x 109"W x 33"H

Feature	Detail
Item Weight	123 Pounds
Seating Capacity	4
Weight Capacity (per seat)	350 Pounds
Seat Depth	20.5 inches
Seat Height	18.1 Inches
Arm Height	23.6 Inches
Leg Length	4.7 Inches
Additional Features	Charging Station (Wireless, USB, Type-C), RGB LED Lighting, Storage Ottomans
Assembly Required	Yes

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues, please contact HYZQ customer support through the retailer's platform where the product was purchased. Please have your model number (BOGQLSMLXR) and purchase date available when contacting support.