Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM B61-011V90BK

HOMCOM Mini Portable Dryer Instruction Manual

Model: B61-011V90BK

1. Introduction

Thank you for choosing the HOMCOM Mini Portable Dryer. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read these instructions thoroughly before use and retain them for future reference.
This compact 4 kg capacity dryer features an 800W motor, 6 drying programs, and an intuitive LED display. Its versatile design allows for freestanding, wall-mounted, or stackable installation, making it suitable for various living spaces.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your dryer, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they emit vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the drying compartment.
- Do not reach into the appliance if the drum is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual.
- Always disconnect the appliance from the power supply before cleaning or performing any maintenance.
- Ensure the appliance is properly grounded.

3. Package Contents

Verify that all components are present and undamaged:

- HOMCOM Mini Portable Dryer Unit
- Drainage Fitting
- Instruction Manual

4. Product Overview

The HOMCOM Mini Portable Dryer is designed for efficient and convenient laundry drying. Key features include a front-loading drum, an intuitive LED touch display, and a robust stainless steel interior.



Image: The HOMCOM Mini Portable Dryer, black, positioned on a countertop above a washing machine in a modern laundry room.

Your browser does not support the video tag.

Video: A short demonstration of the HOMCOM Mini Portable Dryer, showing its compact size, the opening and closing of the door, and the digital display.

5. Setup and Installation

5.1 Unpacking

Carefully remove the dryer from its packaging. Inspect the unit for any signs of damage. Keep all packaging materials until you are satisfied with the product.

5.2 Placement Options

The HOMCOM Mini Portable Dryer offers flexible installation to suit your space:

- **Freestanding:** Place the dryer on a stable, level surface. Ensure adequate ventilation around the unit.
- **Wall-Mounted:** The dryer can be mounted on a sturdy wall using an appropriate bracket (not included). Consult a professional for wall mounting to ensure safety and proper installation.
- **Stackable:** The dryer can be stacked on top of a compatible washing machine using a stacking kit (not included). Ensure the washing machine can support the dryer's weight and that the stacking kit is securely installed.



Image: Visual representation of the two main positioning types: freestanding on a surface and wall-mounted with a bracket.

5.3 Electrical Connection

Connect the dryer to a grounded electrical outlet. Ensure the power supply matches the specifications listed on the

appliance's rating label.

5.4 Drainage Connection

Attach the provided drainage fitting to the designated outlet on the dryer. Direct the drainage hose into a suitable drain or collection container. Ensure the hose is not kinked or obstructed.

6. Operating Instructions

6.1 Loading Clothes

Open the dryer door and load your pre-spun laundry. Do not overload the dryer; ensure clothes have enough space to tumble freely. The dryer has a 4 kg capacity, suitable for approximately 10 t-shirts, one set of bed linen, or 25 small towels.



Image: A person loading damp clothes into the open drum of the HOMCOM Mini Portable Dryer.



Image: An infographic detailing the 4 kg capacity, illustrating it can hold 10 t-shirts, 1 set of bed linen, or 25 small towels. It also notes to use the dryer after the spin cycle for optimal drying.

6.2 Control Panel and Display

The dryer features an LED touch display for easy operation. The display shows the remaining drying time and selected temperature.



Image: A detailed view of the intelligent drying display, showing icons for intelligent mode, adjustable temperature (60°C, 50°C, 40°C, natural air), and adjustable timer (20 min, 30 min, 1 hr, 1.5 hr, 2 hr, 3 hr). It highlights that 60°C can sterilize garments and cycles under 30 minutes can quickly deodorize.

6.3 Selecting a Program

Choose from the available drying programs and settings:

- **Intelligent Mode:** The dryer automatically adjusts settings based on the load.
- **Temperature Control:** Select from 60°C (for sterilization), 50°C, 40°C, or natural air ventilation (for odor removal).
- **Adjustable Timer:** Set drying duration for 20 minutes, 30 minutes, 1 hour, 1.5 hours, 2 hours, or 3 hours.

6.4 Starting and Pausing

Press the 'Start/Pause' button to begin or temporarily stop a drying cycle.

6.5 Child Lock

Activate the child lock feature to prevent accidental changes to settings during operation. Refer to the display icons for

activation instructions.

6.6 Automatic Shutdown

The dryer is equipped with an automatic shutdown feature for safety. If the door is opened during operation, the dryer will automatically pause. Close the door and press 'Start' to resume.



Image: A woman opening the dryer door, with an icon indicating the automatic shutdown function for increased safety.

6.7 Wrinkle Reduction

The dryer's large diameter stainless steel drum and alternating forward/reverse rotation mechanism help minimize wrinkles, making ironing easier.



Image: A diagram showing the dryer drum with arrows indicating both forward (blue) and reverse (orange) rotation, highlighting the wrinkle reduction mechanism.

7. Maintenance

7.1 Cleaning the Lint Filter

Regularly clean the lint filter after each use to maintain drying efficiency and prevent fire hazards. Remove the filter, clean off accumulated lint, and reinsert it properly.

7.2 Cleaning the Exterior

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents that could damage the finish.

7.3 Storage

If storing the dryer for an extended period, ensure it is clean and dry. Disconnect it from the power supply and store it in a

cool, dry place.

8. Troubleshooting

If you encounter issues with your dryer, refer to the following common problems and solutions:

- **Dryer does not start:** Check if the power cord is securely plugged in. Ensure the door is fully closed. Verify that a program has been selected and the 'Start' button pressed.
- **Clothes are not drying properly:** Do not overload the dryer. Clean the lint filter. Ensure the selected program and temperature are appropriate for the load.
- **Excessive noise:** Ensure the dryer is on a level surface. Check for any foreign objects in the drum.
- **Display not working:** Disconnect the power for a few minutes and then reconnect. If the issue persists, contact customer support.

9. Specifications



Image: A diagram showing the dimensions of the HOMCOM Mini Portable Dryer: 48cm (width) x 40cm (depth) x 56cm (height).

Product Specifications

Feature	Specification
Brand	HOMCOM
Model Number	B61-011V90BK
Capacity	4 kg
Power	800W
Form Factor	Front Load
Access Position	Front Load
Color	Black
Dimensions (L x W x H)	48 cm x 40 cm x 56 cm
Weight	14.5 kg
Temperature Settings	60°C, 50°C, 40°C, Air Ventilation
Special Features	LED Display, Auto-Shutdown, Child Lock, Stainless Steel Drum, Forward/Reverse Rotation

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt as proof of purchase.

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GQS4LX2M

More documents and user manuals: **https://manuals.plus/**