Basike Ba-FON137

Basike Ba-FON137 Bluetooth 5.4 ANC Headphones User Manual

Comprehensive instructions for setup, operation, and maintenance of your Basike Ba-FON137 headphones.

1. Introduction

Thank you for choosing the Basike Ba-FON137 Bluetooth 5.4 ANC Headphones. This manual provides detailed instructions to help you get the most out of your new headphones. Please read it carefully before use and retain it for future reference.

Package Contents

- 1x Basike Ba-FON137 Bluetooth Headphone
- 1x USB-C Charging Cable
- 1x 3.5mm Audio Cable
- 1x User Manual (this document)



Image: Basike Ba-FON137 Bluetooth Headphones in Pink. This shows the main product in its packaging.

2. Product Overview

The Basike Ba-FON137 headphones are designed for an immersive audio experience with advanced features. Familiarize yourself with the headphone components and controls.



Image: Detailed view of the Basike Ba-FON137 headphone controls. Labels indicate the microphone, Type-C port, indicator light, 3.5mm auxiliary input, ANC ON/OFF switch, and volume/track control buttons.

Key Components:

- **Microphone:** For calls and voice commands.
- **Type-C Port:** For charging the headphones.
- **Indicator Light:** Displays status (pairing, charging, ANC active).
- **3.5mm Auxiliary Input:** For wired audio connection.
- **ANC ON/OFF Switch:** Activates or deactivates Active Noise Cancellation.
- **Volume/Track Control Buttons:** Adjust volume (+/-) and navigate tracks (Next/Previous).
- **Multifunction Button:** Power on/off, play/pause, answer/end calls.

3. Setup

Charging the Headphones

1. Connect the USB-C charging cable to the Type-C port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The indicator light will show charging status. A full charge takes approximately 2 hours.



Image: Illustration of the Basike Ba-FON137's battery life. Shows 2 hours for charging, 40 hours with ANC off, and 30 hours with ANC on.

Bluetooth Pairing

1. Ensure the headphones are charged.
2. Press and hold the Multifunction Button until the indicator light flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "Ba-FON137".
4. Select "Ba-FON137" from the list of available devices to connect.
5. Once connected, the indicator light will turn solid blue or flash slowly.

Your browser does not support the video tag.

Video: A short demonstration of the Basike Ba-FON137 headphones, including unboxing, comfortable design, Bluetooth connection, ANC activation, and wired mode for gaming. This video illustrates the setup and some operational aspects.

4. Operating Instructions

Power On/Off

- **Power On:** Press and hold the Multifunction Button for 3 seconds.
- **Power Off:** Press and hold the Multifunction Button for 3 seconds.

Music Playback

- **Play/Pause:** Press the Multifunction Button once.
- **Next Track:** Press the '+' button once.
- **Previous Track:** Press the '-' button once.
- **Volume Up:** Press and hold the '+' button.
- **Volume Down:** Press and hold the '-' button.

Call Management

- **Answer/End Call:** Press the Multifunction Button once.
- **Reject Call:** Press and hold the Multifunction Button for 2 seconds.
- **Voice Assistant:** Double-press the Multifunction Button (if supported by your device).



Image: A person using the Basike Ba-FON137 headphones on an airplane, illustrating clear calls with the ENC microphone. The image highlights the microphone's ability to reduce background noise.

Active Noise Cancellation (ANC)

- **Activate/Deactivate ANC:** Toggle the ANC ON/OFF switch. The indicator light will change to confirm activation.
- ANC reduces external noise by up to 45 dB, enhancing your listening experience.
- Note: ANC consumes more battery. For extended use, consider deactivating ANC when not needed.



Image: Visual representation of the Basike Ba-FON137 headphones with an overlay indicating Active Noise Cancellation (ANC) up to 48 dB. This image emphasizes the noise reduction capability.

Wired Mode (3.5mm Audio Cable)

- Connect the 3.5mm audio cable to the auxiliary input on the headphones and to your audio source.
- In wired mode, the headphones function passively, and battery power is not required for audio playback. ANC and microphone functions may be limited or unavailable in wired mode.

5. Maintenance and Care

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in a cool, dry place when not in use.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.
- The headphones are not water-resistant. Avoid contact with liquids.



Image: Three close-up views of the Basike Ba-FON137 headphones highlighting their comfortable and ergonomic design: soft and breathable earcups, 90-degree rotation, and adjustable headband.

6. Troubleshooting

If you encounter issues with your headphones, please refer to the following common problems and solutions:

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source using the USB-C cable.
Cannot pair via Bluetooth.	• Ensure headphones are in pairing mode (flashing blue/red light). • Turn off and on Bluetooth on your device. • Forget "Ba-FON137" from your device's Bluetooth list and try pairing again. • Ensure headphones are within 15 meters of your device.
No sound or poor sound quality.	• Check volume levels on both headphones and your connected device. • Ensure the headphones are properly connected via Bluetooth or 3.5mm cable. • If using wired mode, ensure the cable is fully inserted. • Try playing audio from a different source or device.
ANC is not effective.	• Ensure the ANC switch is in the ON position. • ANC is most effective against low-frequency, constant noises (e.g., airplane engines, bus hum). It may be less effective against sudden or high-frequency sounds.
Microphone not working during calls.	• Ensure the headphones are properly connected via Bluetooth. • Check your device's audio settings to ensure the headphone microphone is selected. • If using wired mode, the microphone function may be limited or unavailable.
Battery life is shorter than expected.	• Using ANC continuously will reduce battery life. • High volume levels can also reduce battery life. • Ensure the headphones are fully charged before use.

7. Specifications

Feature	Detail
Model	Ba-FON137
Bluetooth Version	5.4
Compatibility	iOS, Android, Windows (Celulares, Desktops, Notebooks, Tablets)

Feature	Detail
Speaker Diameter	40 mm
Impedance	32 Ω
Frequency Range	16 Hz - 22 kHz
Bluetooth Range	Up to 15 m (without barriers)
Call Autonomy	30 h (20 h with ANC)
Playback Autonomy	40 h (30 h with ANC)
Standby Time	100 h
Charge Time	2 h
Battery Capacity	400 mAh
Audio Connector	3.5 mm jack
Charging Port	Type-C
Playback Modes	Bluetooth / 3.5 mm jack / FM
Weight	248g (0.55 lb)
Dimensions	188 × 176 × 56 mm
Noise Control	Active Noise Cancellation (ANC)
Special Features	Adjustable headband, Noise isolation, Lightweight, Integrated microphone
Water Resistance	Not water-resistant

8. Warranty and Support

Basike Ba-FON137 headphones come with a **1-year warranty** against manufacturing defects. This warranty does not cover damages caused by improper use of the product or use with an incompatible electrical device.

For any questions or support, please contact Basike customer service. Support is available 24 hours a day, 7 days a week.

Please retain your proof of purchase for warranty claims.

© 2026 Basike. All rights reserved.