



[Manuals.plus](#) /

› [Homiflex](#) /

› Homiflex Farmhouse L Shaped Electric Height Adjustable Desk User Manual (Model MAHfleyg09J)

Homiflex MAHfleyg09J

Homiflex Farmhouse L Shaped Electric Height Adjustable Desk User Manual

Model: MAHfleyg09J

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Homiflex Farmhouse L Shaped Electric Height Adjustable Desk. Please read this manual thoroughly before use and retain it for future reference. Proper use and care will ensure the longevity and optimal performance of your desk.

SAFETY INFORMATION

Important Safety Instructions:

- Always ensure the desk is properly anchored to the floor to prevent tipping, especially when adjusting the height.
- Do not overload the desk, as it may cause instability. The maximum weight capacity for the adjustable section is approximately 165 lbs.
- Be cautious when using the electrical components and keep them away from water or other liquids.
- Always follow the manufacturer's instructions for assembly, use, and maintenance.
- Keep children and pets away from the desk during height adjustment.
- Ensure no obstructions are present in the desk's path during height adjustment.
- Disconnect power before cleaning or performing any maintenance.

PACKAGE CONTENTS

Verify all components are present before beginning assembly. Refer to the separate assembly instructions for a complete parts list and hardware identification.



Figure 1: Desk Dimensions and Included Components. This image illustrates the overall dimensions of the L-shaped desk, including the main desktop (70.9" length), hutch (47.2" width, 63" height), and the adjustable desk section (23" height). It also shows the dimensions of the two types of drawers (14.6" x 18.5" with depths of 4.7" and 11.4") and a power strip. The bottom of the image indicates that the product ships in "separate packages".

- L-shaped desk components (desktop, hutch, storage units)
- Electric height adjustable mechanism
- Control panel for height adjustment
- Power strip with 4 AC outlets, 1 USB port, 1 Type-C port
- RGB LED light strips
- Assembly hardware and tools (as specified in separate assembly guide)

SETUP AND ASSEMBLY

The Homiflex L-shaped desk requires assembly. Detailed instructions and labeled parts are included in the packaging. It is recommended to assemble the desk in the desired location to avoid moving it after completion.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.

2. **Identify Parts:** Match all components with the parts list provided in the separate assembly guide.
3. **Assemble Base Structure:** Follow the step-by-step instructions to build the main frame of the desk, including the hutch and storage units.
4. **Install Height Adjustable Mechanism:** Integrate the electric height adjustable leg system according to the assembly guide. Ensure all connections are secure.
5. **Attach Desktop:** Securely fasten the desktop sections to the assembled base.
6. **Install Electrical Components:** Mount the power outlet strip and connect the LED lighting system as instructed.
7. **Final Checks:** Before plugging in, ensure all screws are tightened and the desk is stable.



- Ample Storage Space
- 1 File Drawer for Letter Size / A4 Size
- 2 Storage Drawers
- 8 Open Shelves

Figure 2: Ample Storage Space. This image highlights the various storage options of the desk, including the hutch with sliding barn doors, the main desktop, the lower desk surface, a cabinet, two storage drawers, a file drawer, and open shelves on the adjustable desk base.

OPERATING INSTRUCTIONS

Electric Height Adjustment

The desk features an electric height adjustment system, allowing you to switch between sitting and standing positions effortlessly and quietly.



Figure 3: Height Adjustable Desk in Use. This image demonstrates the desk's height adjustment feature, showing a user standing at 46.45 inches and another sitting at 28.34 inches. The arrows indicate the adjustable range.

- **Adjusting Height:** Use the **UP** and **DOWN** arrow buttons on the LED control panel to raise or lower the desk. The height range is approximately 29.72" to 46.85".
- **Saving Presets:** The control panel allows you to save up to three preferred height settings. To save a setting, adjust the desk to the desired height, then press and hold one of the numbered preset buttons (**1**, **2**, or **3**) until the display confirms the setting is saved.
- **Recalling Presets:** Press a saved preset button (**1**, **2**, or **3**) to automatically move the desk to the corresponding saved height.

Height Adjustable Desk

Enjoy this peaceful instant




Figure 4: LED Control Panel. This image shows the LED display and buttons for controlling the desk's height: Up/Down arrows and three programmable height settings (1, 2, 3).

Integrated Charging Station

The desk includes a built-in power strip for convenient device charging.

- **AC Outlets:** Features 4 AC outlets (120V/12A) for standard electronics.
- **USB Ports:** Includes 1 USB port (5V/2A) and 1 Type-C port (5V/3A) for charging mobile devices.
- **Power Cord:** The integrated power cord is 6.56 feet long.



4 AC Outlets
120V/12A



1 USB Ports
5V/2A



1 TYPE C
5V/3A



Power Cord
6.56-Foot

Figure 5: Built-in Charging Station. This image displays the integrated power strip, detailing its 4 AC outlets, 1 USB port, and 1 Type-C port, along with the power cord length.

RGB LED Lights

The desk is equipped with RGB LED strips for customizable lighting, enhancing your workspace ambiance.

- **Control:** The LED lights can be controlled via a dedicated smartphone app or the included physical remote control.
- **Features:** Includes music sync functionality, allowing lights to react to audio, and a timer function for scheduled operation.



Figure 6: RGB LED Lighting. This image shows the desk with its LED lights illuminated, along with the remote control and smartphone app interface used to manage the lighting features, including built-in mic, music sync, and timing functions.

MAINTENANCE

Regular maintenance helps preserve the appearance and functionality of your desk.

- **Cleaning Surfaces:** Wipe surfaces with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the laminated finish.
- **Electrical Components:** Ensure all electrical connections are dry and free from dust. Do not attempt to repair electrical components yourself. If issues arise, contact customer support.
- **Moving the Desk:** When relocating the desk, ensure the height is set to its lowest position and disconnect all power cables. Lift the desk carefully, avoiding dragging, which can damage the legs or floor.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they are tight. Loose connections can affect stability and performance.

TROUBLESHOOTING

If you encounter any issues with your Homiflex desk, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Desk does not adjust height.	Power cable disconnected; motor overload; control panel malfunction.	Check power connection. Reduce weight on desk. Contact customer support if issue persists.
Desk moves unevenly or makes unusual noises.	Uneven load; loose fasteners; obstruction.	Distribute weight evenly. Check and tighten all fasteners. Remove any obstructions.
LED lights not working.	Power disconnected; app/remote issue; LED strip malfunction.	Ensure power is connected. Check app/remote battery. Contact customer support.
Charging ports not working.	Power disconnected; device incompatibility; port malfunction.	Verify desk is plugged in. Test with different devices/cables. Contact customer support.

SPECIFICATIONS

Detailed specifications for the Homiflex Farmhouse L Shaped Electric Height Adjustable Desk.

Feature	Detail
Brand	Homiflex
Model Number	MAHfleyg09J
Shape	L-Shape
Desk Design	Computer Desk, Executive Desk
Overall Product Dimensions (D x W x H)	Adjustable Section: 23.6"D x 70.86"W; Hutch Section: 47.2"W; Total Height (with hutch): 63"
Color	White & Brown
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Finish Type	Laminated
Special Feature	Adjustable Height
Minimum Height (Adjustable Section)	29.72 Inches
Maximum Height (Adjustable Section)	46.85 Inches
Item Weight	160.49 Pounds
Number of Drawers	3 (including 1 file drawer)

Feature	Detail
Number of Shelves	Multiple (open shelves on adjustable base and in hutch)
Number of Cabinets	1
Charging Station	4 AC outlets (120V/12A), 1 USB (5V/2A), 1 Type-C (5V/3A)
LED Lighting	RGB with App/Button control, Music Sync, Timer
Required Assembly	Yes



Figure 7: Overall Desk Dimensions. This image provides a comprehensive view of the L-shaped desk's dimensions, including the 70.9" length of the main desktop, 23.6" depth, and the 47.2" width of the hutch section.

WARRANTY INFORMATION

This product comes with a Limited Warranty. Please refer to the warranty card included in your package or contact Homiflex customer support for specific details regarding coverage and duration. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For assembly assistance, troubleshooting, or warranty claims, please contact Homiflex customer support. Contact

information can typically be found on the product packaging or the manufacturer's official website.

Online Resources: [Visit the Homiflex Store on Amazon](#)