Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JADEMALL JADEMALL Bluetooth Keyboard for Samsung Galaxy Tab A9+/A9 Plus 11-inch

JADEMALL Bluetooth Keyboard for Samsung Galaxy Tab A9+/A9 Plus 11-inch

Instruction Manual

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your JADEMALL Bluetooth Keyboard, designed specifically for the Samsung Galaxy Tab A9+/A9 Plus 11-inch tablet. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

Compatibility

This keyboard case is compatible exclusively with the Samsung Galaxy Tab A9+/A9 Plus 11-inch (2023 models: SM-X210, SM-X215, SM-X216, SM-X218). To verify your tablet's model number, please check the back of your device.



Figure 1: Compatibility details for Samsung Galaxy Tab A9+/A9 Plus 11-inch models.

Package Contents

The package typically includes:

- 1 x JADEMALL Bluetooth Keyboard Case
- 1 x USB Charging Cable
- 1 x User Manual

Setup

1. Attaching the Tablet

Carefully place your Samsung Galaxy Tab A9+/A9 Plus 11-inch into the protective case. Ensure all ports, buttons, and the camera

align with the precise cutouts of the case.




Figure 2: Case with precise cutouts for tablet features.

2. Bluetooth Pairing

1. Ensure the keyboard is charged (refer to "Maintenance" for charging instructions).
2. Turn on the keyboard by sliding the power switch to the "ON" position. The Bluetooth indicator light will flash.
3. On your Samsung Galaxy Tab A9+/A9 Plus, go to **Settings** > **Connected devices** > **Bluetooth** and turn Bluetooth on.
4. Select "Connect" on the keyboard (usually a dedicated button or Fn+C combination). The Bluetooth indicator will start blinking rapidly.
5. On your tablet, search for available devices. Select "Bluetooth Keyboard" (or similar name) from the list.
6. Follow any on-screen prompts to complete the pairing process. The indicator light on the keyboard will stop flashing once connected.

The keyboard can be detached from the case and used with other Bluetooth-enabled devices.



Figure 3: Magnetic Bluetooth keyboard with 7-color backlight.

Operating Instructions

1. Adjusting Viewing Angles

The case features three integrated grooves to adjust the tablet's viewing angle. Position your tablet in one of these grooves for optimal comfort during typing, viewing, or drawing. Available angles are approximately 120°, 125°, and 130°.



Figure 4: Multiple viewing angles supported by the case.

2. Backlight Control

The keyboard features a 7-color backlit design. Use the dedicated backlight key (often represented by a light bulb icon) or a function key combination (e.g., **Fn + Light Bulb icon**) to cycle through colors and adjust brightness levels.

3. Automatic Sleep/Wake Function

The case supports an automatic sleep/wake function. Closing the case will put your tablet to sleep, and opening it will wake it up, helping to conserve battery life.

4. Using the Integrated Stylus Holder

An integrated holder is provided for your stylus (stylus not included). This ensures your stylus is always conveniently stored and accessible.



Figure 5: Stylus holder and charging port.

Maintenance

1. Charging the Keyboard

The keyboard features a built-in rechargeable lithium battery. Connect the provided USB charging cable to the keyboard's charging port and to a standard USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

2. Cleaning

Wipe the keyboard and case with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the surfaces.

Troubleshooting

- **Keyboard not connecting via Bluetooth:**
  - Ensure the keyboard is charged and powered on.
  - Make sure Bluetooth is enabled on your tablet.
  - Forget the device from your tablet's Bluetooth settings and try pairing again.
  - Restart both the keyboard and your tablet.
- **Keys not responding:**
  - Check if the keyboard battery is low and charge it.
  - Ensure the keyboard is properly connected via Bluetooth.
  - Try restarting the keyboard and tablet.
- **Backlight not working:**
  - Ensure the keyboard is powered on and charged.
  - Press the backlight key or Fn + backlight key combination to activate or cycle through modes.

Specifications

Brand	JADEMALL
Compatibility	Samsung Galaxy Tab A9+/A9 Plus 11-inch (SM-X210/X215/X216/X218)
Connectivity	Bluetooth
Keyboard Layout	AZERTY (French)
Backlight	7-color adjustable backlight
Battery	Integrated rechargeable lithium battery
Material	Premium double-layer PU leather exterior, anti-slip honeycomb plastic interior
Special Features	Magnetic detachable keyboard, multiple viewing angles (120°, 125°, 130°), auto sleep/wake, integrated stylus holder

Warranty and Support

JADEMALL is committed to providing the best shopping experience. If you encounter any issues with your keyboard case (e.g., keys not working, charging problems), please do not hesitate to contact our customer service. We will provide a satisfactory solution to ensure your pleasant experience.
For support, please refer to the contact information provided with your purchase or visit the official JADEMALL website.

Usage Scenarios

The versatile design of this keyboard case makes it suitable for various environments, including work, school, travel, and home use. It enhances productivity for typing, writing, and viewing videos.



Figure 6: Keyboard case in various usage scenarios.

© 2023 JADEMALL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GR8XWY29

More documents and user manuals: **https://manuals.plus/**