Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE ULSD316KD02S

VASAGLE ULSD316KD02S Electric Standing Desk User Manual

Model: ULSD316KD02S

1. Introduction

This manual provides essential information for the safe and efficient use of your VASAGLE ULSD316KD02S Electric Standing Desk. Please read these instructions thoroughly before assembly and operation to ensure proper function and longevity of your product. This electric standing desk is designed to offer a versatile workspace, allowing seamless transitions between sitting and standing positions, promoting a healthier work routine.

2. Safety Instructions

Adhering to these safety guidelines is crucial for preventing injury and damage to the product:

- Do not place heavy objects on the product that exceed the maximum load of 154 lb (70 kg).
- Keep all electrical components away from liquids to prevent electrical hazards.
- Do not place the desk against the wall during height adjustment to avoid scratches or damage.
- Use the safety lock function to prevent accidental operation, especially around children.
- Always follow the assembly instructions carefully.
- Ensure all screws and fasteners are tightened securely before use.
- Do not allow children to operate the desk without adult supervision.

3. Package Contents

Verify that all components are present before beginning assembly:

- 1 x Electric Standing Desk (Desktop and Frame Components)
- 1 x Accessory Kit (Screws, tools, small parts)

- 1 x Instruction Manual

4. Assembly Instructions

The VASAGLE ULSD316KD02S Electric Standing Desk is designed for effortless assembly. Follow the detailed instructions provided in the included manual for a quick setup.

1. **Join the Desktop Panels:** Carefully connect the desktop sections using the provided hardware.
2. **Assemble the Frame:** Attach the legs and crossbars to form the sturdy desk frame.
3. **Attach the Desktop to the Frame:** Secure the assembled desktop to the frame.
4. **Connect Electrical Components:** Plug in the motor and control panel as indicated in the manual.

All parts are clearly labeled, and the instructions include diagrams to guide you through each step. Assembly typically takes approximately 30 minutes.



Image: Visual guide for the 3-step assembly process.

5. Operating Instructions

Control Panel Overview

The desk features an intuitive control panel located on the front edge of the desktop.




Image: Close-up of the control panel with height display and buttons.

Height Adjustment

Use the up (▲) and down (▼) arrow buttons to manually adjust the desk height. The current height is displayed on the digital screen.

Memory Presets

The desk offers 4 memory presets to save your preferred sitting and standing heights. This allows for quick and easy

transitions.

- **To Save a Height:** Adjust the desk to your desired height. Press the 'M' button (or similar memory set button, if applicable, otherwise assume the number buttons are for saving). Then press one of the number buttons (1, 2, 3, or 4) until the display flashes or beeps, indicating the height is saved.
- **To Recall a Height:** Simply press the corresponding number button (1, 2, 3, or 4) to automatically move the desk to your saved position.



Image: Diagram showing different height settings for various users.

Sedentary Reminder

The desk includes a sedentary reminder function to prompt you to change posture or stretch, helping to reduce body fatigue. The 4th memory button often shares this function.




Image: A user standing up at the desk, prompted by the sedentary reminder.

Safety Lock Function

To prevent accidental operation, especially by children, the desk is equipped with a safety lock.

- **To Lock:** Press and hold the up (▲) and down (▼) arrow buttons together for approximately 3 seconds until 'LOC' appears on the display.
- **To Unlock:** Press and hold the up (▲) and down (▼) arrow buttons together again for approximately 3 seconds until 'LOC' disappears.




Image: Hand pressing buttons to activate the safety lock feature.

6. Features

Your VASAGLE Electric Standing Desk comes with several thoughtful features to enhance your workspace:

- **Sturdy & Steady Construction:** Built with reinforced legs and a robust steel frame, the desk remains solid and wobble-free, supporting up to 154 lb (70 kg). The premium motor is tested for 20,000 lifts, ensuring smooth and reliable height adjustments.
- **Spacious Desktop:** The 63"W x 27.6"D desktop provides ample space for multiple monitors, office supplies, and other essentials, offering 16.7% more workspace compared to smaller models.
- **Practical Cable Holes:** Two integrated cable holes help manage and hide cords, contributing to a neat and organized workspace.
- **Convenient Hooks:** Two side hooks are included for hanging bags, headphones, or other items, keeping them within easy reach and off the desktop.
- **Rounded Corners:** The desktop features rounded corners to help reduce bumps and enhance safety in busy work environments.



Image: Demonstrates the desk's stability and 154 lb load capacity.

Practical Cable Holes

- Allow for easy cable management




Image: Close-up of the practical cable holes for organization.

Convenient Hooks

- Perfect for hanging bags, headphones, and more



Image: Shows the convenient hooks attached to the desk frame.

Rounded Corners

- Help reduce bumps





Image: Illustrates the rounded corners of the desktop for safety.

7. Specifications

Attribute	Detail
Brand	VASAGLE
Model Number	ULSD316KD02S
Product Dimensions	63"W x 27.6"D x 28.3"-46.5"H (160 cm W x 70 cm D x 72-118 cm H)
Height Adjustment Range	28.3" - 46.5" (72 - 118 cm)
Maximum Weight Capacity	154 lb (70 kg)
Material	Steel, Particleboard, PA Plastic
Color	Rustic Brown
Special Features	Sedentary Reminder, 4 Memory Heights, Safety Lock, Cable Holes, Side Hooks, Rounded Corners
Assembly Required	Yes




Image: Detailed dimensions and maximum static load capacity.

8. Maintenance

To keep your electric standing desk in optimal condition:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and not pinched or tangled, which could affect desk operation or cause damage.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 154 lb (70 kg) to prevent damage to the motor and frame.

9. Troubleshooting

If you encounter issues with your desk, refer to the following common solutions:

Problem	Possible Cause	Solution
Desk not moving	Power cable disconnected, safety lock engaged, overload	Check power connection, disengage safety lock, reduce weight on desk
Uneven height adjustment	Obstruction, uneven weight distribution	Remove obstructions, redistribute weight evenly, perform a reset (refer to full manual for specific reset procedures)
Unusual noise during operation	Loose screws, obstruction in lifting mechanism	Check and tighten all screws, inspect for obstructions
Sedentary reminder not working	Feature not activated or incorrectly set	Refer to the operating instructions for activating and setting the sedentary reminder

For more complex issues or if troubleshooting steps do not resolve the problem, please contact VASAGLE customer support.

10. Warranty and Support

Your VASAGLE Electric Standing Desk is covered by a manufacturer's warranty. Please refer to the warranty information included with your purchase for details on coverage and duration. For technical support, replacement parts, or any other inquiries, please contact VASAGLE customer service through the contact information provided in your product packaging or on the official VASAGLE website.

11. Product Video Overview

Watch this official product video for a visual guide on the features and benefits of the VASAGLE Electric Standing Desk.

Video: An overview of the VASAGLE Electric Standing Desk, highlighting its adjustable height, sedentary reminder, and sturdy construction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GRBKFJV3

More documents and user manuals: **https://manuals.plus/**