

Skullcandy INKD_PLUS

Skullcandy INKD+ Earbuds Instruction Manual

Model: INKD_PLUS

INTRODUCTION

Welcome to your Skullcandy INKD+ Earbuds. This manual provides comprehensive instructions to help you set up, operate, maintain, and troubleshoot your new earbuds. The INKD+ earbuds are designed for a comfortable, noise-isolating audio experience with convenient in-line controls for managing calls and music.



Image: Skullcandy INKD+ Earbuds, showcasing their sleek design.

1. SETUP

1.1 Unboxing and Components

Carefully remove all contents from the packaging. You should find the following items:

- Skullcandy INKD+ Earbuds with in-line remote and 3.5mm audio jack
- Multiple sizes of silicone ear gels (small, medium, large)

1.2 Choosing the Right Ear Gels

Selecting the correct ear gel size is crucial for optimal sound quality and comfort. Experiment with the different sizes provided to find the best fit for your ears. A good fit will create a seal that enhances bass and noise isolation.

1. Gently remove the pre-installed ear gels from the earbuds.
2. Select a different size ear gel and firmly push it onto the earbud nozzle until it is securely attached.
3. Insert the earbuds into your ears. If the fit feels loose or sound quality is poor, try a different size.

1.3 Connecting to Your Device

The Skullcandy INKD+ Earbuds connect to your audio device via a standard 3.5mm audio jack.

- Locate the 3.5mm audio port on your smartphone, tablet, computer, or other audio device.

- Insert the 3.5mm audio jack of the INKD+ earbuds firmly into the device's audio port.
- Ensure the connection is secure to prevent audio interruptions.

2. OPERATING INSTRUCTIONS

The INKD+ earbuds feature an in-line remote for easy control of your audio and calls.

2.1 Music Control

- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice quickly.
- **Previous Track:** Press the center button three times quickly.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.

2.2 Call Management

- **Answer/End Call:** Press the center button once.
- **Reject Call:** Press and hold the center button for 2 seconds.

2.3 Activate Voice Assistant

- **Activate Voice Assistant:** Press and hold the center button for 2 seconds (when not on a call).

3. MAINTENANCE

Proper care ensures the longevity and performance of your INKD+ earbuds.

3.1 Cleaning Earbuds and Ear Gels

- Gently remove the silicone ear gels from the earbuds.
- Wash the ear gels with mild soap and warm water. Rinse thoroughly and allow them to air dry completely before reattaching.
- Use a soft, dry, lint-free cloth to wipe the earbud housing and cable.
- For stubborn dirt on the earbud nozzles, use a dry cotton swab or a small, soft brush. **Do not use liquids directly on the earbud drivers.**

3.2 Storage

- When not in use, store your earbuds in a clean, dry place, preferably in a small pouch or case to prevent tangling and damage.
- Avoid wrapping the cable too tightly around the earbuds or remote, as this can cause internal wire damage over time.

4. TROUBLESHOOTING

If you encounter issues with your INKD+ earbuds, try the following solutions:

4.1 No Sound or Intermittent Audio

- **Check Connection:** Ensure the 3.5mm audio jack is fully inserted into your device's port.
- **Test Another Device:** Plug the earbuds into a different audio device to determine if the issue is with the earbuds or the original device.
- **Check Device Volume:** Ensure the volume on your audio device is turned up and not muted.

- **Inspect Cable:** Look for any visible damage or kinks in the earbud cable.

4.2 Poor Sound Quality (Muffled, Distorted, or Low Bass)

- **Ear Gel Fit:** Ensure you are using the correct size ear gels for a proper seal in your ear canal.
- **Clean Earbuds:** Check if the earbud nozzles or ear gels are blocked by earwax or debris. Clean them as described in the Maintenance section.
- **Audio Source Quality:** Test with different audio files or streaming services to rule out a low-quality source.

4.3 Microphone Not Working

- **Device Compatibility:** Ensure your device supports the in-line microphone function with a 3.5mm jack. Some older devices may not.
- **Check Connection:** A loose connection can affect microphone functionality.
- **Test Another Device:** Try the earbuds with another device to isolate the problem.

4.4 In-line Remote Not Responding

- **Device Compatibility:** Some functions of the in-line remote may not be fully compatible with all devices or operating systems.
- **Check Connection:** Ensure the 3.5mm jack is fully inserted.
- **Restart Device:** Sometimes a simple device restart can resolve minor software glitches.

5. SPECIFICATIONS

Key specifications for your Skullcandy INKD+ Earbuds:

Brand	Skullcandy
Model Name	INKD_PLUS
Material	Silicone, Nylon
Enclosure Material	Silicone, Nylon

6. WARRANTY INFORMATION

Skullcandy products are built to last, but if something goes wrong, we're here to help. Your Skullcandy INKD+ Earbuds are covered by a limited warranty against manufacturing defects. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Skullcandy website.

Please retain your proof of purchase for warranty claims.

7. SUPPORT

If you require further assistance or have questions not covered in this manual, please contact Skullcandy Customer Support:

- **Online Support:** Visit the official Skullcandy support website for FAQs, troubleshooting guides, and contact options.
- **Contact Information:** Refer to the Skullcandy website or product packaging for the most current customer service phone numbers and email addresses.

