

[Manuals.plus](#) /

› [Generico](#) /

› Generico Recliner Chair 373536 User Manual

Generico 373536

Generico Recliner Chair 373536 User Manual

Model: 373536

1. INTRODUCTION

Thank you for choosing the Generico Recliner Chair 373536. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: Front view of the Generico Recliner Chair 373536 in light gray fabric.

2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Do not exceed the maximum weight capacity of 110 kg (242 lbs).
- Keep children and pets away from moving parts during operation.
- Avoid placing fingers or other body parts near the reclining mechanism to prevent injury.
- Do not stand on the chair or use it as a step stool.
- Periodically check all bolts and screws to ensure they are tight.

3. PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- Backrest section
- Seat section with armrests
- Footrest assembly
- Legs/Feet (typically 4)
- Assembly hardware (screws, bolts, washers, Allen key)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is required for this recliner chair. Follow these general steps. Refer to the specific assembly diagram included in your package for detailed instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent damage.
2. **Attach Legs:** Securely attach the chair legs to the base of the seat section using the provided hardware. Ensure they are tightened firmly.
3. **Connect Backrest:** Slide the backrest into the receiving brackets on the seat section. Ensure it clicks into place or is secured with the designated locking mechanism/hardware.
4. **Verify Connections:** Double-check that all connections are secure and tight before using the chair.



Image 4.1: Front view of the assembled recliner chair.

5. OPERATING INSTRUCTIONS

The Generico Recliner Chair features a manual recline function for personalized comfort.

1. **To Recline:** Locate the handle on the right side of the chair (when seated). Pull this handle to release the footrest and allow the backrest to recline. Lean back gently to achieve your desired recline angle, up to a maximum of 135 degrees.
2. **To Return to Upright Position:** Push down on the footrest with your legs while simultaneously leaning forward. The backrest will return to its upright position, and the footrest will lock into place.




Image 5.1: Illustration of the recliner chair in various recline positions, demonstrating the range of motion.



Image 5.2: Side view highlighting the manual recline handle and the convenient side storage pocket.



Image 5.3: Detailed view of the manual recline handle for easy operation.

6. MAINTENANCE

Proper care will extend the life and appearance of your recliner chair.

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner following the product's instructions. Test on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Check Hardware:** Periodically inspect and tighten all screws and bolts to ensure stability.

7. TROUBLESHOOTING

If you encounter issues with your recliner, refer to the following common solutions:

- **Chair does not recline smoothly:** Check for any obstructions in the mechanism. Ensure all assembly bolts are tightened correctly.
- **Footrest does not stay down:** Verify that the recline handle is fully released and the mechanism is not jammed.
- **Squeaking noises:** Apply a small amount of silicone-based lubricant to moving metal parts of the reclining

mechanism. Avoid oil-based lubricants on fabric.

- **Wobbling:** Ensure all legs are securely attached and all assembly hardware is tightened. Adjust leg levelers if present.

8. SPECIFICATIONS

Feature	Detail
Model Number	373536
Color	Light Gray
Material	Fabric (100% Polyester), Metal, Plywood
Filling Material	Foam, PP Fiber
Dimensions (Folded)	77 x 95 x 99 cm (L x W x H)
Dimensions (Reclined)	77 x 146 x 81.5 cm (L x W x H)
Seat Width	50 cm
Seat Depth	57 cm
Seat Height from Floor	42-44 cm
Armrest Height from Floor	58 cm
Maximum Load Capacity	110 kg (242 lbs)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GRG3TN61>

More documents and user manuals: <https://manuals.plus/>