

Nothing Phone 4a 5G

Nothing Phone 4a 5G User Manual

Model: Phone 4a 5G | Brand: Nothing

1. INTRODUCTION

Welcome to the user manual for your Nothing Phone 4a 5G. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. The Nothing Phone 4a 5G is designed for powerful performance, immersive visuals, and versatile photography. It features a 6.78-inch AMOLED display, a Snapdragon 7s Gen 4 processor, a 50MP triple camera system, and a 5400mAh battery, running on Android 16 with Nothing OS 4.1.

Please read this manual thoroughly to ensure optimal use and longevity of your smartphone.

2. WHAT'S IN THE BOX

Upon unboxing your Nothing Phone 4a 5G, please verify that all the following items are included:

- Nothing Phone 4a 5G Handset
- Nothing Cable (USB Type-C to Type-C)
- Phone Case
- Screen Protector (pre-applied)
- SIM Tray Ejector Tool
- Safety Information and Warranty Card

Note: A power adapter is not included in the box and must be purchased separately.

3. SETUP

3.1. SIM Card Installation

Your Nothing Phone 4a 5G supports Dual Nano SIM cards. Follow these steps to install your SIM cards:

1. Locate the SIM card tray on the side of your phone.

2. Insert the SIM ejector tool into the small hole on the SIM tray and press firmly until the tray pops out.
3. Place your Nano SIM cards into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully reinsert the SIM tray back into the phone until it clicks into place.



Image: Rear view of the Nothing Phone 4a 5G in White, highlighting the transparent design and camera module. The SIM tray is located on the side frame.

3.2. Initial Power On

Press and hold the Power button on the side of the phone until the Nothing logo appears on the screen. The phone will then boot up.

3.3. Initial Configuration

Follow the on-screen prompts to complete the initial setup. This includes selecting your language, connecting to a Wi-Fi network, signing in with your Google account, and setting up security features like fingerprint or face unlock. Your device runs on Nothing OS 4.1, based on Android 16.

4. OPERATING YOUR DEVICE

4.1. Display

The Nothing Phone 4a 5G features a 6.78-inch AMOLED display with a resolution of 1224 x 2720 pixels. It supports a 120Hz refresh rate for smooth scrolling and HDR10+ for vibrant colors. The display offers up to 1600 nits HBM and 4500 nits peak brightness, protected by Corning Gorilla Glass 7i.

4.2. Camera System

Your phone is equipped with an advanced triple rear camera system and a high-resolution front camera:

- **Main Camera:** 50MP with Optical Image Stabilization (OIS)
- **Periscope Telephoto Camera:** 50MP with OIS and 3.5x optical zoom
- **Ultrawide Camera:** 8MP
- **Front Camera:** 32MP for selfies and video calls

The rear camera supports 4K video recording, Dolby Vision HDR, Ultra XDR, Gyro-EIS, and OIS for stable and high-quality video capture. Various shooting modes are available, including Night, Portrait, Panorama, and Pro Mode.



Image: Close-up of the Nothing Phone 4a 5G's rear camera module, detailing the triple lens setup.

4.3. Performance

Powered by the Qualcomm Snapdragon 7s Gen 4 processor with an octa-core CPU and Adreno 810 GPU, the Phone 4a 5G delivers responsive performance for multitasking, gaming, and demanding applications. It comes with 8GB or 12GB RAM and up to 256GB of UFS 3.1 internal storage.

4.4. Battery and Charging

The device is equipped with a 5400mAh battery. It supports 50W wired fast charging, capable of reaching 50% charge in approximately 22 minutes and 100% in about 64 minutes. Use a compatible 50W charger for optimal charging speeds.

4.5. Connectivity

The Nothing Phone 4a 5G supports 5G cellular connectivity, Wi-Fi 6, Bluetooth 5.4, and NFC. It features a USB Type-C port for charging and data transfer. GPS, BeiDou, GLONASS, Galileo, and QZSS navigation systems are supported.

4.6. Security Features

For secure access, the phone includes an in-display optical fingerprint sensor and Face Unlock functionality.

4.7. Glyph Interface

The unique Glyph Interface on the rear of the phone features 63 mini-LEDs with 6 individually addressable zones. These LEDs can be customized for notifications, charging status, and other visual alerts.

5. MAINTENANCE

5.1. Software Updates

Your Nothing Phone 4a 5G is designed to receive up to 3 major Android operating system updates and 6 years of security patches. Ensure your device is connected to Wi-Fi and has sufficient battery life before performing any software updates. Navigate to **Settings > System > System update** to check for and install available updates.

5.2. Cleaning Your Device

To clean your phone, use a soft, lint-free cloth. Avoid using abrasive materials, solvents, or aerosol sprays. For stubborn smudges, slightly dampen the cloth with water. Ensure no moisture enters ports or openings. The phone has an IP64 dust and water resistance rating, but it is not waterproof; avoid submerging it in liquids.

6. TROUBLESHOOTING

If you encounter issues with your Nothing Phone 4a 5G, try the following basic troubleshooting steps:

- **Restart the Device:** A simple restart can resolve many minor software glitches. Press and hold the Power button, then select 'Restart'.
- **Check Connections:** For connectivity issues (Wi-Fi, Bluetooth, cellular), ensure that the respective features are enabled and that you are within range of a strong signal.
- **Clear App Cache:** If a specific app is misbehaving, try clearing its cache. Go to **Settings > Apps > [App Name] > Storage & cache > Clear cache**.
- **Software Update:** Ensure your phone's software is up to date (refer to Section 5.1).
- **Factory Reset:** As a last resort, if persistent issues occur, you may perform a factory reset. This will erase all

data on your phone, so ensure you back up important information first. Go to **Settings > System > Reset options > Erase all data (factory reset)**.

For more complex issues, refer to the support information provided in Section 8.

7. SPECIFICATIONS

Below are the detailed technical specifications for the Nothing Phone 4a 5G:

Feature	Specification
Brand	Nothing
Model	Phone 4a 5G
Operating System	Nothing OS 4.1 Powered by Android 16
Processor	Qualcomm Snapdragon 7s Gen 4 (Octa-core CPU, Adreno 810 GPU)
RAM	8 GB / 12 GB
Internal Storage	128 GB / 256 GB (UFS 3.1)
Display	6.78-inch AMOLED, 1224 x 2720 Pixels, 120Hz Refresh Rate, HDR10+, 4500 nits Peak Brightness, Corning Gorilla Glass 7i
Rear Camera	50MP Main (OIS) + 50MP Periscope Telephoto (OIS, 3.5x Optical Zoom) + 8MP Ultrawide
Front Camera	32 MP
Battery Capacity	5400 mAh (Lithium-Ion)
Charging	50W Wired Fast Charging (50% in 22 min, 100% in 64 min)
Connectivity	5G, Wi-Fi 6, Bluetooth 5.4, NFC, USB Type-C
SIM Card	Dual Nano SIM
Biometric Security	In-display Optical Fingerprint Sensor, Face Unlock
Water Resistance	IP64 Dust and Water Resistant
Dimensions	16.2 x 7.6 x 0.9 Centimeters
Weight	204 Grams

8. WARRANTY INFORMATION

The Nothing Phone 4a 5G comes with a 1-year manufacturer warranty for the handset in India. In-box accessories such as the data cable and any applicable earphones or removable batteries are covered for 6 months from the date of purchase. A valid invoice is required to claim warranty services. Exclusions may apply as per Nothing India's

warranty terms.

For detailed warranty terms and conditions, please refer to the warranty card included in your product box or visit the official Nothing India website.

9. SUPPORT INFORMATION

Should you require technical assistance or have questions regarding your Nothing Phone 4a 5G, please contact the official support channels:

- **Manufacturer:** Padget Electronics
- **Packer Contact Information:** Nothing Technology India Pvt. Ltd., Bengaluru, Karnataka, India
- **Importer Contact Information:** Nothing Technology India Pvt. Ltd., Bengaluru, Karnataka, India

For the most up-to-date support contact details and online resources, please visit the official Nothing website.