

- Manuals.plus /
- > [GAN XIN](#) /
 - > GAN XIN Scoreboard Console Gx.09mRYG Instruction Manual

GAN XIN Gx.09mRYG

GAN XIN Scoreboard Console Gx.09mRYG Instruction Manual

Model: Gx.09mRYG

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your GAN XIN Scoreboard Console, Model Gx.09mRYG. This console is designed as a replacement or accessory for compatible GAN XIN scoreboards (e.g., ASIN: B0DMDXS1DG).

1.1 Package Contents

- 1 x GAN XIN Scoreboard Console (Model Gx.09mRYG)



Figure 1: Front view of the GAN XIN Scoreboard Console, showing its buttons and display area. This image displays the compact design

2. SETUP

The GAN XIN Scoreboard Console is designed for straightforward integration with compatible GAN XIN scoreboards. Ensure your scoreboard is powered off before connecting the console.

2.1 Connecting the Console

1. Locate the designated console port on your GAN XIN scoreboard unit. This port is typically labeled for console or remote control connection.
2. Connect the console's cable securely into the scoreboard's console port. Ensure the connection is firm to prevent accidental disconnection during use.
3. Once connected, power on your scoreboard unit. The console should automatically establish communication with the scoreboard.

Note: Refer to your specific GAN XIN scoreboard's instruction manual for detailed connection diagrams and compatibility information.

3. OPERATING INSTRUCTIONS

The GAN XIN Scoreboard Console provides intuitive control over your scoreboard's functions. The layout of buttons and display may vary slightly depending on the specific scoreboard model it controls.

3.1 Basic Functions

- **Power On/Off:** The console typically powers on with the scoreboard. Some consoles may have a dedicated power button.
- **Score Adjustment:** Use the designated buttons (e.g., '+1', '+2', '+3', 'Reset') to adjust scores for Home and Guest teams.
- **Timer Control:** Buttons for 'Start/Stop', 'Reset', and 'Set Time' allow management of game time or shot clock.
- **Period/Foul Control:** Dedicated buttons for advancing periods, adjusting fouls, or timeouts.
- **Display Modes:** Some consoles offer options to switch between different display modes or statistics.

For detailed instructions on specific functions and advanced features, always refer to the comprehensive user manual provided with your GAN XIN scoreboard unit.

4. MAINTENANCE

Proper care and maintenance will ensure the longevity and reliable performance of your GAN XIN Scoreboard Console.

4.1 Cleaning

- Wipe the console's surface with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or strong chemicals, as these can damage the plastic material and electronic components.
- Ensure no liquid enters the console through button gaps or ports.

4.2 Storage

- Store the console in a cool, dry place away from direct sunlight and extreme temperatures.

- Protect the console from physical impact and excessive dust.

5. TROUBLESHOOTING

If you encounter issues with your GAN XIN Scoreboard Console, refer to the following common troubleshooting steps.

5.1 Common Issues

- **Console Not Responding:**
 - Check if the console cable is securely connected to the scoreboard.
 - Ensure the scoreboard itself is powered on and functioning correctly.
 - If applicable, check the console's power source or batteries.
- **Incorrect Display/Functionality:**
 - Verify that the console model is compatible with your specific scoreboard model.
 - Restart both the scoreboard and the console by powering them off and then on again.
 - Refer to your scoreboard's manual for specific error codes or troubleshooting steps related to console communication.

If problems persist after attempting these steps, please contact customer support or refer to the warranty information.

6. SPECIFICATIONS

Feature	Specification
Brand Name	GAN XIN
Model Name	Gx.09mRYG
Material	Plastic
Color	White
Item Dimensions (LxWxH)	7.87 x 3.15 x 10.24 inches
Item Package Dimensions (LxWxH)	11.02 x 8 x 4 inches
Package Weight	16 ounces
Included Components	Console
Suggested Users	Unisex-adult
Manufacturer	HANGZHOU GANXIN ELECTRONIC CO .,LTD
ASIN	B0GRZYT12M

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This GAN XIN Scoreboard Console comes with a **1 Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact the manufacturer, HANGZHOU GANXIN ELECTRONIC CO.,LTD, or the seller from whom you purchased the product. Refer to your purchase documentation for specific contact details.

© 2026 GAN XIN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GRZYT12M>

More documents and user manuals: <https://manuals.plus/>