

[Manuals.plus](#) /

› [Garvee](#) /

› Garvee Pop Up Screen Tent 70"x70" (3-4 Person) Instruction Manual

Garvee 6ft-s72e4

Garvee Pop Up Screen Tent Instruction Manual

Model: 70"x70" (3-4 Person)

INTRODUCTION

The Garvee Pop Up Screen Tent is designed to provide a comfortable and protected outdoor space for various activities. This all-season shelter offers protection against wind, rain, and snow, making it suitable for year-round use. Its spacious interior and high ceiling provide ample room for 2-3 adults, enhancing visibility and movement. The tent features a quick pop-up design for easy setup and an arched roof structure to prevent water accumulation. Crafted from high-quality TPU material, it ensures clear visibility and durability against temperature extremes and tearing. The weather-resistant fabric also provides UPF 40 UV protection.

SPACIOUS INTERIOR

Fits **2-3** People. Enjoy Leisure Time Together



This image shows the spacious interior of the tent, comfortably accommodating multiple individuals for leisure activities.

SAFETY INFORMATION


Always set up the tent on a flat, stable surface. Avoid using in high winds or severe weather conditions. Keep the tent away from heat sources and open flames. Always follow the manufacturer's instructions for setup, use, and dismantling. Consult a professional if you are unsure about any aspect of the tent's use.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Pop Up Screen Tent (Main Unit) x1

- Compression Strap x1
- Ground Nail x8
- Wind Rope x4
- Storage Bag x1
- Instruction Manual x1
- Support Pole x2




This diagram details the tent's dimensions and lists all components included in the package, aiding in inventory and assembly.

SETUP INSTRUCTIONS

1. **Unpack the Tent:** Remove the tent from its storage bag and lay it flat on a clear, level surface.
2. **Pop-Up Action:** The main frame is designed to pop up instantly. Gently unfold the tent, allowing the flexible steel frame to expand into its full shape.
3. **Insert Support Poles:** Locate the two support poles. Insert them into the designated sleeves or connectors to provide additional structural integrity, especially for the arched roof.
4. **Secure with Ground Nails:** Use the provided ground nails to secure the tent's base to the ground. Insert nails through the loops at the bottom edges of the tent.

5. **Attach Wind Ropes:** For enhanced stability, especially in breezy conditions, attach the four wind ropes to the designated points on the tent. Stake the other end of the ropes into the ground at an appropriate distance, ensuring tension.



This image visually guides users through the quick setup process of the pop-up tent, showing its instant deployment.

OPERATING INSTRUCTIONS

Doors and Windows

- The tent features closable doors and windows. Use the zippers to open and close them as needed for entry, exit, or weather protection.
- The high-quality TPU material provides clear, wide visibility while inside the tent.

Ventilation

- In warmer conditions, open the windows to allow for airflow and ventilation.
- In colder conditions, keep windows and doors closed to retain warmth.

Recommended Uses

This tent is ideal for various outdoor activities, including:


- Camping and picnics
- Backyard and patio use
- Sports events
- RV trips
- Fishing and sunbathing



This illustration demonstrates the tent's capability to provide protection against diverse weather elements, ensuring comfort year-round.

ULTIMATE COMFORT

for Every Outdoor Activity



This image highlights the tent's versatility for various outdoor activities, providing comfort and shelter during leisure.

MAINTENANCE

Cleaning

- Clean the TPU material and fabric with a soft cloth, mild soap, and water. Avoid harsh chemicals or abrasive cleaners that could damage the material.
- Rinse thoroughly and allow the tent to air dry completely before folding and storing.

Storage

- Ensure the tent is completely dry before folding to prevent mold and mildew.
- Carefully fold the tent according to the instructions to fit it back into the provided storage bag.

- Store the tent in a cool, dry place away from direct sunlight and extreme temperatures.

Inspection

- Periodically inspect the frame, fabric, zippers, and seams for any signs of wear or damage.
- Address any minor repairs promptly to extend the lifespan of the tent.

MORE DETAILS




Waterproof



Flexible & Durable



High-strength Support Rod



Galvanized Steel Flexible Frame



Unbreakable Zipper

This image provides a closer look at the high-quality components of the tent, including its waterproof fabric, robust frame, and durable zippers.

TROUBLESHOOTING

Tent Instability in Wind

- **Solution:** Ensure all 8 ground nails are securely staked into the ground. Utilize the 4 wind ropes, anchoring them firmly to provide additional stability. Avoid using the tent in excessively high winds.

Excessive Heat Inside the Tent

- **Solution:** Open the tent's windows and doors to allow for cross-ventilation. The tent's design is intended to offer protection, which can trap heat in direct sunlight.

Difficulty Folding the Tent for Storage

- **Solution:** The pop-up frame requires a specific folding technique. Refer to the visual instructions in the manual or practice the folding process a few times. Ensure the tent is completely dry before attempting to fold and store.

SPECIFICATIONS

Feature	Detail
Brand	Garvee
Model Number	6ft-s72e4
Size	70"x70" (3-4 Person)
Item Dimensions (L x W x H)	68.11"L x 68.11"W x 81.5"H
Floor Area	36 Square Feet
Material	TPU (Tent Fabric), Alloy Steel (Frame)
Item Weight	19.6 Pounds
Water Resistance Level	Waterproof
Ultraviolet Light Protection	UPF 40+
Frame Type	Round
Required Assembly	No (Pop-up design)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Garvee website. Keep your proof of purchase for any warranty claims.